

Programmer's Reference to the DCOM Interface of DEWESoft 6.4

Version 2006-06 (for DEWESoft 6.4)



www.dewetron.com

Contents

Contents.....	2
List of Figures	5
List of Tables.....	8
1 Introduction.....	9
2 Plug-ins for DEWESoft.....	10
2.1 General Information about DEWESoft Plug-ins.....	10
2.2 Prerequisites for DEWESoft Plug-ins	11
3 General Information about DEWESoft.....	12
3.1 The Buffer Structure.....	12
3.2 The Channel Structur	12
4 Creating Plug-Ins in Visual Basic 6	13
4.1 GUID and Registration.....	13
4.2 MS Visual Basic Example Code	14
5 Creating Plug-ins in Borland Delphi 7	18
5.1 The basic steps	18
5.2 EmptyTemplate Delphi 7 Source Code.....	25
5.2.1 Source Code of the Project EmptyTemplate.dpr.....	25
5.2.2 Source code of EmptyTemplateIMPL.pas:	26
5.2.3 Source code of EmptyTemplateForm.pas:	30
5.3 Registering a Delphi Plug-in	31
6 CustomExport.....	32
6.1 General Information on CustomExport.....	32
6.2 Creating a CustomExport in Delphi 7	32
6.3 ICustomExport, ICustomExport2, IExportFrame	36
6.4 ICustomExport	37
6.4.1 Methods  of ICustomExport.....	37
6.4.2 Properties  of ICustomExport	40
6.5 ICustomExport2	41
6.5.1 Methods  of ICustomExport2.....	41
6.6 IExportFrame	43
6.6.1 Methods  of IExportFrame	43
6.7 Source Code of the CustomExport.....	43
6.7.1 Source Code of a CustomExport Unit.....	44
6.7.2 Source Code of a CustomExport Frame/Form.....	47
7 Description of Methods and Properties.....	48
7.1 IAISetupScreen	48
7.1.1 Methods  of IAISetupScreen	48
7.2 IAlarms.....	48
7.2.1 Properties  of IAlarms	48
7.3 IAlarmCond.....	48
7.3.1 Properties  of IAlarmCond	48
7.3.2 Methods  of IAlarmCond.....	49
7.4 IAChannel	49
7.4.1 Properties  of IAChannel	49
7.5 IAOGroup.....	52
7.5.1 Properties  of IAOGroup	52
7.6 IApp.....	54
7.6.1 Methods  of IApp	54

7.6.2	Properties  of IApp	64
7.6.3	Events  of IApp.....	69
7.6.4	Types / Constants  of IApp.....	70
7.7	IAveragedFFT	70
7.7.1	Methods  of IAveragedFFT	70
7.7.2	Properties  of IAveragedFFT.....	71
7.8	ICAN	73
7.8.1	Properties  of ICAN.....	73
7.9	ICANPort	74
7.9.1	Methods  of ICANPort	74
7.9.2	Properties  of ICANPort	75
7.10	IChannel	75
7.10.1	Methods  of IChannel.....	75
7.10.2	Properties  of IChannel.....	78
7.10.3	Types / Constants  of IChannel	82
7.11	IChannelConnection.....	84
7.11.1	Methods  of IChannelConnection	84
7.11.2	Properties  of IChannelConnection	86
7.11.3	Types / Constants  of IChannelConnection.....	87
7.12	IChannelGroup.....	87
7.12.1	Methods  of IChannelGroup.....	87
7.12.2	Properties  of IChannelGroup.....	87
7.13	IChannelGroup2.....	88
7.13.1	Methods  of IChannelGroup2.....	88
7.14	IChannelGroups	88
7.14.1	Properties  of IChannelGroups	88
7.15	IChannelList.....	88
7.15.1	Properties  of IChannelList.....	88
7.16	IDaqChannel.....	88
7.16.1	Methods  of IDaqChannel	88
7.16.2	Properties  of IDaqChannel	88
7.17	IDaqData	89
7.17.1	Methods  of IDaqData	89
7.17.2	Properties  of IDaqData	90
7.18	IDaqGroup.....	91
7.18.1	Properties  of IDaqGroup	91
7.19	IData.....	92
7.19.1	Methods  of IData.....	92
7.19.2	Properties  of IData.....	93
7.20	IDataSection	95
7.20.1	Methods  of IDataSection.....	95
7.20.2	Properties  of IDataSection.....	95
7.21	IDataSections	96
7.21.1	Properties  of IDataSections	96
7.22	IEvent	96
7.22.1	Properties  of IEvent.....	96
7.23	IEventList.....	96
7.23.1	Properties  of IEventList.....	96
7.24	IFilenameSettings.....	97
7.24.1	Properties  of IFilenameSettings.....	97
7.25	ILoadEngine.....	99

7.25.1	Methods  of ILoadEngine.....	99
7.25.2	Properties  of ILoadEngine.....	100
7.26	IMasterClock.....	100
7.26.1	Methods  of IMasterClock.....	100
7.27	IModule.....	100
7.27.1	Methods  of IModule.....	100
7.27.2	Properties  of IModule.....	101
7.28	IModules.....	102
7.28.1	Properties  of IModules	102
7.29	IPadData.....	102
7.29.1	Methods  of IPadData.....	102
7.29.2	Properties  of IPadData.....	102
7.30	IPlugin2.....	103
7.30.1	Methods  of IPlugin2.....	103
7.30.2	Properties  of IPlugin2.....	105
7.31	IPlugin3.....	105
7.31.1	Methods  of IPlugin3.....	105
7.32	IPluginGroup.....	107
7.32.1	Methods  of IPluginGroup.....	107
7.32.2	Properties  of IPluginGroup.....	108
7.33	IScreen.....	108
7.33.1	Methods  of IScreen	108
7.33.2	Properties  of IScreen	108
7.34	IScreens.....	108
7.34.1	Properties  of IScreens.....	108
7.35	IStoreEngine.....	109
7.35.1	Methods  of IStoreEngine	109
7.35.2	Properties  of IStoreEngine	109
7.36	ITrig.....	109
7.36.1	Properties  of ITrig	109
7.37	ITrigger.....	110
7.37.1	Properties  of ITrigger	110
7.38	ITriggerCondition.....	110
7.38.1	Properties  of ITriggerCondition	110
7.39	ITriggerCondList.....	111
7.39.1	Properties  of ITriggerCondList	111
7.39.2	Methods  of ITriggerCondList	111
7.40	IVideoLoadEngine	112
7.40.1	Methods  of IVideoLoadEngine.....	112
7.41	IVideoLoadEngines.....	112
7.41.1	Properties  of IVideoLoadEngines	112
8	DEWESoft DCOM Interface Tree	113
9	DEWESoft DCOM Interface – Properties and Methods	114
	Index.....	147

List of Figures

Figure 1 The DCOM Interface	9
Figure 2 Plugins Tab of the Hardware Setup	10
Figure 3 Plug-in Frame, directly embedded into the Setup Screen.....	11
Figure 4 "Configure" Button in Plugins Tab.....	11
Figure 5 Buffer Structure	12
Figure 6 The Channel Structure	12
Figure 7 Reference to DEWESoft Library in a VB Project	13
Figure 8 Class ID registered using regsvr32	13
Figure 9 DEWESoft plug-in entries	14
Figure 10 Plug-in Frame, directly embedded into the Setup Screen.....	18
Figure 11 New ActiveX Library	18
Figure 12 Save Project as.....	19
Figure 13 New Type Library.....	19
Figure 14 Type Library, Uses Tab	19
Figure 15 Type Library, Select DEWESoft Library	20
Figure 16 Type Library, Show Selected.....	20
Figure 17 Type Library, "Refresh Implementation"	21
Figure 18 Type Library, New CoClass	21
Figure 19 Type Library, Rename CoClass.....	21
Figure 20 Type Library, Insert Interface	22
Figure 21 TypeLibrary, Insert Interface "IPlugin2"	22
Figure 22 Type Library, "Refresh Implementation"	22
Figure 23 Save Type Library as.....	23
Figure 24 New Frame.....	23
Figure 25 Save Frame as.....	24
Figure 26 Rename Frame	24
Figure 27 New Unit.....	24
Figure 28 Save Unit as.....	25
Figure 29 Setting the Host Application.....	25
Figure 30 File Export – Export file types.....	32
Figure 31 File >> New >> Other.....	32
Figure 32 New ActiveX Library	33
Figure 33 Save Project As.....	33
Figure 34 File >> New >> Unit.....	33
Figure 35 Save Unit As.....	34
Figure 36 Target File Extension.....	34
Figure 37 Import Type Library	34
Figure 38 Import Type Library – Create Unit.....	35
Figure 39 CustomExport Flowchart (1)	36
Figure 40 CustomExport Flowchart (2)	37
Figure 41 Time Axis for Export.....	40
Figure 42 Export Frame in DEWESoft's Export Screen	43
Figure 43 ShowChannelSetup.....	48
Figure 44 Analog Output Channel Setup	49
Figure 45 Analog Output Amplitude	50
Figure 46 AOChannel FilterFreq1 (for low pass filter)	50
Figure 47 AOChannel FilterFreq1 (for band pass filter).....	50
Figure 48 AOChannel FilterFreq2 (for band pass filter).....	50
Figure 49 AOChannel FilterType	50

Figure 50 AOChannel FilterOrder	51
Figure 51 AOChannel FilterProtoType.....	51
Figure 52 Analog Output Offset.....	51
Figure 53 Analog Output Phase	51
Figure 54 Analog Output Waveform	52
Figure 55 AmplChangeFactor.....	52
Figure 56 DCChangeFactor	52
Figure 57 FreqChangeFactor.....	53
Figure 58 PhaseChangeFactor.....	53
Figure 59 Analog Output Manual Start/Stop Button	54
Figure 60 Changing the DAQ Type in DEWESoft's Hardware Setup.....	55
Figure 61 Com Port for the Modules	55
Figure 62 File Export in DEWESoft	56
Figure 63 Hardware Setup.....	56
Figure 64 Load Display Setup Menu Item	57
Figure 65 Load Data File	57
Figure 66 Load Setup	58
Figure 67 Storing Options	58
Figure 68 Manual Start Trigger.....	58
Figure 69 Manual Stop Trigger.....	58
Figure 70 Measure.....	59
Figure 71 MenuItem Load Setup	59
Figure 72 New Setup.....	59
Figure 73 Pause Storing	59
Figure 74 Print Button.....	60
Figure 75 Resume Storing.....	60
Figure 76 SaveSetup.....	60
Figure 77 Data Header	61
Figure 78 Setting the Main Data Directory	62
Figure 79 Add display	63
Figure 80 Screens of a kind.....	63
Figure 81 DEWESoft's Storing Options	63
Figure 82 Setup Button	63
Figure 83 Store Button	64
Figure 84 Stop Button	64
Figure 85 Acquisition Rate	66
Figure 86 Property Frame of Measurement Screen	67
Figure 87 Sampling Rate Options	67
Figure 88 Store Options	67
Figure 89 ShowStyle = 0.....	68
Figure 90 ShowStyle = 1	68
Figure 91 ShowStyle = 2.....	68
Figure 92 AveragedCPB Weighting	71
Figure 93 AveragedFFT Averages Count	72
Figure 94 AveragedFFT Averaging Type.....	72
Figure 95 Averaged FFT Lines	72
Figure 96 Averaged FFT Window Type.....	73
Figure 97 Channel Setup Button	79
Figure 98 Channel Setup.....	80
Figure 99 Sample rate divider	82
Figure 100 "Used" Button	82

Figure 101 AType set to ctLast	86
Figure 102 AType set to ctOverlap, Overlap set to 0.....	86
Figure 103 AType set to ctOverlap, Overlap set to 50.....	86
Figure 104 AutoZero	89
Figure 105 Current Position Cursor	94
Figure 106 "Used" Button	95
Figure 107 Data File Options – Create a multifile	97
Figure 108 Data File Options – Absolute time	97
Figure 109 Data File Options – Make new file after.....	97
Figure 110 Data File Options – Size	97
Figure 111 Data File Options – Unit.....	98
Figure 112 Data File Options – File name	98
Figure 113 Filename setup – Start index.....	98
Figure 114 Filename setup – Date of storing	98
Figure 115 Filename setup – Multifile	99
Figure 116 Filename setup – Time of storing	99
Figure 117 Storing Options	109
Figure 118 Trigger Properties	110
Figure 119 DEWESoft DCOM Interface Tree.....	113

List of Tables

Table 1 Screen Buttons 61
Table 2 T_ChIndex..... 83
Table 3 List of Properties and Methods 114

1 Introduction

This reference should help developers to use DEWESoft's DCOM Interface. The interface as documented in this paper is available in DEWESoft 6.4 or newer.

As illustrated in Figure 1, the DCOM Interface of DEWESoft 6.4 and newer offers the possibility to design plug-ins for DEWESoft doing some special tasks on the one hand and to implement other applications controlling DEWESoft, which is called 'automation', on the other hand.

Plug-ins and applications for automating DEWESoft can be developed in different programming languages, e.g. Borland Delphi, MS Visual Basic, MS Visual C++/C# or NI LabVIEW (automation only). In this reference some examples are described using MS Visual Basic and Borland Delphi 7.




Figure 1 The DCOM Interface

2 Plug-ins for DEWESoft

2.1 General Information about DEWESoft Plug-ins

On the one hand, the motivation for creating plug-ins for DEWESoft can be to gain access to acquired data during measurement e.g. in order to make some special calculations on it or to output the data via RS-232, etc. On the other hand, the task of a plug-in could be to add further data channels to DEWESoft. This could be data of a special sensor (e.g. connected via RS-232) or data which is derived from special calculations on data currently measured by DEWESoft. In both ways, coming from DEWESoft or being added to DEWESoft, data can be either synchronous or asynchronous.

When a plug-in is registered to the windows registry before or on startup of DEWESoft, as described later, it will be listed in the “Plugins” tab of the hardware setup as shown in Figure 2. If a plug-in is checked here, it will appear in the “Plugins” tab of the measurement setup screen too.




Figure 2 Plugins Tab of the Hardware Setup

A plug-in, which is an ActiveX library (ActiveX DLL), can consist of two main parts. The one part is the plug-in implementation itself, which is necessary in any case. The other part is a frame or a window which task is to allow the user to change some settings of the plug-in. Whether this part is a frame or a separate window depends on the development environment used for creating the plug-in. In case of a plug-in designed in Delphi, using a frame would be a suitable solution. This frame will appear directly embedded into the Plugins tab of the measurement setup-screen of DEWESoft as shown in Figure 3.




Figure 3 Plug-in Frame, directly embedded into the Setup Screen

In case of a plug-in created by means of a programming environment not supporting “frames”, e.g. Visual Basic, it is not possible to create such a frame being embedded into DEWESoft. Therefore settings of a plug-in have to be made in a separate window. This window can be opened by clicking the “Configure”-button which will appear instead of the frame in the Plug-ins tab (see Figure 4).




Figure 4 "Configure" Button in Plug-ins Tab

2.2 Prerequisites for DEWESoft Plug-ins

The IPlugin2 interface is available in DEWESoft Version 6.2 and newer. With version 6.3 of DEWESoft the interface IPlugin3 is introduced, offering additional functionalities for plug-ins. IPlugin3 is derived from IPlugin2, so it has to be used together with the functions of IPlugin2.

It is not recommended to use the interface “IPlugin” for the development of any new plug-ins any longer. “IPlugin2” substitutes “IPlugin” and offers an extended functionality. “IPlugin” will still remain supported in DEWESoft in order to work in conjunction with any plug-ins developed by customers so far.

3 General Information about DEWESoft

3.1 The Buffer Structure

The data acquired by DEWESoft is stored according to the buffer structure illustrated in Figure 5. At first the data is stored to the so-called direct buffer. After having acquired a certain number of values, the minimum, maximum, average and RMS values are calculated and stored to intermediate buffer. After the collection of a certain amount of values within the intermediate buffer, once again the minimum, maximum, average and RMS values are calculated. Consequently these are stored to the so-called reduced buffer.




Figure 5 Buffer Structure

3.2 The Channel Structure

The channel structure of DEWESoft can be compared to Figure 6. The channels of the same kind are grouped together to a ChannelGroup. Such a group can be e.g. for analog channels, for digital channels, for CAN data, etc. These groups are put together to the ChannelGroups which is an element of Data.

Another way for accessing a channel would be via the list of AllChannels or of UsedChannels.




Figure 6 The Channel Structure

4 Creating Plug-Ins in Visual Basic 6

For developing plug-ins for DEWESoft, the DEWESoft library has to be referenced to the project within the development system. In Visual Basic this is done via 'Project' >> 'References' and checking the DEWESoft Library as shown in Figure 7.

Plug-ins created with an earlier version of the library will not work with newer versions of DEWESoft.




Figure 7 Reference to DEWESoft Library in a VB Project

When programming new plug-ins, each plug-in has to implement all the functions of Plugin2.

4.1 GUID and Registration

In order to apply a plug-in to DEWESoft, it is necessary to register its GUID (Globally Unique Identifier) to windows. This can be done using 'regsvr32.exe'. Within the command window (cmd.exe) type in as follows:

```
regsvr32 c:\myfolder\myplugin.dll
```

(where 'c:\myfolder' has to be substituted by the corresponding path and 'myplugin' by the name or the ActiveX-library). Having done this, the GUID is inserted into the registry and can be found using the registry editor ('regedit.exe'). The entry will be named like the name-property of the class as defined in the development environment. This entry will be found in "HKEY_CLASSES_ROOT" looking similar to Figure 8.



Figure 8 Class ID registered using regsvr32

In order to inform DEWESoft about the existence of a plug-in, an additional entry needs to be created within the registry. In the section "HKEY_LOCAL_MACHINE\SOFTWARE\Dewesoft\Plugins" a key, e.g. "MyPlugin" must be created. Within this key, the string-values "Description", "GUID", "Name", "Vendor" and

“Version” can be set. Setting “GUID” to the corresponding value in “HKEY_CLASSES_ROOT” (e.g. at “HKEY_CLASSES_ROOT\ MyPlugin.Class1\Clsid”) is necessary. Setting the value “Name” is recommended in order to be able to identify the plug-in within the hardware configuration dialog of DEWESoft. The entries within the windows registry can be similar to Figure 9.




Figure 9 DEWESoft plug-in entries

4.2 MS Visual Basic Example Code

```
Implements IPlugin2
Dim FApp As DEWESoft.App
Dim Ch1 As DEWESoft.IChannel
Dim Ch2 As DEWESoft.IChannel
```

```
Private Sub Class_Terminate()

    Set FApp = Nothing
    Set Ch1 = Nothing
    Set Ch2 = Nothing

End Sub
```

```
Private Sub IPlugin2_ClearChannelsInstance()

    'Executed before all channels are destroyed in DEWESoft.
    'All instances have to be cleared.
    '(set to "nothing" or "nil" in other languages)

    Set Ch1 = Nothing
    Set Ch2 = Nothing

End Sub
```

```
Private Sub IPlugin2_Configure()

    'Executed when the 'Configure'-button is clicked by the user
```

The DCOM Interface of DEWESoft 6.4 – Creating Plug-Ins in Visual Basic 6

```
frmMyConfigurationDialog.frmMyConfigurationDialog_Init

End Sub

Private Sub IPlugin2_HideFrame()
    'Executed, when the setup screen is left.

End Sub

Private Property Get IPlugin2_Id() As String
    'The GUID of the plug-in should be returned here.

End Property

Private Sub IPlugin2_Initiate(ByVal DeweApp As DEWESoft.IApp)
    'When DEWESoft is started and the plug-in
    'is checked in the hardware configuration.

    Set FApp = DeweApp

End Sub

Private Sub IPlugin2_LoadSetup(ByVal Data As Variant)
    'When a channel setup is loaded.
    '(corresponds to File >> Load Setup)

    MountChannels

End Sub

Private Sub IPlugin2_NewSetup()
    'When a new channel setup is created.
    '(corresponds to File >> New Setup)

    MountChannels

End Sub

Private Sub IPlugin2_OnGetData()
    'When new data is added to a channel.
    'This happens every 40 ms.
    'It is not necessary to add any new data.

    Dim TimeStamp As Double

    TimeStamp = FApp.MasterClock.GetCurrentTime
    Call Ch1.AddAsyncSingleSample(Rnd, TimeStamp)
    Call Ch2.AddAsyncSingleSample(Rnd, TimeStamp)

End Sub

Private Sub IPlugin2_OnOleMsg(ByVal Msg As Long, ByVal Param As Long)

End Sub

Private Sub IPlugin2_OnStartAcq()
    'When data acquisition starts

End Sub
```

```
Private Sub IPlugin2_OnStartStoring()  
    'When the storing of data is started  
End Sub
```

```
Private Sub IPlugin2_OnStopAcq()  
    'When data acquisition is stopped  
End Sub
```

```
Private Sub IPlugin2_OnStopStoring()  
    'When the storing of data is stopped  
End Sub
```

```
Private Sub IPlugin2_OnTrigger(ByVal Time As Double)  
    'When a trigger occurs.  
    'Returns the corresponding measurement time in seconds.  
End Sub
```

```
Private Sub IPlugin2_SaveSetup(Data As Variant)  
    'When a channel setup is saved  
    '(corresponds to File >> Save Setup)  
End Sub
```

```
Private Function IPlugin2_ShowFrame(ByVal Parent As Long) As Boolean  
    'When entering the setup screen.  
    IPlugin2_ShowFrame = False  
End Function
```

```
Private Sub IPlugin2_UpdateFrame()  
    'When the frame is updated.  
End Sub
```

```
Private Property Let IPlugin2_Used(ByVal RHS As Boolean)  
    FUsed = RHS  
End Property
```

```
Private Property Get IPlugin2_Used() As Boolean  
    'Corresponds to the check box in the  
    'hardware configuration in the plugin tab.  
    IPlugin2_Used = FUsed  
End Property
```

```
Private Sub MountChannels()  
    'Sub for mounting the channels.  
Dim PluginGroup As DEWESoft.IPluginGroup  
Set PluginGroup = FApp.Data.Groups(8)
```

```
Err.Clear
On Error Resume Next
ChLat.Used = True
ChLon.Used = True

If Err.Number <> 0 Then
    Err.Clear
    On Error GoTo errorhandler
    Set Ch1 = PluginGroup.MountChannel(5, True, -1)
    Ch1.Name = "First channel"
    Ch1.Used = True

    Set Ch2 = PluginGroup.MountChannel(5, True, -1)
    ChLon.Name = "Second channel"
    ChLon.Used = True
End If

Set PluginGroup = Nothing
Exit Sub

errorhandler:
    MsgBox ("Error on MountChannels")

End Sub
```

5 Creating Plug-ins in Borland Delphi 7

Delphi is the most suitable programming environment for creating plug-ins. The main advantage is the ability to create so-called frames. These frames are similar to forms but do not have window-like characteristics like a title bar or a surrounding border, when embedded in DEWESoft.

The frame of a plug-in created in Delphi will appear seamlessly integrated in the “Plugins” tab of the measurement setup screen of DEWESoft e.g. like shown in the picture below.




Figure 10 Plug-in Frame, directly embedded into the Setup Screen

The task of the frame of a plug-in is to allow the user to alter some necessary settings required to make the plug-in work.

5.1 The basic steps

The basic steps for creating plug-ins using Delphi are as follows:

Create a new ActiveX Library (New >> Other... >> ActiveX >> ActiveX Library).




Figure 11 New ActiveX Library

Save Project as... >> Template.dpr (choose a name suitable for your application).




Figure 12 Save Project as...

Add a new type library (New >> Other... >> ActiveX >> Type Library).




Figure 13 New Type Library

Within the type library window switch to the “Uses” tab. Only the "OLE Automation" type library is listed and checked. Select "Show all type libraries" from the context menu (right mouse click) of the type library list.




Figure 14 Type Library, Uses Tab

Scroll to the latest version of the "DEWESoft library" and check it. Since DEWESoft version 6.2b43 the DEWESoft library version 6.2 is available. Plug-ins created with earlier versions

of the library (1.0) will not work with newer versions of DEWESoft. Since DEWESoft version 6.3.x/6.4x the DEWESoft library version 630.6 (276.6 in Hex notation) is available.




Figure 15 Type Library, Select DEWESoft Library

Click "Show Selected" from the context menu.




Figure 16 Type Library, Show Selected

Now you should see just the two necessarily selected type libraries. Click the “Refresh Implementation” button from the tool bar. (See mouse cursor in picture below.)




Figure 17 Type Library, “Refresh Implementation”

Create a “New CoClass” (by clicking the third icon of the tool bar)...




Figure 18 Type Library, New CoClass

...and rename it to “Plugin”.




Figure 19 Type Library, Rename CoClass

Select “Insert Interface” from the context menu of the “Implements” tab...




Figure 20 Type Library, Insert Interface

...and choose “IPlugin2” from the “Insert Interface” dialog. (You may choose both, “IPlugin2” and “IPlugin3” with latest versions of DEWESoft.)




Figure 21 TypeLibrary, Insert Interface "IPlugin2"

Afterwards click “Refresh Implementation” again.




Figure 22 Type Library, "Refresh Implementation"

Now save the type library as e.g. “Template.tlb” (choose a name which is suitable for your application).




Figure 23 Save Type Library as...

Next step is to add a “frame” by clicking “File >> New >> Frame”... (For some applications it might be useful to choose a Form instead of a Frame. If a Form is used, its property BorderStyle has to be set to bsNone via the Object Inspector.)




Figure 24 New Frame

...and to save the frame as e.g. “TemplateFrame.pas” (choose a name suitable for your application).




Figure 25 Save Frame as...

Now you may rename the frame to e.g. “SetupFrame” by altering the Name property in the Object Inspector.




Figure 26 Rename Frame

Now click “File >> New >> Unit” to add a new unit to the project.




Figure 27 New Unit

Save this unit which is the main implementation of the plug-in, as e.g. “PluginIMPL”




Figure 28 Save Unit as...

In order to be able to debug the application during development, specify DEWESoft.exe as the “Host Application”. Click Run >>Parameters... and click the browse button within the “Run Parameters” dialog to select the path to DEWESoft. (In most cases this will be “C:\Dewetron\Program\DEWESoft6\DEWESoft.exe”.) Every time the debugging of the plug-in in Delphi is started, DEWESoft will be started automatically.




Figure 29 Setting the Host Application

After having completed these steps described above, some standard code has to be added. Each of the functions which can be called by DEWESoft has to be implemented in the plug-in.

5.2 EmptyTemplate Delphi 7 Source Code

The following listing contains the fundamental source code lines which will be necessary in any plug-in developed in Delphi 7.

5.2.1 Source Code of the Project EmptyTemplate.dpr

```
library EmptyTemplate;
```

```
uses
```

```
    ComServ,
```

```
EmptyTemplate_TLB in 'EmptyTemplate_TLB.pas',
EmptyTemplateIMPL in 'EmptyTemplateIMPL.pas',
EmptyTemplateForm in 'EmptyTemplateForm.pas' {SetupForm},
DEWESoft_TLB in 'DEWESoft_TLB.pas';

exports
  DllGetClassObject,
  DllCanUnloadNow,
  DllRegisterServer,
  DllUnregisterServer;

{$R *.TLB}

{$R *.RES}

begin
end.
```

5.2.2 Source code of EmptyTemplateIMPL.pas:

```
unit EmptyTemplateIMPL;

interface

uses ComObj, Dewesoft_TLB, Forms, EmptyTemplate_TLB, Controls, SysUtils;

type
  TPlugin = class(TAutoObject, IPlugin2, IPlugin3)
  private
    FForm: TForm;
    FApp: IApp;
    FUsed: Boolean;
  protected
    //IPlugin2 -->
    function Get_Id: WideString; safecall;
    function Get_Used: WordBool; safecall;
    function ShowFrame(Parent: Integer): WordBool; safecall;
    procedure ClearChannelsInstance; safecall;
    procedure Configure; safecall;
    procedure HideFrame; safecall;
    procedure Initiate(const DeweApp: IApp); safecall;
    procedure LoadSetup(Data: OleVariant); safecall;
    procedure NewSetup; safecall;
    procedure OnGetData; safecall;
    procedure OnStartAcq; safecall;
    procedure OnStartStoring; safecall;
    procedure OnStopAcq; safecall;
    procedure OnStopStoring; safecall;
    procedure OnTrigger(Time: Double); safecall;
    procedure SaveSetup(var Data: OleVariant); safecall;
    procedure Set_Used(Value: WordBool); safecall;
    procedure UpdateFrame; safecall;
    procedure OnOleMsg(Msg: Integer; Param: Integer); safecall;
    //<-- IPlugin2

    //IPlugin3 -->
    procedure OnStartSetup; safecall;
    procedure OnStopSetup; safecall;
    procedure OnBeforeStartAcq(var AllowStart: WordBool); safecall;
    procedure OnAfterStartAcq; safecall;
    procedure OnBeforeStopAcq(var AllowStop: WordBool); safecall;
    procedure OnAfterStopAcq; safecall;
    procedure OnRepaintFrame; safecall;
    procedure OnTriggerStop(Time: Double; TrigDuration: Double); safecall;
    procedure OnAfterCalcMath; safecall;
    function GetDWTypeLibVersion: Integer; safecall;
    procedure OnGetSetupData; safecall;
```

```
    procedure OnResizeFrame(Width: Integer; Height: Integer); safecall;
    procedure ProvidesClock(var Value: WordBool); safecall;
    procedure OnGetClock(var ClockLow: Integer; var ClockHigh: Integer); safecall;
    procedure SetCANPort(Port: Integer); safecall;
    procedure OnAlarm(CondIndex: Integer; Status: WordBool); safecall;
    procedure OnBigListLoad(const TextSetup: WideString); safecall;
    procedure OnExit; safecall;
    //<-- IPlugin3

public
    procedure Initialize; override;
    destructor Destroy; override;
end;

TPluginObjectFactory = class(TAutoObjectFactory)
public
    procedure UpdateRegistry(Register: Boolean); override;
end;

implementation

uses ComServ, Registry, Windows, EmptyTemplateForm, StdCtrls, Variants;

{ TPluginObjectFactory }
procedure TPluginObjectFactory.UpdateRegistry(Register: Boolean);
var
    Reg: TRegistry;
begin
    inherited UpdateRegistry(Register);
    if Register then
    begin
        Reg := TRegistry.Create(KEY_ALL_ACCESS);
        Reg.RootKey := HKEY_LOCAL_MACHINE;
        Reg.OpenKey('Software\Dewesoft\Plugins\EmptyTemplate', True);
        Reg.WriteString('GUID', GUIDToString(CLASS_Plugin));
        Reg.WriteString('Name', 'EmptyTemplate');
        Reg.WriteString('Version', 'beta');
        Reg.WriteString('Description', 'Just an empty template...');
        Reg.WriteString('Vendor', 'Dewesoft');
        Reg.WriteInteger('TLB', DEWESoftMinorVersion);
        Reg.Free;
    end else
    begin
        Reg := TRegistry.Create(KEY_ALL_ACCESS);
        Reg.RootKey := HKEY_LOCAL_MACHINE;
        Reg.DeleteKey('Software\Dewesoft\Plugins\EmptyTemplate');
        Reg.Free;
    end;
end;

function TPlugin.Get_Id: WideString;
begin
    Result := GUIDToString(CLASS_Plugin);
end;

function TPlugin.Get_Used: WordBool;
begin
    Result := FUsed;
end;

function TPlugin.ShowFrame(Parent: Integer): WordBool;
begin
    FForm := TSetupForm.Create(nil, Parent);
    FForm.ParentWindow := HWND(Parent);
    FForm.Align := alClient;
    TSetupForm(FForm).Plugin := Self;
    Result := True;
end;

procedure TPlugin.ClearChannelsInstance;
```

```
begin

end;

procedure TPlugin.Configure;
begin

end;

procedure TPlugin.HideFrame;
begin
  if FForm <> nil then
  begin
    FForm.Visible := False;
    FForm.ParentWindow := 0;
  end;
  FreeAndNil(FForm);
end;

procedure TPlugin.Initiate(const DeweApp: IApp);
begin
  FApp := DeweApp;
end;

procedure TPlugin.LoadSetup(Data: OleVariant);
begin
  // Mount Channels here, if necessary!
end;

procedure TPlugin.NewSetup;
begin
  // Mount Channels here, if necessary!
end;

procedure TPlugin.OnGetData;
begin

end;

procedure TPlugin.OnStartAcq;
begin

end;

procedure TPlugin.OnStartStoring;
begin

end;

procedure TPlugin.OnStopAcq;
begin

end;

procedure TPlugin.OnStopStoring;
begin

end;

procedure TPlugin.OnTrigger(Time: Double);
begin

end;

procedure TPlugin.SaveSetup(var Data: OleVariant);
begin

end;

procedure TPlugin.Set_Used(Value: WordBool);
```

```
begin
  FUsed:= Value;
end;

procedure TPlugin.UpdateFrame;
begin

end;

destructor TPlugin.Destroy;
begin
  inherited;
end;

procedure TPlugin.OnOleMsg(Msg, Param: Integer);
begin

end;

function TPlugin.GetDWTypeLibVersion: Integer;
begin
  Result:= DEWESoftMinorVersion;
end;

procedure TPlugin.OnAfterCalcMath;
begin

end;

procedure TPlugin.OnAfterStartAcq;
begin

end;

procedure TPlugin.OnAfterStopAcq;
begin

end;

procedure TPlugin.OnBeforeStartAcq(var AllowStart: WordBool);
begin

end;

procedure TPlugin.OnBeforeStopAcq(var AllowStop: WordBool);
begin

end;

procedure TPlugin.OnGetClock(var ClockLow, ClockHigh: Integer);
begin

end;

procedure TPlugin.OnGetSetupData;
begin

end;

procedure TPlugin.OnRepaintFrame;
begin

end;

procedure TPlugin.OnResizeFrame(Width, Height: Integer);
begin
  if Assigned(FForm) then
  begin
    FForm.Width := Width;
    FForm.Height := Height;
  end;
end;
```

```
    end;
end;

procedure TPlugin.OnStartSetup;
begin

end;

procedure TPlugin.OnStopSetup;
begin

end;

procedure TPlugin.OnTriggerStop(Time, TrigDuration: Double);
begin

end;

procedure TPlugin.ProvidesClock(var Value: WordBool);
begin

end;

procedure TPlugin.SetCANPort(Port: Integer);
begin

end;

procedure TPlugin.OnAlarm(CondIndex: Integer; Status: WordBool);
begin

end;

procedure TPlugin.OnBigListLoad(const TextSetup: WideString);
begin

end;

procedure TPlugin.OnExit;
begin

end;

procedure TPlugin.Initialize;
begin
    inherited;
end;

initialization
    TPluginObjectFactory.Create(ComServer, TPlugin, Class_Plugin,
        ciMultiInstance, tmApartment);
end.
```

5.2.3 Source code of EmptyTemplateForm.pas:

```
unit EmptyTemplateForm;

interface

uses
    Windows, Messages, SysUtils, Variants, Classes, Graphics, Controls, Forms,
    Dialogs, StdCtrls, EmptyTemplateIMPL;

type
    TSetupForm = class(TForm)
        Label1: TLabel;
    private
```

```
FPlugin: TPlugin;
FParentWindow: THandle;
protected
  procedure CreateParams(var Params: TCreateParams); override;
  procedure CreateWnd; override;
public
  property Plugin: TPlugin read FPlugin write FPlugin;
  constructor Create(AOwner: TComponent; ParentWin: THandle);
end;

implementation

{$R *.dfm}
procedure TSetupForm.CreateParams(var Params: TCreateParams);
begin
  inherited;
  if (Parent = nil) and IsLibrary and
    not (csDestroying in ComponentState) then
    Params.WndParent := FParentWindow;
end;

constructor TSetupForm.Create(AOwner: TComponent; ParentWin: THandle);
begin
  FParentWindow := ParentWin;
  inherited Create(AOwner);
end;

procedure TSetupForm.CreateWnd;
begin
  inherited;
end;

end.
```

5.3 Registering a Delphi Plug-in

Plug-ins have to be registered to the Windows-Registry in order to be recognized by DEWESoft on startup. Therefore the parameters specified in the procedure "TPluginObjectFactory.UpdateRegistry" of "EmptyTemplateIMPL.pas" are necessary.

Note: Registering plug-ins designed in Delphi having the registration-information properly included in the code will be registered automatically by DEWESoft version 6.3x and newer on start-up and it is necessary that plug-in reside in the subdirectory "Addons" within the DEWESoft installation folder.

In conjunction with DEWESoft version 6.2x, the registration has to be done manually as follows. It can be done within Delphi by clicking "Run >> Register ActiveX Server". Another way to register the Plug-in would be by using regsvr32 from the command line window. To do so, regsvr32 EmptyPlugin.dll has to be called at the path where the plug-in resides. In order to remove the plug-in parameters from the registry, the following line can be used: regsvr32 /u EmptyPlugin.dll. Another way to un-register the plug-in is to click "Run >> Unregister ActiveX Server" within Delphi.

6 CustomExport

6.1 General Information on CustomExport

CustomExport offers the ability to create user-defined file exports for DEWESoft. Such a CustomExport will be added to the list of exports within DEWESoft.




Figure 30 File Export – Export file types

A CustomExport is an ActiveX library having the extension “.exp”. If a CustomExport library resides in the subdirectory “Addons” of the DEWESoft installation folder, it will be recognized on start-up.

6.2 Creating a CustomExport in Delphi 7

For creating a new CustomExport in Delphi 7 the following steps have to be done: First, create a new ActiveX Library Project by clicking “File >> New >> Other...” (See Figure 31)




Figure 31 File >> New >> Other...

...and select ActiveX Library as shown in Figure 32.




Figure 32 New ActiveX Library

Now save the ActiveX Library Project as e.g. MyExport.dpr (Figure 33)




Figure 33 Save Project As...

Add a new Unit to the project by clicking “File >> New >> Unit” (Figure 34)




Figure 34 File >> New >> Unit

And save the unit as e.g. MyExportIMPL (Figure 35).




Figure 35 Save Unit As...

The file extension of the ActiveX Library has to be “.exp”. This has to be set in the “Project Options” dialog (Figure 36) which is opened by clicking “Project >> Options...” or by pressing the keys <Shift> + <Ctrl> + <F 11>.




Figure 36 Target File Extension

Finally the DEWESoft Library has to be imported by clicking “Project >> Import Type Library...” (Figure 37).




Figure 37 Import Type Library

From the list in the “Import Type Library” dialog choose DEWESoft Library. Change the “Unit dir name” to the path where your project resides and click “Create Unit”. Be careful to choose the write version of the DEWESoft Library. The version 6.2 will work DEWESoft Version 6.2b43 or newer. The older version of the library (1.0) will only work with older

versions of DEWESoft. If DEWESoft 6.3 is installed on the computer, the version number will be something like “276.6”. The part left to the dot is the “DEWESoftMajorVersion” in Hex notation. So, this example would be of DEWESoft version 630 in decimal notation. The part right to the dot is the “DEWESoftMinorVersion” which is the version of DEWESoft’s type library. This version number is shown in the “Plugin” section of the DEWESoft’s hardware setup at the right bottom.




Figure 38 Import Type Library – Create Unit

Since version 6.4 of DEWESoft, an additional interface for embedding a configuration frame to DEWESoft is available. If this functionality is used, a Frame or Form has to be added to the project.

6.3 ICustomExport, ICustomExport2, IExportFrame




Figure 39 CustomExport Flowchart (1)




Figure 40 CustomExport Flowchart (2)

6.4 ICustomExport

6.4.1 Methods of ICustomExport

function EndChannel: HRESULT;

EndChannel is called at the end of the export of each channel when the ExportType is set to etChannelBased.

function EndDataFolder: HRESULT;

EndDataFolder is called at the end of each data folder. A data folder is a section of time where data is stored; in other words the time between a start and a stop trigger.

function EndExport: HRESULT;

EndExport is called at the very end of the export. E.g. DLLs used during export can be released here.

function EndHeader: HRESULT;

EndHeader is called at the end of writing the header information of an export and before the export of the measurement data is started.

function EndInfo: HRESULT;

EndInfo is called after writing the general information to the export file (functions WriteInfoDate, WriteInfoInteger, WriteInfoSingle, and WriteInfoString). In most cases EndInfo will remain empty.

function EndValue: HRESULT;

EndValue is called, when the ExportType is etValueBased, after one value of each channel is exported.

function StartAbsValue(DateTime: TDateTime): HRESULT;

StartAbsValue is called when the ExportType is set to etValueBased and the “Time axis” is set to “Absolute” before one value of each channel is exported.

Parameters:

DateTime is the time stamp in absolute time for one set values.

function StartChannel(const FieldName: WideString; const FieldUnit: WideString; Async: WordBool): HRESULT;

StartChannel is called when ExportType is set to channel-based every time the export of a new channel is started.

Parameters:

FieldName is the name and the comment of the channel. E.g. this could be “AI 0 - MyComment” for an analog channel.

FieldUnit is the Unit of the channel. E.g. this could be “m/s²” or just “-“, if no unit was specified for the channel.

Async specifies whether the channel contains asynchronous data or not.

function StartDataField(const FieldName: WideString; const FieldUnit: WideString; ExportRate: Integer): HRESULT;

StartDataField is called for each channel for exporting the name, the unit and the rate for each channel.

Parameters:

FieldName is the name and the comment of the channel. E.g. this could be “AI 0 - MyComment” for an analog channel.

FieldUnit is the unit of a channel. E.g. this could be “m/s²” or just “-“, if no unit was specified for the channel.

ExportRate equals to the acquisition rate of a channel.

function StartDataFolder(const FolderName: WideString; AbsTime: TDateTime): HRESULT;

StartDataFolder is called when the export of channel-specific data starts. A data folder is a section of time where data is stored; in other words the time between a start and a stop trigger.

Parameters:

FolderName is the name of the DataFolder. E.g. this can be “Data1”.

AbsTime is the absolute start time of the folder.

function StartExport(const App: IApp): HRESULT;

At StartExport DLLs for exporting should be initialized if necessary (depending on the type of export) and the file to which data will be exported should be opened here.

Parameters:

App is a reference to DEWESoft for accessing its functions and properties.

function StartInfo(const Info: WideString): HRESULT;

At StartInfo the writing of general information of the exported data begins. The functions WriteInfoDate, WriteInfoInteger, WriteInfoSingle, and WriteInfoString will follow.

Parameters:

Info can contain any general header information.

function StartTimeField(const FieldName: WideString; const FieldUnit: WideString): HRESULT;

StartTimeField is called for exporting the name of the time channel and its unit.

Parameters:

FieldName is the name of the time channel. In most cases this will be just “Time”.

FieldUnit is the time unit. E.g. this could be “s” for seconds.

function StartValue(TimeValue: Double): HRESULT;

StartValue is called when the ExportType is set to etValueBased and the “Time axis” is set to “Relative” before one value of each channel is exported.

Parameters:

TimeValue is the time value for the following set of values to export.

function WriteAsyncValue(TimeStamp: Double; Value: Single): HRESULT;

WriteAsyncValues is called for each asynchronous value when the ExportType is channel-based.

TimeStamp is the asynchronous time value corresponding to the value to export.

Value is data value to export.

function WriteInfoDate(const Description: WideString; Value: TDateTime): HRESULT;

WriteInfoDate writes date information to the header of the export file.

Parameters:

Description is a string describing the value. E.g. this string could be something like “Start time”.

Value is the appropriate time and date.

function WriteInfoInteger(const Description: WideString; Param: Integer): HRESULT;

WriteInfoInteger writes information of the type Integer to the header of the export file.

Parameters:

Description is a string describing the value. E.g. this string could be “Sample rate”.

Param is the appropriate Integer value.

function WriteInfoSingle(const Description: WideString; Value: Single): HRESULT;

WriteInfoSingle writes information of the type Single to the header of the export file.

Parameters:

Description is a string describing the value.

Value is the appropriate Single value.

function WriteInfoString(const Description: WideString; const Value: WideString): HRESULT;

WriteInfoString writes information of the type string to the header of the export file.

Parameters:

Description is a string describing the value.

Value is the appropriate string.

function WriteValue(Value: Single): HRESULT;

WriteValue is called for each value to export, when the ExportType is value-based or when synchronous values are exported in channel-based mode. (For asynchronous values in channel-based mode, WriteAsyncValue is called.)

Parameters:

Value is the data value to export.

6.4.2 Properties of ICustomExport

property AbsoluteTime: WordBool;

AbsoluteTime specifies whether the export is done in absolute time or not. Cf. Figure 41. This property is set by DEWESoft.




Figure 41 Time Axis for Export

property DataCount: Largeuint;

DataCount specifies the number of samples. This property is set by DEWESoft. For channel-based export the DataCount differs for each channel. For value-based export the DataCount is equal for each channel. This property can be necessary for some exports needing to know that count at the beginning.

property ExportType: ExportTypes; (read-only)

ExportType specifies whether the export is value-based or channel-based. These two types correspond to the constants etValueBased (=0) or etChannelBased (=1). Value-based means, that the first value of each channel is exported before the second value of each channel and so on. Channel-based means that each values of the first channel are exported before each values of the second channel and so on.

property Extension: WideString; (read-only)

Extension specifies the file extension denoting the file type, e.g. “.txt” for a text file.

property FileName: WideString;

FileName is the name of the export file entered by the user before performing the export. This property is set by DEWESoft.

property SupportsAsync: WordBool; (read-only)

SupportsAsync specifies whether the custom export supports asynchronous data or not. This property is relevant only for channel-based export. If SupportsAsync is true, asynchronous channels will be exported as such. If SupportsAsync is false, asynchronous channels will be exported as synchronous channels and gaps between values will be interpolated.

property SupportsSRDiv: WordBool; (read-only)

SupportsSRDiv defines whether the export supports a sample rate divider or not. This property is relevant only for channel-based export. If SupportsSRDiv is false, additional samples will be inserted.

property TimeIncrease: Double;

TimeIncrease defines the interval between two subsequent values of synchronous data.

6.5 ICustomExport2

6.5.1 Methods of ICustomExport2

function GetDWTypeLibVersion(out Value: Integer): HRESULT;

At GetDWTypeLibVersion the DEWESoft type library version should be returned.

Parameters:

Value is the DEWESoft type library version number. It is defined as DEWESoftMinorVersion in DEWESoft's type library.

function Get_SupportsDouble(out Value: WordBool): HRESULT;

At Get_SupportsDouble it should be returned whether the custom export supports the export of measurement values of the type Double.

Parameters:

Value defines whether Double values are supported or not.

function SetAbsMax(AbsMax: Single): HRESULT;

At SetAbsMax the absolute maximum of the measurement is made available to the export. E.g. this can be used for scaling purpose.

Parameters:

AbsMax is the absolute maximum measured value.

function SetAbsMin(AbsMin: Single): HRESULT;

At SetAbsMin the absolute minimum of the measurement is made available to the export. E.g. this can be used for scaling purpose.

Parameters:

AbsMin is the minimal measured value.

function SetApp(const App: IApp): HRESULT;

At SetApp a reference to the IApp is provided.

function SetChannel(const Ch: IChannel): HRESULT;

At SetChannel a reference to current channel is provided.

function SetChannelColor(Color: Integer): HRESULT;

SetChannelColor gives the color of the channel to the export.

Parameters:

Color is the integer value of the color of a channel.

function SetDoubleFloat(DoubleFloat: WordBool): HRESULT;

SetDoubleFloat give back to the export whether the values which will be exported are of the type Double or not. If not, its type is Single.

Parameters:

DoubleFloat is True if the values to export are of the type Double.

function SetRangeMax(Value: Single): HRESULT;

SetRangeMax makes the maximum range setting available to the export.

Parameters:

Value is the maximum limit of the measurement range.

function SetRangeMin(Value: Single): HRESULT;

SetRangeMin makes the minimum range setting available to the export.

Parameters:

Value is the minimum limit of the measurement range.

function SetTrigOffset(TrigTime: Double): HRESULT;

SetTrigOffset gives back the pre-time of a trigger event. The time given back is not overlapping with previous trigger events.

Parameters:

TrigTime is the pre-time of the trigger event.

function StartEvents: HRESULT;

StartEvents is called before the events are exported.

function StopEvents: HRESULT;

StopEvents is called after the events are exported.

function Get_SupportsDouble(out Value: WordBool): HRESULT;

Get_SupportsDouble defines whether the custom export supports the export of values of the type Double.

Parameters:

Value has to be set to True if the export supports Double values.

function WriteAsyncDoubleValue(TimeStamp: Double; Value: Double): HRESULT;

WriteAsyncDoubleValue is similar to WriteAsyncValue of ICustomExport.

WriteAsyncDoubleValues is called for each asynchronous value when the ExportType is channel-based.

TimeStamp is the asynchronous time value corresponding to the value to export.

Value is data value to export.

function WriteDoubleValue(Value: Double): HRESULT;

WriteDoubleValue is similar to WriteValue of ICustomExport. WriteValue is called for each value to export, when the ExportType is value-based or when synchronous values are exported in channel-based mode. (For asynchronous values in channel-based mode, WriteAsyncDoubleValue is called.)

Parameters:

Value is the data value to export.

function WriteEvent(EventType: Integer; const EventTypeString: WideString; Time: Double; const Comment: WideString): HRESULT;

WriteEvent is called for each event of the exported data.

Parameters:

EventType defines the type of event. This can be etText (=\$00000015), etKeyboard (=\$00000014);

EventTypeString is a string defining the event type.

Time is the time when the event occurred.

Comment is a possible remark associated with the event.

6.6 IExportFrame

DEWESoft 6.4 and newer offers the possibility of embedding an ExportFrame into its export screen. This frame will appear next to the list of available file exports, cf. Figure 42.




Figure 42 Export Frame in DEWESoft's Export Screen

6.6.1 Methods of IExportFrame

procedure ShowFrame(Handle: Integer; out FrameHeight: Integer); safecall;

ShowFrame is called by DEWESoft when the setup frame of the custom export is shown.

Parameters:

Handle is the handle which should be assigned to the ParentWindow property of the frame.

FrameHeight returns the height of the configuration frame to DEWESoft.

procedure HideFrame; safecall;

HideFrame is called when the custom export is left and its onfiguration frame should be hidden.

procedure Apply; safecall;

Apply is called by DEWESoft when the “Export data” button is clicked. At this moment changes of the exports configuration within the configuration frame can be applied.

6.7 Source Code of the CustomExport

Now, the code of the CustomExport project should look like the following:

```
library MyExport;

uses
  ComServ,
  MyExportFormUnit in 'MyExportFormUnit.pas' {MyExportForm},
  MyExportIMPL in 'MyExportIMPL.pas';

{$E .exp}

exports
```

```
DllGetClassObject,  
DllCanUnloadNow,  
DllRegisterServer,  
DllUnregisterServer;  
  
{ $R *.RES }  
  
begin  
end.
```

6.7.1 Source Code of a CustomExport Unit

The following source code should be added to the unit MyExportIMPL.pas. Specific code depending on the export has to be added to the functions.

```
unit MyExportIMPL;  
  
{ $WARN SYMBOL_PLATFORM OFF }  
interface  
uses  
  Windows, ActiveX, Classes, ComObj, Dewesoft_TLB, IniFiles, Dialogs,  
  StrUtils, Math, SysUtils, Controls, Forms, ClipBrd, Variants;  
  
const  
  Version = '1.00 b1';  
  
type  
  
TExport = class(TComObject, ICustomExport, ICustomExport2, IExportFrame)  
private  
  FForm: TForm;  
  FApp: IApp;  
  
  FFileName: TFileName;  
  TimeIncrease: Double;  
  AbsoluteTime: WordBool;  
  DataCount: Largeint;  
protected  
  //-->ICustomExport  
  function Get_FileName(out Value: WideString): HRESULT; stdcall;  
  function Set_FileName(const Value: WideString): HRESULT; stdcall;  
  function StartExport(const App: IApp): HRESULT; stdcall;  
  function EndExport: HRESULT; stdcall;  
  function Get_ExportType(out Value: ExportTypes): HRESULT; stdcall;  
  function Get_AbsoluteTime(out Value: WordBool): HRESULT; stdcall;  
  function Set_AbsoluteTime(Value: WordBool): HRESULT; stdcall;  
  function StartDataFolder(const FolderName: WideString; AbsTime: TDateTime):  
  HRESULT; stdcall;  
  function EndDataFolder: HRESULT; stdcall;  
  function StartInfo(const Info: WideString): HRESULT; stdcall;  
  function WriteInfoString(const Description: WideString; const Value:  
WideString): HRESULT; stdcall;  
  function WriteInfoInteger(const Description: WideString; Param: Integer):  
  HRESULT; stdcall;  
  function WriteInfoSingle(const Description: WideString; Value: Single):  
  HRESULT; stdcall;  
  function WriteInfoDate(const Description: WideString; DateTime: TDateTime):  
  HRESULT; stdcall;  
  function EndInfo: HRESULT; stdcall;  
  function StartTimeField(const FieldName: WideString; const FieldUnit:  
WideString): HRESULT; stdcall;  
  function StartDataField(const FieldName: WideString; const FieldUnit:  
WideString; ExportRate: Integer): HRESULT; stdcall;  
  function EndHeader: HRESULT; stdcall;  
  function StartValue(TimeValue: Double): HRESULT; stdcall;  
  function StartAbsValue(DateTime: TDateTime): HRESULT; stdcall;  
  function WriteValue(Value: Single): HRESULT; stdcall;  
  function WriteAsyncValue(TimeStamp: Double; Value: Single): HRESULT; stdcall;
```

```
function StartChannel(const FieldN: WideString; const FieldUnit: WideString;
Async: WordBool): HRESULT; stdcall;
function Get_Extension(out Value: WideString): HRESULT; stdcall;
function Get_TimeIncrease(out Value: Double): HRESULT; stdcall;
function Set_TimeIncrease(Value: Double): HRESULT; stdcall;
function EndChannel: HRESULT; stdcall;
function EndValue: HRESULT; stdcall;
function Get_SupportsAsync(out Value: WordBool): HRESULT; stdcall;
function Get_SupportsSRDiv(out Value: WordBool): HRESULT; stdcall;
function Get_DataCount(out Value: Largeuint): HRESULT; stdcall;
function Set_DataCount(Value: Largeuint): HRESULT; stdcall;
//<--

//-->ICustomExport2
function SetAbsMin(AbsMin: Single): HRESULT; stdcall;
function SetAbsMax(AbsMax: Single): HRESULT; stdcall;
function SetTrigOffset(TrigTime: Double): HRESULT; stdcall;
function SetChannelColor(Color: Integer): HRESULT; stdcall;
function SetRangeMax(Value: Single): HRESULT; stdcall;
function SetRangeMin(Value: Single): HRESULT; stdcall;
function WriteDoubleValue(Value: Double): HRESULT; stdcall;
function WriteAsyncDoubleValue(TimeStamp: Double; Value: Double): HRESULT;
stdcall;
function GetDWTypeLibVersion(out Value: Integer): HRESULT; stdcall;
function Get_SupportsDouble(out Value: WordBool): HRESULT; stdcall;
function SetDoubleFloat(DoubleFloat: WordBool): HRESULT; stdcall;
function StartEvents: HRESULT; stdcall;
function StopEvents: HRESULT; stdcall;
function WriteEvent(EventType: Integer; const EventTypeString: WideString;
Time: Double; const Comment: WideString): HRESULT; stdcall;
function SetChannel(const Channel: IChannel): HRESULT; stdcall;
function SetApp(const Channel: IApp): HRESULT; stdcall;
//<--

//-->IExportFrame
procedure ShowFrame(Handle: Integer; out FrameHeight: Integer); safecall;
procedure HideFrame; safecall;
procedure Apply; safecall;
//<--

public
  procedure Initialize; override;
  destructor Destroy; override;
end;

TExportObjectFactory = class(TComObjectFactory)
public
  procedure UpdateRegistry(Register: Boolean); override;
end;

const
  Class_Export: TGUID = '{8BA63341-3DEE-4BFB-90AA-DAA66DC874E2}';
  //New GUID can be generated by <Ctrl> + <Shift> + <G>
implementation
  uses ComServ, Registry, MyExportFormUnit;

procedure TExportObjectFactory.UpdateRegistry(Register: Boolean);
var
  Reg: TRegistry;
begin
  inherited UpdateRegistry(Register);
  if Register then
  begin
    Reg := TRegistry.Create(KEY_ALL_ACCESS);
    Reg.RootKey := HKEY_LOCAL_MACHINE;
    Reg.OpenKey('Software\Dewesoft\Exports\ExportTemplate', True);
    Reg.WriteString('GUID', GUIDToString(Class_Export));
    Reg.WriteString('Name', 'My Export (*.any)');
    Reg.WriteString('Extension', 'any');
    Reg.WriteString('Version', Version);
```

```
    Reg.WriteInteger('TLB', DEWESoftMinorVersion);
    Reg.WriteString('Vendor', 'Dewesoft');
    Reg.Free;
end else
begin
    Reg := TRegistry.Create(KEY_ALL_ACCESS);
    Reg.RootKey := HKEY_LOCAL_MACHINE;
    Reg.DeleteKey('Software\Dewesoft\Exports\ExportTemplate');
    Reg.Free;
end;
end;

{ TExport }
function TExport.EndChannel: HRESULT;
begin
    Result := S_OK;
end;

function TExport.EndDataFolder: HRESULT;
begin
    Result := S_OK;
end;

function TExport.EndExport: HRESULT;
begin
    FApp := nil;
    Result := S_OK;
end;

function TExport.EndHeader: HRESULT;
begin
    Result := S_OK;
end;

function TExport.EndInfo: HRESULT;
begin
    Result := S_OK;
end;

function TExport.EndValue: HRESULT;
begin
    Result := S_OK;
end;

function TExport.Get_AbsoluteTime(out Value: WordBool): HRESULT;
begin
    Value:= AbsoluteTime;
    Result := S_OK;
end;

function TExport.Get_DataCount(out Value: Largeint): HRESULT;
begin
    Value:= DataCount;
    Result := S_OK;
end;

function TExport.Get_ExportType(out Value: ExportTypes): HRESULT;
begin
    Value := etChannelBased; //or: Value:= etValueBased;
    Result := S_OK;
end;

function TExport.Get_Extension(out Value: WideString): HRESULT;
begin
    Value := '.any';
    Result := S_OK;
end;
```

6.7.2 Source Code of a CustomExport Frame/Form

```
unit MyExportFormUnit;

interface

uses
  Windows, Messages, SysUtils, Variants, Classes, Graphics, Controls, Forms,
  Dialogs, StdCtrls;

type
  TMyExportForm = class(TForm)
    lblTitle: TLabel;
    lblVersion: TLabel;
  private
    { Private declarations }
  public
    procedure ShowFrame(Handle: Integer; out FrameHeight: Integer);
    procedure HideFrame;
    procedure Apply;
  end;

var
  MyExportForm: TMyExportForm;

implementation

{$R *.dfm}

{ TMyExportForm }

procedure TMyExportForm.Apply;
begin

end;

procedure TMyExportForm.HideFrame;
begin
  Visible := False;
  ParentWindow := 0;
end;

procedure TMyExportForm.ShowFrame(Handle: Integer;
  out FrameHeight: Integer);
begin
  ParentWindow := Handle;
  Visible := True;
  Left := 0;
  Top := 0;
  FrameHeight := Height;
end;

end.
```

7 Description of Methods and Properties

7.1 IAISetupScreen

7.1.1 Methods of IAISetupScreen

procedure ShowChannelSetup(ChNo: Integer);

ShowChannelSetup opens a channel setup dialog window similar to pressing the Setup-button of a channel.

Parameters:

ChNo defines the number of the channel of which the setup dialog should be shown.

SLOT	ON/OFF 	NAME	PHYSICAL VALUES	ZERO 	SETUP
0	Used 	AI 0	- [-] 5	Zero 	Set ch. 0
1	Unused 	AI 1	- [-] 5	Zero 	Set ch. 1
2	Unused 	AI 2	- [-] 5	Zero 	Set ch. 2

Figure 43 ShowChannelSetup

procedure SetColumnVisible(ColNo: Integer; Visible: WordBool);

SetColumnVisible allows showing or hiding the different columns of the channel setup. (This procedure works for analog channels only.)

Parameters:

ColNo is the number of the column.

Visible defines whether to show or to hide the column specified by ColNo.

7.2 IAlarms

7.2.1 Properties of IAlarms

property ActiveCount: Integer; (read-only)

ActiveCount is the number of alarm conditions which are currently active.

property ActiveItem[I: Integer]: IAlarmCond; (read-only)

ActiveItem[I] is the active alarm condition at the index I. I is in the range of 0...ActiveCount-1. ActiveItem list is consistent only during measurement.

property Count: Integer; (read-only)

Count is the number of alarm conditions which are set.

property Item[I: Integer]: IAlarmCond; (read-only)

Item[I] is the alarm condition at index I. I is in the range of 0...Count-1.

7.3 IAlarmCond

7.3.1 Properties of IAlarmCond

property Index: Integer; (read-only)

Returns the Index of the alarm condition.

property Name: WideString; (read-only)

Name is the name which is assigned to an alarm condition.

property Status: WordBool; (read-only)

Status is true if an alarm condition is met and the alarm is currently still active.

property StopOption: Integer;

StopOption defines how and whether an alarm condition is stopped. This can be one of the following:

- 0...never
- 1...manual
- 2...on stop condition
- 3...on time

property StopTime: Single;

StopTime is the time after which an alarm is stopped if the StopOption is set to 3 (on time). The unit of StopTime is seconds.

property StopTrigger: ITrig; (read-only)

StopTrigger is the combination of trigger conditions deactivating an alarm if StopOption is set to 2.

property Trigger: ITrig; (read-only)

Trigger is the combination of trigger conditions activating an alarm. (cf. 7.36 ITrig)

7.3.2 Methods of IAlarmCond

procedure EndAlarm;

EndAlarm can be called in order to stop an alarm having StopOption set to 1 (manual).

7.4 IAChannel

7.4.1 Properties of IAChannel

The properties of AOChannel refer to the setup of an AO channel. Cf. right side of Figure 44.




Figure 44 Analog Output Channel Setup

property Ampl: Single;

Ampl specifies the amplitude value of the output signal.




Figure 45 Analog Output Amplitude

property FilterFreq1: Single;

FilterFreq1 is the first frequency value of a low pass or band pass filter (only applicable to noise output signals), cf. Figure 46 and Figure 47.



Figure 46 AOChannel FilterFreq1 (for low pass filter)




Figure 47 AOChannel FilterFreq1 (for band pass filter)

property FilterFreq2: Single;

FilterFreq2 is the second frequency of a filter (band pass) (only applicable to noise output signals), cf. Figure 48.




Figure 48 AOChannel FilterFreq2 (for band pass filter)

property FilterType: Integer;

FilterType is the type of a filter which can be e.g. one of the following: None, Pink, Low Pass, Band pass. Cf. Figure 49.



Figure 49 AOChannel FilterType

property FilterOrder: Integer;

FilterOrder denotes the order of a low pass or band pass filter (only applicable to noise output signals), cf. Figure 50.




Figure 50 AOChannel FilterOrder

property FilterProtoType: Integer;

FilterProtoType refers to the filter's prototype which can be e.g. Butterworth, Chebyshev or Bessel, cf. Figure 51. This setting is applicable to low pass and band pass filters of noise output signals.



Figure 51 AOChannel FilterProtoType

property Offset: Single;

Offset specifies the offset value of the output signal.




Figure 52 Analog Output Offset

property Phase: Single;

Phase specifies the phase angle of the output signal.




Figure 53 Analog Output Phase

property Range: Integer;

Range defines the voltage range of the output channel.

0...+/- 10V

1...+/- 1V

property WaveForm: AOWaveForm;

WaveForm denotes the type of waveform, which can be one of the following:

0...Sine

1...Triangular

2...Rectangular

3...Saw

4...Noise

5...Arbitrary




Figure 54 Analog Output Waveform

7.5 IAOGGroup

7.5.1 Properties of IAOGGroup

property AmplChangeFactor: Single;

AmplChangeFactor is the rate at which amplitude changes are done. Its unit is [V/s].



Figure 55 AmplChangeFactor

property AOChannels: IChannelList; (read-only)

AOChannels provides a list of analog output channels. It is of the type IChannelList.

property ControlsClock: WordBool; (read-only)

ControlsClock is true, if the analog output-board is the master clock (Dependant on the hardware setup).

property DCChangeFactor: Single;

DCChangeFactor is the rate at which DC value changes are done. Its unit is [V/s].




Figure 56 DCChangeFactor

property DeltaFreq: Single;

DeltaFreq is the frequency difference between subsequent steps of “Step sweep” signal.

property Freq: Single;

Freq is the frequency of a signal.

property FreqChangeFactor: Single;

FreqChangeFactor is the rate at which frequency changes are done. Its unit is [Hz/s].




Figure 57 FreqChangeFactor

property LogSweep: WordBool;

LogSweep defines whether the frequency change of a sweep is logarithmic or not.

property OperationMode: AOperationMode;

OperationMode defines the mode of the function generator, which can be one of the following:

- 0...Fixed Frequency
- 1...Sweep
- 2...Step sweep
- 3...Burst
- 4...Chirp

property PhaseChangeFactor: Single;

PhaseChangeFactor is the rate at which phase changes are done. Its unit is [°/s].



Figure 58 PhaseChangeFactor

property SampleRate: Integer;

SampleRate is the sample rate for analog output.

property ShowInfoChannels: WordBool;

ShowInfoChannels defines whether informative channels should be available during measurement. These are “Ampl”, “Phase”, “Offset” and “Freq”, providing information about the current waveform settings.

property StartFreq: Single;

StartFreq defines the start frequency of a signal like “Sweep”, “Step sweep” or “Chirp”.

property StartTime: Single;

StartTime defines the startup time of a waveform.

property StopFreq: Single;

StopFreq is the end frequency of a signal like “Sweep”, “Step sweep” or “Chirp”.

property StopTime: Single;

StopTime defines the fall time of a waveform.

property SweepMode: AOSweepMode;

SweepMode defines the mode of a sweep waveform, which decides whether a sweep signal will be output repeatedly or only once. This can be one of the following:

- 0...Loop
- 1...Single

7.6 IApp

7.6.1 Methods of IApp

function AOGetManualAvail: WordBool;

Whether the manual start/stop feature of analog output is available in the current setup. Cf. Figure 59.



Figure 59 Analog Output Manual Start/Stop Button

procedure AOSetManual;

To manually start or stop the AO equal to clicking the “Manual” button on DEWESoft, cf. Figure 59.

procedure ChangeDaqType(DaqType: Integer);

ChangeDaqType changes the device type for analog acquisition. Cf. Figure 60.

- 0...No A/D
- 1...Dewetron DAQ
- 2...Dewetron DSA
- 3...Spectrum
- 4...National Instruments
- 5...National Instruments MX
- 6...National Instruments DSA
- 7...Data Translation
- 8...Microstar DAP




Figure 60 Changing the DAQ Type in DEWESoft's Hardware Setup

procedure ChangeComPort(ComPort: Integer);

ChangeComPort changes the com port which is used for communication to the modules. Cf. Figure 61.

Parameters:

ComPort is the number of the com port which should be selected. 0...com 1, 1... com 2, etc.




Figure 61 Com Port for the Modules

procedure ExportData(ExportType: Integer; const FileName: WideString);

ExportData corresponds to the file export feature of DEWESoft (see Figure 62). It exports the currently selected DEWESoft data file to the specified file type to the target path.

Parameters:

ExportType specifies the export file type which can be one of the following:

- 0...Flexpro (*.fpd)
- 1...Excel (.xls)
- 2...DIAdem (*.dat)
- 3...Matlab (*.mat)
- 4...Universal File Format 58 (*.unv)
- 5...FAMOS (*.dat)
- 6...NSoft time series (*.dac)
- 7...Text (*.txt)
- 8...Sony (*.log)
- 9...RPCIII (*.rsp)
- 10...Comptade (*.cfg)

FileName specifies the name of the target-file including its path.




Figure 62 File Export in DEWESoft

procedure GetInterfaceVersion(var Major: Integer; var Minor: Integer; var Revision: Integer);

GetInterfaceVersion can be used for reading the version of DEWESoft’s DCOM interface.

Parameters:

Major is the major version number.

Minor is the minor version number.

Revision is the revision number.

procedure HardwareSetup(Plugins: WordBool);

HardwareSetup starts the dialog window of the hardware setup like clicking “System >> Hardware setup”.

Parameters:

Plugins defines whether to show the Plugins tab in the hardware setup or not. If Plugins is set to True, the windows registry will be searched for installed plug-ins, the plug-ins will be re-initialized and the Plugins tab will be shown. If Plugins is set to False, the Plugins tab will not be shown.



Figure 63 Hardware Setup

procedure Init;

Init starts the initialization of DEWESoft.

procedure LoadDBC(PortNo: Integer; const FileName: WideString);

LoadDBC loads the dbc-file specified by FileName and applies it the CAN-port specified by PortNo.

Parameters:

PortNo is the port-number to which the dbc-file is applied (first port is 0).

FileName is the name of the dbc-file including its path. If the dbc-file resides in the DEWESoft's "Setup"-directory, the file-name without the whole path would be sufficient.

procedure LoadDisplaySetup(const FileName: WideString);

LoadDisplaySetup allows loading a display setup as it can be done by the menu item "File >> Load Display Setup", cf. Figure 64.

Parameters:

FileName is the file name including the path of the DEWESoft setup file which should be applied.




Figure 64 Load Display Setup Menu Item

procedure LoadFile(const FileName: WideString);

LoadFile loads a data file specified by FileName. This function corresponds to clicking "Data >> Load Data File" (see Figure 65).

Parameters:

FileName is the file name including its path.




Figure 65 Load Data File

procedure LoadModuleSetup(const FileName: WideString);

LoadModuleSetup loads the setup of modules only (no screens, no triggers, ...) from a DEWESoft setup file (.dss).

Parameters:

FileName is the file name of the setup file including its path.

procedure LoadSetup(const FileName: WideString);

LoadSetup loads a setup file specified by FileName. This function corresponds to clicking "File >> Load Setup" (see Figure 66)

Parameters:

FileName is the file name of the setup file including its path.



Figure 66 Load Setup

procedure MainWndMessage(Msg: Integer; WParam: Integer; Wait: WordBool);
 MainWndMessage can be used in conjunction with plug-ins. MainWndMessage is the only allowed message to be called from any thread within a plug-in. If it is necessary to send a message to DEWESoft from an additional thread of a plug-in, MainWndMessage has to be used. “Msg” and “Param” will be available at “IPlugin2.OnOleMsg” which will follow. On this, the message has to be sent to DEWESoft from the main thread of the plug-in.

Parameters:

Msg and WParam are Integer values specifying the message in order to be able to send the appropriate message when OnOleMsg is called within the plug-in.

Wait specifies whether the thread from which MainWndMessage was called will wait or continue execution.

procedure ManualStart;

ManualStart causes a manual start trigger, when DEWESoft is in measure mode and a trigger condition is set (see Figure 67) and armed. This function corresponds to clicking the trigger button as shown in Figure 68.




Figure 67 Storing Options




Figure 68 Manual Start Trigger

procedure ManualStop;

ManualStop causes a manual stop trigger, when DEWESoft is in measure mode and a trigger condition is set and currently active. This function corresponds to clicking the trigger button when a trigger is currently active, as shown in Figure 69.




Figure 69 Manual Stop Trigger

procedure Measure;

Measure makes DEWESoft to switch to measure mode, corresponding to clicking the “Measure” button to do so (see Figure 70).




Figure 70 Measure

procedure MenuClick(Item: MenuItems);

MenuClick causes the menu item defined by “Item” to be clicked. E.g. Item would set to 2 would cause the Load setup file dialog to be opened equal to clicking the menu item from the File menu as shown in Figure 71.

Parameters:

Item can be one of the following constants defined as MenuItems:

ItemSaveSetup = 0

ItemSaveSetupAs = 1

ItemLoadSetup = 2




Figure 71 MenuItem Load Setup

procedure NewSetup;

NewSetup equals to clicking “New Setup” from the File menu (see Figure 72), causing a new setup to be created.




Figure 72 New Setup

procedure PauseStoring;

PauseStoring pauses the storing of data equal to pressing the Pause-button (cf. Figure 73) which is available when storing is in progress.



Figure 73 Pause Storing

procedure PrintScreen(ShowDialog: WordBool);

PrintScreen corresponds to the “Print” button in DEWESoft (cf. Figure 74). This procedure can only be used when the application is in Analyse mode (when the Print button would be shown). By default this procedure prints the screen on the default printer.

Parameters:

ShowDialog defines whether the printing dialog is shown or not.



Figure 74 Print Button

procedure ResumeStoring;

ResumeStoring resumes the storing of data after storing has been paused before. This function is equal to pressing the Resume-button which is available when storing is paused. (Cf. Figure 75)



Figure 75 Resume Storing

procedure SaveSetup(const FileName: WideString);

SaveSetup saves the current setup to the file specified by FileName. Compare to clicking “File >> Save Setup” (see Figure 76).

Parameters:

FileName is the file name of the setup file to store to including its path.




Figure 76 SaveSetup

function SendCommand(const Cmd: WideString; Timeout: Integer): WideString;

SendCommand sends a command string to a hardware module via the (internal) module bus and returns its answer.

Parameters:

Cmd is the command string to send to the module.

Timeout specifies how long to wait for an answer of the module. Its unit is ms.

procedure SetFullScreen(Full: WordBool);

SetFullScreen switches between full screen display mode and standard display mode, similar to pressing <CTRL> + <F> to do so.

Parameters:

Full defines the mode to switch to. If Full is True, the window switches to full screen. If Full is False, the window switches to normal display mode.

procedure SetHeaderData(const Caption: WideString; const Header: WideString);

SetHeaderData allows changing the data of the header of a measurement file.

Parameters:

Caption denotes which field of the header to change. E.g. the caption of the standard field would be “Comments” (see mouse cursor in Figure 77).

Header is the text being set to the specified field.




Figure 77 Data Header


procedure SetInstrument(Id: Integer);

SetInstrument sets DEWESoft to a certain screen.

Parameters:

Id specifies the screen to set. Id can be one of the following values corresponding to the buttons on the right:

Table 1 Screen Buttons

0...“Overview”,	
1... “Scope”,	
2... “Recorder”,	
3...“FFT”,	
4...“Video”,	
5...“GPS”,	
6...“Vert. rec.”,	
7...“Power”.	

procedure SetMainDataDir(const DataDir: WideString);

SetMainDataDir allows setting the main data directory used by DEWESoft similar to setting it via the “General setup” manually, cf. Figure 78.

Parameters:

DataDir is path of the directory which should be set.



Figure 78 Setting the Main Data Directory

function SetScopeParams(PreTime: TDateTime; PostTime: TDateTime; const Channel: IChannel; Level: Single): Integer;

SetScopeParams sets the trigger properties of the scope.

Parameters:

PreTime is the pre-trigger time,

PostTime is the post-trigger time,

Channel specifies the channel used for triggering,

Level specifies the trigger level.

The data type TDateTime is a Double value which is interpreted as follows:

The integral part of a Delphi TDateTime value is the number of days that have passed since 12/30/1899. The fractional part of the TDateTime value is fraction of a 24 hour day that has elapsed.

Following are some examples of TDateTime values and their corresponding dates and times:

```
0      12/30/1899 12:00 am
2.75   1/1/1900 6:00 pm
-1.25  12/29/1899 6:00 am
35065  1/1/1996 12:00 am
```

procedure SetScopeUsed(Value: WordBool);

SetScopeUsed activates or deactivates the scope trigger.

Parameters:

Value denotes whether the scope trigger is used or not. True will activate the scope trigger and False will deactivate it.

procedure SetScreenIndex(Index: Integer);

SetScreenIndex sets the screen index of the active screen, if more than one screen of one kind exists. Additional screens can be added by clicking “Displays >> Add display” as shown in Figure 79.

Parameters:

Index is the index of the screen to show. The screens are indexed starting at 0 up to number of screens -1. Figure 80 shows 3 Overview screens to select. In this case the screen named “Overview” would corresponds to index = 0, “Overview 2” to index = 1 and “Overview 3” to index =2.




Figure 79 Add display




Figure 80 Screens of a kind

procedure SetStoreMode(Mode: Integer);

SetStoreMode allows setting DEWESoft’s storing options, cf. Figure 81. (The storing mode can be read via the property “StoreMode”).

Parameters:

Mode is the list index of the storing option, which can be one of the following:

- 0... “always fast”
- 1... “always slow”
- 2... “fast on trigger”
- 3... “fast on trigger, slow otherwise”




Figure 81 DEWESoft's Storing Options

procedure SetupScreen;

SetupScreen switches the application to the setup screen like clicking the Setup button (Figure 82)



Figure 82 Setup Button

procedure ShowSensorEditor;

ShowSensorEditor opens the sensor editor window.

procedure StartModuleScan;

StartModuleScan allows to manually start the scanning of the modules after having stoped it by StopModuleScan.

procedure StartStoring(const FileName: WideString);

StartStoring corresponds to the function of the Store button (Figure 83). It starts storing or arms the trigger if one is set.

Parameters:

FileName is the name of the file where data is stored to including its path and its extension (.dsd). If FileName is empty, the settings of DEWESoft are used.



Figure 83 Store Button

procedure Stop;

Stop stops the application and switches to the stop-screen. This function is similar to clicking the Stop button (Figure 84).



Figure 84 Stop Button

procedure StopModuleScan;

StopModuleScan allows to stop the scanning of the modules. Use StartModuleScan to restart scanning again.

procedure UpdateHardwareSetup;

UpdateHardwareSetup has to be called after making changes within the hardware setup.

procedure WriteErrorMessage(const ErrorMsg: WideString);

WriteErrorMessage writes an error message to the caption of DEWESoft. The purpose of this procedure is mainly for debugging applications. (In future the message will be written to some kind of debug-window.)

procedure ZeroAllAutoChannels(Zero: WordBool);

ZeroAllAutoChannels works for all DaqChannels having AutoZero set to True.

Parameters:

Zero: If Zero is set to True, the function sets the offset to perform zeroing. If Zero is False, it clears the offset from selected channels.

7.6.2 Properties of IApp

property ActiveScreen: Integer; (read-only)

ActiveScreen is the number of the active screen, which can be one of the following:

- 0...“Overview”,
- 1...“Scope”,
- 2...“Recorder”,
- 3...“FFT”,
- 4...“Video”,
- 5...“GPS”,

6...”Vert. rec.”,

7...”Power”.

property Acquiring: WordBool; (read-only)

Acquiring informs about whether DEWESoft is currently acquiring data. (If this property is True, DEWESoft is not necessarily storing.)

property ActualRunMode: Integer; (read-only)

ActualRunMode is the actual mode in which the application is currently running. This can be one of the following:

0...none,

1...measure,

2...analyse.

At startup ActualRunMode will be 0 in most cases (except “Automatically start acquisition” is checked in the “Starting setup” within the “General settings”). If the application is in measure mode, ActualRunMode is 1. If it is in analyze mode, ActualRunMode will be 2. The application can be set back to ActualRunMode of 0 by calling Stop.

property AISetupScreen: IAISetupScreen

See 7.1 IAISetupScreen for details.

property Alarms: IAlarms; (read-only)

Alarms provides the interface for the alarm settings. See IAlarms.

property AlwaysEnableTrigger: WordBool

AlwaysEnableTrigger allows to show the Trigger tab in setup screen anyway.

property AOGroup: IAOGroup; (read-only)

See IAOGroup for detailed information.

property AveragedCPB: IAveragedFFT (read-only)

AveragedCPB provides an interface for the calculation of octave analysis data. See IAveragedFFT.

property CAN: ICAN; (read-only)

See ICAN for detailed information.

property Data: IData; (read-only)

Data provides the measurement data and corresponding methods and properties. See IData for detailed information.

property DataLost: WordBool; (read-only)

DataLost is true when loss of data has occurred during measurement.

property DaqGroup: IDaqGroup; (read-only)

DaqGroup is the group of analog input channels. See IDaqGroup.

property DisableStoring: WordBool;

DisableStoring will hide the Store button, if it is set to True.

Property Enabled: WordBool;

Enabled allows enabling and disabling DEWESoft. If Enabled is False, it is not possible to manipulate DEWESoft’s controls by the mouse.

property EventList: IEventList; (read-only)

EventList contains a list of events occurred during measurement. See IEventList for detailed information.

property FileNameSettings: IFileNameSettings; (read-only)

FileNameSettings provides access to the settings of the naming options of the data files.

property Height: Integer;

Height is the height of the application window expressed in pixels.

property IniFileDir: WideString;

IniFileDir is the path of the directory where the ini-file of DEWESoft resides.

property IsSetupMode: WordBool; (read-only)

IsSetupMode informs about whether DEWESoft is currently in the setup mode or not.

property Left: Integer;

Left is the distance between the left border of the application window and the left border of the screen expressed in pixels.

property LoadEngine: ILoadEngine; (read-only)

LoadEngine has to be used for handling data files acquired by DEWESoft. See ILoadEngine for detailed information.

property MainDataDir: WideString; (read-only)

MainDataDir is the path of the directory where measurement data is stored (By default this path would be C:\Dewetron\Program\DEWESoft6\Data).

property MasterClock: IMasterClock; (read-only)

MasterClock provides the current time from the A/D-board before the data is transferred. The unit of this time is seconds. MasterClock can be used for times-tamping asynchronous data.

property MeasureSampleRate: Integer;

MeasureSampleRate is the sample rate for data acquisition. This property corresponds to the setting shown in Figure 85 where the mouse cursor is placed.




Figure 85 Acquisition Rate

property Modules: IModules; (read-only)

Modules provides the interface to the modules. See IModules.

property Parent: Integer;

Parent serves for referencing the windows handle of a form as the parent for DEWESoft.

property Screens: IScreens; (read-only)

Screens allows handling the different screens of DEWESoft. These screens can be e.g. an “Overview”, a “Recorder”, etc. Moreover, each of these categories can have more than one screen. See IScreens and IScreen for detailed information.

property ShowPropertyFrame: WordBool;

ShowPropertyFrame allows to show or to hide the property frame of a measurement screen. The property frame is the frame on the left side of a measurement screen. (Cf. Figure 86, where the property frame is shown on the left screen shot and not shown on the right one.)




Figure 86 Property Frame of Measurement Screen

property ShowSROptions: WordBool;

ShowSROptions allows to show or to hide the sampling rate options within the setup screen. (Cf. Figure 87, where the sampling rate options are shown on the left screen shot and not shown on the right one.)




Figure 87 Sampling Rate Options

property ShowStoreOptions: WordBool;

ShowStoreOptions allows to show or to hide the store options within the setup screen. (Cf. Figure 88, where the sampling rate options are shown on the left screen shot and not shown on the right one.)



Figure 88 Store Options

property ShowStyle: Integer;

ShowStyle is for changing the appearance of the menu bar.

0...hides the whole menu bar (hides menu and buttons, cf. Figure 89),




Figure 89 ShowStyle = 0

1...shows the menu bar but hides the drop-down menu bar (shows only buttons, cf. Figure 90),



Figure 90 ShowStyle = 1

2... shows the menu bar including the drop-down menu bar (shows menu and buttons, cf. Figure 91).



Figure 91 ShowStyle = 2

property StayOnTop: WordBool;

StayOnTop allows setting whether the application window should stay on top or not. If set to True, DEWESoft will remain in the foreground of the screen.

property StoreEngine: IStoreEngine; (read-only)

StoreEngine has to be used for handling the storing of data. See IStoreEngine for detailed information.

property TimerInterval: Integer

TimerInterval is the timer interval for DEWESoft acquisition in ms. The default value is 33.

property Top: Integer;

Top is the distance between the top border of the application window and the top border of the screen expressed in pixels.

property Trigger: ITrigger; (read-only)

See 7.36 for details.

property UsedDatafile: WideString;

UsedDatafile is the file name of the data file including its path and file extension (.dsd) where acquired data will be stored to. E.g. this could be “C:\Dewetron\Program\DEWESoft6\Data\Test.dsd”.

property UsedSetupfile: WideString; (read-only)

UsedSetupfile is the file name of the setup file currently used, including its path and file extension (.dss). E.g. this could be “C:\Dewetron\Program\DEWESoft6\Setups\MySetup.dss”.

property Version: WideString; (read-only)

Version is the number of the currently used DEWESoft version. E.g. this can be “6.2”.

property Visible: WordBool;

Visible defines whether the application window should be visible or not.

property Width: Integer;

Width is the width of the application window expressed in pixels.

7.6.3 Events ⚡ of IApp

procedure OnAlarm;

OnAlarm will be raised when an alarm occurs. Alarms can be set in the Alarms tab of the setup screen which is available when activated within the hardware setup.

procedure OnDataLost;

OnDataLost occurs when data lost is reported by the DAQ object.

procedure OnEvent(Reason: EventReason; Param: OleVariant);

OnEvent will be raised in case of several events.

Parameters:

EventReason denotes the type of event, which can be one of the following:

- 1 indicating “start”,
- 2 indicating “stop”,
- 3 indicating “trigger”,
- 11 indicating “VStart” (video start storing)
- 12 indicating “VStop” (video stop storing)
- 20 indicating “Keyboard”
- 21 indicating “Notice”
- 22 indicating “Voice”
- 24 indicating “Module” (example: Bridge shunt on/off).

Param can contain certain data of this event. E.g. in case of a “Notice”-event, this will be of the type String.

procedure OnException(const Str: WideString);

OnException will be raised when an error occurs within DEWESoft.

Parameters:

Str contains the message according to the exception that has happened.

procedure OnExit;

OnExit is raised on exiting DEWESoft.

procedure OnGetData;

OnGetData will be raised every time new data is added to a channel. This event happens about every 40ms.

procedure OnGetTime(var TimeLo: Integer; var TimeHi: Integer);

At OnGetTime a clock can be provided to DEWESoft, if no AD-hardware is used.

Parameters:

TimeLo and TimeHi are used because a 64-bit value is necessary to provide the time value.

procedure OnStartStoring;

OnStartStoring will be raised when the storing of data is started or a trigger for storing data is armed.

procedure OnStopStoring;

OnStopStoring will be raised when the storing of data is stopped or a trigger for storing data is unarmed.

procedure OnTrigger(Mid: Integer; Dir: Integer; Time: Double);

OnTrigger will be raised when a trigger event happens.

Parameters:

Mid is the number of complete data blocks currently acquired.

Dir is the position within the current data block.

Time is the current measurement time.

procedure OnTriggerStop(Mid: Integer; Dir: Integer; Time: Double);

OnTriggerStop will be raised when a stop-trigger happens.

Parameters:

Mid is the number of complete data blocks currently acquired.

Dir is the position within the current data block.

Time is the current measurement time.

7.6.4 Types / Constants of IApp

type

MenuItems = TOleEnum;

const

ItemSaveSetup = 0;

ItemSaveSetupAs = 1;

ItemLoadSetup = 2;

7.7 IAveragedFFT

7.7.1 Methods of IAveragedFFT

function CalculateFromPos(Mid: Integer; Dir: Integer): WordBool;

CalculateFromPos calculates the octave values according to the previously set properties. The function returns True if enough data was available for the calculation; False otherwise.

Parameters:

Mid: The intermediate buffer position.

Dir: The direct buffer position.

Mid and Dir define the position within the data file from where the calculation should be started.

procedure GetChannels(Channels: OleVariant);

GetChannels provides a list of all channels used in AveragedFFT.

Parameters:

Channels is an OleVariant containing an array of channels of the type IChannel.

procedure GetData(ChNo: Integer; OctaveDivider: Integer; Weighting: Integer; out BandCount: Integer; out Data: OleVariant);

GetData retrieves the calculated octave analysis data after having called CalculateFromPos.

Parameters:

ChNo is the number of the channel which data should be retrieved.

OctaveDivider is the divider for octave analysis. It is e.g. 3 in case of 1/3 octave analysis. The Divider can be 1, 3, 12 or 24.

Weighting is the weighting curve which is applied (cf. Figure 92). This can be one of the following:

0...Linear

1...A-weighting

2...B-weighting

3...C-weighting

4...D-weighting

BandCount returns the number of frequency bands.

Data returns the array of the calculated data. The length of the array depends on the BandCount.




Figure 92 AveragedCPB Weighting

7.7.2 Properties of IAveragedFFT

property AveCount: Integer;

AveCount is the number of averages which will be used for the calculation (cf. Figure 93).




Figure 93 AveragedFFT Averages Count

property AverageType: Integer;

AverageType defines the type of averaging which should be applied to the calculation (cf. Figure 94).




Figure 94 AveragedFFT Averaging Type

property Lines: Integer;

Lines defines the number of FFT lines used for the calculation (cf. Figure 95).





Figure 95 Averaged FFT Lines

property Overlap: Integer;



property Window: Integer;

Window defines the kind of window which will be applied (cf. Figure 96). The value can be one of the following:

- 0...Rectangular
- 1...Hanning
- 2...Hamming
- 3...Flat top
- 4...Triangle
- 5...Blackman
- 6...Exponent down.




Figure 96 Averaged FFT Window Type

7.8 ICAN

7.8.1 Properties of ICAN

property SupportsOutput: WordBool; (read-only)

SupportsOutput gives information about whether a CAN-port is capable to output data.

property Count: Integer; (read-only)

Count gives the number of available CAN-ports.

property Item[Index: Integer]: ICANPort; (read-only)

Item is one of the CAN-ports which is of the type ICANPort (See 7.9 for details). Index specifies the which CAN-port to use. Index ranges from 0 up to Count-1.

7.9 ICANPort

7.9.1 Methods of ICANPort

procedure EnableOutput(Enable: WordBool);

EnableOutput enables or disables a CAN-port for output.

Parameter:

Enable must be True to enable the output, False otherwise.

procedure EndRead;

EndRead should be called after reading of data from the CAN-port. (See ReadMessage.)

function GetBaudRate: Integer;

GetBaudRate returns the Baud rate currently applied to a CAN-port.

function GetBaudRateList: OleVariant;

GetBaudRateList returns an array of available Baud rates. The data type of the array elements is String.

function ReadMessage(var TimeStamp: Double; var ArbId: Integer; var DataLo: Integer; var DataHi: Integer): WordBool;

ReadMessage reads a CAN-message.

Parameters:

TimeStamp is the timestamp of the read message, which is of the type Double.

Note:

If this function is used e.g. within a plug-in, it should be used within the procedure OnGetData and in conjunction with StartRead and StopRead. It should be called as often as defined by MessageCount. So, the code could look somehow like the following:

```
procedure Plugin.OnGetData;  
var i, ArbId, DataLo, DataHi: Integer;  
    TimeStamp: Double;  
begin  
    MyCanPort.StartRead;  
    for i:= 0 to MyCanPort.MessageCount - 1 do  
        begin  
            ReadMessage(TimeStamp, ArbId, DataLo, DataHi);  
            //do something with TimeStamp, ArbId, DataLo and DataHi.  
        end;  
    MyCanPort.EndRead;  
end;
```

function SendFrame(Extended: WordBool; ArbId: Integer; Data: T_CANFrame): WordBool;

SendFrame sends a message on the CAN-port.

Parameters:

Extended specifies whether extended identifiers are used or not.

ArbId is the identifier of the CAN-message.

Data is the data of the message which is of the type T_CANFrame. T_CANFrame is a record of 8 bytes (Byte0...Byte7).

procedure SetBaudRate(BaudRate: Integer);

SetBaudRate sets the baud rate of a CAN-port.

Parameters:

BaudRate is the Baud rate to be set.

procedure StartRead;

StartRead should be called before starting the reading of data from the CAN-port. (See ReadMessage.)

7.9.2 Properties  of ICANPort

property MessageCount: Integer; (read-only)

MessageCount gives the number of messages available to read from the CANport.

7.10 IChannel

7.10.1 Methods  of IChannel

procedure AddAsyncByteSample(Value: Byte; TimeStamp: Double);

AddAsyncByteSample adds an asynchronous data sample of the type Byte and its corresponding timestamp to a channel.

Parameters:

Value is the sample value to add to the channel.

TimeStamp is the corresponding timestamp of the sample.

procedure AddAsyncDoubleSample(Value: Double; TimeStamp: Double);

AddAsyncDoubleSample adds an asynchronous data sample of the type Double and its corresponding timestamp to a channel.

Parameters:

Value is the sample value to add to the channel.

TimeStamp is the corresponding timestamp of the sample.

procedure AddAsyncSingleSample(Value: Single; TimeStamp: Double);

AddAsyncSingleSample adds an asynchronous data sample of the type Single and its corresponding timestamp to a channel.

Parameters:

Value is the sample value to add to the channel.

TimeStamp is the corresponding timestamp of the sample.

procedure AddSingleSample(Value: Single);

AddSingleSample adds a synchronous data sample of the type Single to a channel.

Parameters:

Value is the sample value to add to the channel.

procedure AddSingleSamples(Count: Integer; Data: OleVariant; Timestamps: OleVariant);

AddSingleSamples allows adding a number of samples to a channel.

Parameters:

Count is the number of samples which will be added.

Data must contain a 1D-array of values of the type Single. The length of the array must be equal to Count.

TimeStamps must contain a 1D-array of timestamps of the type Double. The length of the array must be equal to Count.

function CreateConnection: IChannelConnection;

CreateConnection creates a connection to a channel in order to access its data. See IChannelConnection for detailed information.

function GetDBAddress: Integer;

GetDBAddress returns the pointer of the next position in the direct buffer to be written to.

procedure GetIBValues(Pos: Integer; out Min: Single; out Max: Single; out Ave: Single; out Rms: Single);

GetIBValues reads the intermediate buffer values Min, Max, Ave and RMS at the position specified by Pos. The property IChannel.IBPos can be read to determine the current position of the intermediate buffer. This procedure is implemented for automation applications developed in LabVIEW because, due to its data type, the property IChannel.IBValues is not accessible by LabVIEW. In programming environments other than LabVIEW the property IBValues can be used instead of GetIBValues.

Parameters:

Pos specified the position within the intermediate buffer to read from.

Min is the minimum value.

Max is the maximum value.

Ave is the average value.

Rms is the RMS value.

procedure GetIndex1(out IndexLevel: Integer; out I1: Integer; out I2: Integer; out I3: Integer; out I4: Integer; out I5: Integer);

GetIndex1 reads the indexes specifying a channel. This procedure is implemented for automation applications developed in LabVIEW because, due to its data type, the property IChannel.Index cannot be read by LabVIEW. In programming environments other than LabVIEW the property IChannel.Index can be used instead of GetIndex1.

Parameters:

IndexLevel defines the number of used indexes specifying a channel. This number depends on the kind of a channel.

Index1 defines the group a channel belongs to.

Index2...Index5 are group dependant indexes.

See Table 2 for detailed information on those indexes.

procedure GetRBValues(Pos: Integer; out Min: Single; out Max: Single; out Ave: Single; out Rms: Single); safecall;

GetRBValues reads the reduced buffer values Min, Max, Ave and RMS at the position specified by Pos. The property IChannel.RBPos can be read to determine the current position of the reduced buffer. This procedure is implemented for automation applications developed in LabVIEW because, due to its data type, the property IChannel.RBValues is not accessible by LabVIEW. In programming environments other than LabVIEW the property RBValues can be used instead of GetRBValues.

Parameters:

Pos specified the position within the reduced buffer to read from.

Min is the minimum value.

Max is the maximum value.

Ave is the average value.

Rms is the RMS value.

function GetScaledData: OleVariant;

GetScaledData returns scaled data from the direct buffer. The data type of scaled data is always "Single". The return value is an OleVariant containing an array of data points.

If GetScaledData is used during measurement, the size of the array returned will increase with the measurement time because all the acquired data of the channel within the buffer is returned.

If `GetScaledData` is used for reloading acquired data from a `dsd` file in conjunction with `ILoadEngine` and `ReloadBlock`, `GetScaledData` returns an array which size is equal to `IData.Samples`. See `ILoadEngine` and `IData` for detailed information.

function `GetScaledDataEx(Start: Integer; Count: Integer): OleVariant;`

`GetScaledDataEx` is an extended version of `GetScaledData`. `GetScaledDataEx` returns scaled data from the direct buffer which is already linearized and allows specifying the start position from where to start retrieving data and the desired amount of data. The data type of scaled data is always “Single”.

Parameters:

`Start` defines the position within the direct buffer from where to start retrieving data.

`Count` is the amount of data being retrieved.

procedure `GetScaledDataEx1(Start: Integer; Count: Integer; out Data: OleVariant);`

`GetScaledDataEx1` offers functionality equal to `GetScaledDataEx` but is implemented as a procedure and not as a function.

`Start` defines the position within the direct buffer from where to start retrieving data.

`Count` is the amount of data being retrieved.

`Data` contains the data retrieved from the direct buffer.

function `GetTSDData: OleVariant;`

`GetTSDData` retrieves the timestamp data of asynchronous channels. This function should be used in conjunction with `GetScaledData` for asynchronous channels. The returned `OleVariant` contains an array of timestamp values of the data type “Double”. The size of the array will be equal to the size of the array returned by `GetScaledData`.

function `GetTSDDataEx (Start: Integer; Count: Integer): OleVariant;`

`GetTSDDataEx` retrieves the timestamp data of asynchronous channels. This function should be used in conjunction with `GetScaledDataEx` or `GetUnscaledDataEx` for asynchronous channels. Similar to `GetScaledDataEx`, the function allows to specifying the start position from where to start retrieving timestamp data and the desired amount of timestamp data. The data type of timestamp data is “Double”.

Parameters:

`Start` defines the position within the direct buffer from where to start retrieving timestamp data.

`Count` is the amount of timestamp data being retrieved.

procedure `GetTSDDataEx1(Start: Integer; Count: Integer; out Data: OleVariant);`

`GetTSDDataEx1` is similar to `GetTSDDataEx`, but is implemented as a procedure and not as a function.

Parameters:

`Start` defines the position within the direct buffer from where to start retrieving timestamp data.

`Count` is the amount of timestamp data being retrieved.

`Data` contains the timestamp data retrieved from the direct buffer.

function `GetUnscaledData: OleVariant;`

`GetUnscaledData` returns unscaled data from the direct buffer. The return value is an `OleVariant` containing an array of data points.

If `GetScaledData` is used during measurement, the size of the array returned will increase with the measurement time because all the acquired data of the channel within the buffer is returned.

If `GetUnscaledData` is used for reloading acquired data from a `dsd` file in conjunction with `ILoadEngine` and `ReloadBlock`, `GetUnscaledData` returns an array which size is equal to `IData.Samples`. See `ILoadEngine` and `IData` for detailed information.

function `GetUnscaledDataEx(Start: Integer; Count: Integer): OleVariant;`

`GetUnscaledDataEx` is an extended version of `GetUnscaledData`. `GetUnscaledDataEx` returns unscaled data from the direct buffer which is already linearized and allows specifying the start position from where to start retrieving data and the desired amount of data.

Parameters:

`Start` defines the position within the direct buffer from where to start retrieving data.

`Count` is the amount of data being retrieved.

procedure `GetUnscaledDataEx1(Start: Integer; Count: Integer; out Data: OleVariant);`

`GetUnscaledDataEx1` offers functionality equal to `GetUnscaledDataEx` but is implemented as a procedure and not as a function.

`Start` defines the position within the direct buffer from where to start retrieving data.

`Count` is the amount of data being retrieved.

`Data` contains the data retrieved from the direct buffer.

procedure `IncDBSamples(Count: Integer);`

To increment the position of the direct buffer.

Parameters:

`Count` is the amount of samples the direct buffer position will be increased.

function `ScaleValue(Value: Single): Single;`

`ScaleValue` returns the scaled value of the given unscaled value.

Parameters:

`Value` is the unscaled value which should be scaled.

procedure `SetSRDiv(SRDiv: Integer);`

`SetSRDiv` allows setting the sample rate divider.

Parameters:

`SRDiv` is the sample rate divider to be set.

procedure `SetSRDivType(AType: TSRDivType);`

`SetSRDivType` allows setting the type of sample rate divider.

Parameters:

`AType` is type to be applied which is of the data type `TSRDivType`. `AType` can be one of the following:

0...`sdSkip`

1...`sdAverage`

2...`sdFilter4th`

3...`sdFilter6th`

4...`sdFilter8th`

7.10.2 Properties of `IChannel`

property `Async: WordBool;` (read-only)

`Async` is `True` when the channel is asynchronous, otherwise it is `False`.

property Bytes: Integer; (read-only)

Bytes is the number of bytes used for one data sample of the specific channel. The number of bytes depends on the data type used for the channel.

property DataType: Integer; (read-only)

DataType is the data type of data samples of a channel. The data type can be one of the following:

- 0...Byte,
- 1...ShortInt,
- 2...SmallInt,
- 3...Word,
- 4...Integer,
- 5...Single,
- 6...Int64,
- 7...Double,

property DBBufSize: Integer; (read-only)

DBBufSize is the size of the direct buffer. (See 3.1 The Buffer Structure)

property DBDataSize: Integer; (read-only)

DBDataSize is the size of the data stored in the direct buffer.

property DBPos: Integer; (read-only)

DBPos is the next position within the direct buffer to be written to.

property DBTimeStamp[Index: Integer]: Double; (read-only)

DBTimeStamp[Index] is the timestamp data of asynchronous data in the direct buffer. Index is the position within the direct buffer.

property DBValues[Index: Integer]: Single; (read-only)

DBValues[Index] is the data value in the direct buffer. Index is the position within the direct buffer.

property Description: WideString;

Description is a comment to a channel. Description is equal to “property Measurement”. Description correspond to the description entered within the channel setup dialog (see mouse cursor in Figure 98) which can be reached via the setup button of a channel (see mouse cursor in Figure 97).




Figure 97 Channel Setup Button




Figure 98 Channel Setup

property ExportOrder: Integer

ExportOrder allows specifying the order in which the channels are exported. The default value is -1 meaning not ordered. Channels having the default ExportOrder set to -1 will always be listed after any channel having a customized ExportOrder.

So, e.g. the order of channels can be similar to the following list of ExportOrder properties:

- 3
- 4
- 7
- 1000
- 7000
- 1
- 1
- 1
- ...

This order will be applied to the channel lists shown in any screen too.

Using “Data >> Store Settings and Events”, these settings can be stored to the data file.

property Group: IChannelGroup; (read-only)

Group is a group containing the channels. E.g. channels of a plug-in have to be mounted to group 8.

property IBBufSize: Integer; (read-only)

IBBufSize is the size of the intermediate buffer. (See 3.1 The Buffer Structure)

property IBDataSize: Integer; (read-only)

IBDataSize is the size of the data within the intermediate buffer.

property IBPos: Integer; (read-only)

IBPos is the next position in the intermediate buffer to be written to.

property IBValues[Index: Integer]: T_ReducedRec; (read-only)

IBValues[Index] is a record of the intermediate buffer values at Index. Index defines the position within the intermediate buffer. The record contains the values Min, Max, Ave and RMS.

The property IBValues does not work in conjunction with LabVIEW. It is recommended to use the procedure IChannel.GetIBValues instead.

property Index: T_ChIndex; (read-only)

Index is a record of indexes specifying a channel. See T_ChIndex in 7.10.3 Types / Constants of IChannel.

The property Index is not available in LabVIEW. It is recommended to use the procedure IChannel.GetIndex1 instead.

property MainDisplayColor: Int64;

MainDisplayColor specifies the color of a channel. The default colors of DEWESoft and their order are as follows:

clLime, clAqua, clRed, clFuchsia, clBlue, clTeal, clOlive, clGreen,
\$00FF8080, \$00FF80FF, \$0080FF00, \$00FFFF80, \$00D6DAD6, \$0081ABB1, \$00CF63C7, \$0065CD92,
\$0043E7EF, \$005ED5D5, \$00953AC9, \$00F19A9C, \$00AFE6A6, \$00A0ADEB, \$0055CAB9, \$0013E6E6,
\$0010CBCB, \$00EA738A, \$002E04EE, \$004D5ED2, \$009F9FA2, \$00C67362, \$00C67362, \$00AA027C,
\$00AA027C, \$00BDFDFED, clWhite, \$005E0DE3, \$008F8D61, \$0021E4AA, \$002C49D3, \$00BC05B3,
\$002E03BE, \$0093FDF0, \$00026458, \$00BC4151, \$0040A293, \$00656569, \$00B37015, \$0002DBCB,
\$0021FEF3, \$0040B09A, \$008CFFDF, \$009A8BFE, \$00716F4D, \$005B49FE, \$0033079A, \$0001DA3D,
\$00020DD2, \$0074852E, \$003F41A0, \$00727070, clYellow, clSilver, clActiveCaption, clBtnFace;

property Measurement: WideString;

Measurement is equal to “property Description”. See there for detailed information.

property Name: WideString;

Name is the name of a channel.

property Offset: Double;

Offset is the value of the channel offset.

property RBufSize: Integer; (read-only)

RBufSize is the size of the reduced buffer. (See 3.1 The Buffer Structure)

property RBDataSize: Integer; (read-only)

RBDataSize is the size of the data within the reduced buffer.

property RBPos: Integer; (read-only)

RBPos is the next position in the reduced buffer to be written to.

property RBValues[Index: Integer]: T_ReducedRec; (read-only)

RBValues[Index] is a record of the reduced buffer values at Index. Index defines the position within the reduced buffer. The record contains the values Min, Max, Ave and RMS.

The property RBValues does not work in conjunction with LabVIEW. It is recommended to use the procedure IChannel.GetRBValues instead.

property Scale: Double;

Scale is the scaling value of a channel.

property Shown: WordBool;

Shown defines whether a channel is shown or not.

property SRDiv: Integer; (read-only)

SRDiv is the sample rate divider set for a specific channel. SRDiv corresponds to the setting within the channel setup shown at the position of the mouse cursor in Figure 99.




Figure 99 Sample rate divider

property TypicalMaxValue: Single; (read-only)

TypicalMaxValue is the maximum value of the y-axis of a graph displaying a certain channel.

property TypicalMinValue: Single; (read-only)

TypicalMinValue is the minimum value of the y-axis of a graph displaying a certain channel.

property Unit_: WideString;

Unit_ defines the measurement unit of a channel.

property Used: WordBool;

Used specifies whether a channel is used or not, corresponding to the “Used” button at each channel in the measurement setup (Cf. Figure 100).




Figure 100 "Used" Button

property UserScaleMax: Single;

UserScaleMax offers the ability to change the maximum value of the scaling of the y-axis of a channel.

property UserScaleMin: Single;

UserScaleMin offers the ability to change the minimum value of the scaling of the y-axis of a channel.

7.10.3 Types / Constants of IChannel

T_ChIndex

T_ChIndex = packed record

IndexLevel: Smallint;

Index1: Integer;

Index2: Integer;

Index3: Integer;

Index4: Integer;
 Index5: Integer;
 end;

T_ChIndex is a record of indexes containing information about a channel.

IndexLevel defines the number of used indexes, which depends on the kind of a channel.

Index1 always defines the group a channel belongs to. Index2 to Index5 are group dependant indexes, which can be interpreted as described in Table 2:

Table 2 T_ChIndex

Channel type	IndexLevel (number of used indexes)	Index1	Index2	Index3	Index4	Index5
AI	2	1	channel number (0...number of channels - 1)			
			Example: Channel "AI 3" → (2; 1, 3)			
DI	3	100	port number	bit number		
			Example: Channel "bit no 3 on DI port 2" → (3; 100, 2, 3)			
Counter	2	200	counter number (0...number of counters - 1)			
			Example: Channel "counter 0" → (2; 200, 0)			
PAD	3	1000	slot number	channel number on module		
			Example: Channel "PAD slot 3/ Ch 2" – (3; 1000, 3, 2)			
CAN bus message	3	2000	port number	message id		
			Example: channel "RPM in Motor message on CAN port 0" → (3; 2000, 0, 33 [Motor message id])			
CAN bus signal	4	2000	port number	message id	start bit in message	
			Example: channel "RPM in Motor message on CAN port 0" → (4; 2000, 0, 33 [Motor message id], 16 [start bit of RPM channel])			
MATH (old, DEWESoft 6.3.x)	2	3000	math channel number			
			Example: Channel "Math 5" → (2; 3000, 5)			
MATH (new, DEWESoft 6.4)	4	7000	number of the math object. (The line in the math channel setup.)	Module number. E.g. basic statistics has as much modules as input channels.	The output channel number of one math module.	
			Example: Channel "Math object 5, module 0, output channel 1" → (4; 7000, 5, 0, 1)			
GPS	2	4000	GPS channel (0...X absolute, 1...Y absolute, ..., 7...used satellites;)			
			Example: channel "Y absolute" → (2; 4000, 1)			
Power	5	6000	Module number (0...#Modules-1)	Phase Phase 1 = 1 Phase 2 = 2 Phase 3 = 3 Total = 4	Voltages = 0; Currents = 1; Power = 2; THD = 3; Unbalance= 5; Disturbances= 6; Impedances= 7; Flicker= 8;	0...Number of channels
			Example: (5; 6000; 0; 1; 3; 0) THD 0 of 1 st power module.			
AO	3	200000	AO channel sub-type: 10000...AO/Freq	AO channel number.		

			0...AO 1000...AO/Ampl 2000...AO/Phase 3000...AO/Offset			
Example: (3; 200000, 2000, 0) Phase of AO 0.						

T_ReducedRec

T_ReducedRec = packed record

Min: Single;

Max: Single;

Ave: Single;

Rms: Single;

end;

T_ReducedRec is a record of reduced data values of the following kinds: Minimum, Maximum, Average and RMS.

7.11 IChannelConnection

7.11.1 Methods of IChannelConnection

function GetDataBlocks(NumBlocks: Integer): OleVariant;

GetDataBlocks returns a certain number of data blocks from the direct buffer. The return value is an OleVariant containing an array of values of the type “Single”. The size of the array will be NumBlocks times the size of one data block. The size of the data blocks and the position within the direct buffer from where data is retrieved are dependant on the properties AType and BlockSize. See there for detailed information.

Parameters:

NumBlocks defines the number of data blocks to read.

procedure GetDataBlocks1(NumBlocks: Integer; out Data: OleVariant);

GetDataBlocks1 offers the same functionality as GetDataBlocks but is implemented as a procedure instead of a function.

Parameters:

NumBlocks defines the number of data blocks to read.

Data contains an array of values of the type “Single”.

function GetDataValues(NumValues: Integer): OleVariant;

GetDataValues returns the specified amount of data values from the direct buffer. The return value is an OleVariant containing an array of values of the type “Single”. The size of the array will be equal to NumValues. If GetDataValues is used, IChannelConnection.AType would be set to ctLast in most cases. If IChannelConnection.AType is set to ctNew, data will be returned only if the specified amount of new data (not read yet) is available. If GetDataValues is used for reading asynchronous data, the corresponding timestamps can be read by GetTSValues. If those two functions are used, GetTSValues has to be called before GetDataValues is called.

Parameters:

NumValues specifies the amount of data values to retrieve from the direct buffer.

procedure GetDataValues1(NumValues: Integer; out Data: OleVariant);

GetDataValues1 offers the same functionality as GetDataValues but is implemented as a procedure instead of a function. If GetDataValues is used, IChannelConnection.AType would be set to ctLast in most cases. If IChannelConnection.AType is set to ctNew, data will be

returned only if the specified amount of new data (not read yet) is available. If `GetDataValues1` is used for reading asynchronous data, the corresponding timestamps can be read by `GetTSValues1`. If those two functions are used, `GetTSValues1` has to be called before `GetDataValues1` is called.

Parameters:

`NumValues` specifies the amount of data values to retrieve from the direct buffer.

`Data` contains an array of values of the type “Single”.

procedure Reset;

To reset a `ChannelConnection` at a certain moment. In the case of multiple connections, calling `StartDataSync` before resetting the connections and calling `EndDataSync` after having reset each connection would be necessary for synchronization. (Remark: Reset is called by `CreateConnection`.)

procedure Start;

`Start` resets the `ChannelConnections` to the start of the acquisition.

function GetTSBlocks(NumBlocks: Integer): OleVariant;

`GetTSBlocks` has to be used in conjunction with `GetDataBlocks` in case of asynchronous channels. When those two functions are used, `GetTSBlocks` has to be called before `GetDataBlocks`. The return value is an `OleVariant` containing an array of timestamp values of the type “Double”.

Parameters:

`NumBlocks` specifies the number of blocks to read.

procedure GetTSBlocks1(NumBlocks: Integer; out Data: OleVariant);

`GetTSBlocks1` offers the same functionality as `GetTSBlocks`, but is implemented as a procedure instead of a function.

Parameters:

`NumBlocks` specifies the number of blocks to read.

`Data` contains an array of timestamps of the type “Double”.

function GetTSValues(NumValues: Integer): OleVariant;

`GetTSValues` returns the specified amount of timestamp values from the direct buffer. The return value is an `OleVariant` containing an array of timestamps of the type “Double”. The size of the array will be equal to `NumValues`. If `GetTSValues` is used, `ICChannelConnection.AType` would be set to `ctLast` in most cases. If `ICChannelConnection.AType` is set to `ctNew`, data will be returned only if the specified amount of new data (not read yet) is available. `GetTSValues` is intended to be used in conjunction with `GetDataValues`. When both of these functions are used, `GetTSValues` has to be called before `GetDataValues`.

Parameters:

`NumValues` specifies the amount of timestamps to retrieve from the direct buffer.

procedure GetTSValues1(NumValues: Integer; out Data: OleVariant);

`GetTSValues1` offers the same functionality as `GetTSValues` but is implemented as a procedure instead of a function. If `GetSTValues1` is used, `ICChannelConnection.AType` has to be set to `ctLast`. `GetTSValues1` is intended to be used in conjunction with `GetDataValues1`. When both of these functions are used, `GetTSValues1` has to be called before `GetDataValues1`.

Parameters:

`NumValues` specifies the amount of timestamps to retrieve from the direct buffer.

Data contains an array of timestamps of the type “Double”.

7.11.2 Properties of IChannelConnection

property AType: ConnTypes;

AType defines the type of the ChannelConnection and therefore alters the behavior of GetDataBlocks and GetDataBlocks1. AType can be one of the following:

0... ctLast... for reading a certain amount (specified by “BlockSize”) of the last data; Figure 101 illustrates two subsequent calls of GetDataBlocks when AType is set to ctLast.

1... ctOverlap... for reading blocks (size specified by “BlockSize”) of data; the percentage of an overlap of the data blocks can be specified by Overlap; Figure 102 illustrates two subsequent calls of GetDataBlocks when AType is set to ctOverlap and Overlap is set to 0%. In Figure 103 Overlap is set to 50%.

2... ctTrigger... for reading the data which is displayed in the Scope-screen on triggers (use App.SetScopeParams before, in order to setup the trigger of the scope and activate the scope trigger by calling App.SetScopeTriggerUsed(True); see chapter 7.6.1 Methods of IApp for detailed information.).

3... ctNew... for reading a certain amount (specified by “BlockSize” or “NumValues”) of the last data only if such an amount of new data (not read yet) is available.




Figure 101 AType set to ctLast




Figure 102 AType set to ctOverlap, Overlap set to 0




Figure 103 AType set to ctOverlap, Overlap set to 50

property BlockSize: Integer;

BlockSize specifies the size of the data block(s) to read using GetDataBlocks or GetDataBlocks1.

property Channel: IChannel; (read-only)

See IChannel for detailed information.

property NumBlocks: Integer; (read-only)

NumBlocks is the number of available data blocks of the size specified by BlockSize within the direct buffer not read yet.

property NumValues: Integer; (read-only)

NumValues is the number of available values within the direct buffer not read yet.

property Overlap: Integer;

Overlap defines how much the data blocks read by two subsequent calls of GetDataBlocks or GetDataBlocks1 should overlap each other, when AType is set to ctOverlap. See Figure 102 and Figure 103 for illustration.

7.11.3 Types / Constants of IChannelConnection

type

```
ConnTypes = TOleEnum;
```

const

```
ctLast 0;
```

```
ctOverlap = 1;
```

```
ctTrigger = 2;
```

```
..ctNew = 3;
```

7.12 IChannelGroup

7.12.1 Methods of IChannelGroup

function GetIndexName(Index: T_ChIndex): WideString;

GetIndexName returns the name of the ChannelGroup specified by Index.

7.12.2 Properties of IChannelGroup

property Count: Integer; (read-only)

Count is the number of channels in a group.

property ExportRate: Integer;

ExportRate defines the sample rate for exporting asynchronous data to DIAdem. This property can be set separately for each group.

property Item[Index: Integer]: IChannel; (read-only)

Item[Index] is the channel item of a group. This item is of the type IChannel.

property Name: WideString; (read-only)

Name is the name of a group. The name of a group cannot be changed.

7.13 IChannelGroup2

IChannelGroup2 is derived from IChannelGroup, so it provides the properties and methods of IChannelGroup including those of IChannelGroup2

7.13.1 Methods of IChannelGroup2

function GetIndexNameShort(Index: T_ChIndex): WideString;

GetIndexNameShort returns the name of the index in an abbreviated version.

7.14 IChannelGroups

7.14.1 Properties of IChannelGroups

property Count: Integer; (read-only)

Count indicates the number of channel groups.

property Item[Index: Integer]: IChannelGroup; (read-only)

Item[Index] is one of the channel groups which is of the type IChannelGroup

7.15 IChannelList

7.15.1 Properties of IChannelList

property Count: Integer; (read-only)

Count is the number of channels within the channel list.

property Item[Index: Integer]: IChannel; (read-only)

Item[Index] is one of the channels from the channel list. The item is of the type IChannel.

7.16 IDaqChannel

In order to access the properties of IDaqChannel a channel of the type IChannel must be casted to the type IDaqChannel. The properties of IDaqChannel are available only for analog channels.

7.16.1 Methods of IDaqChannel

procedure SetCardGain(Gain: Single);

SetCardGain sets the gain of a DAQ card.

Parameters:

Gain is the new gain value to be set.

7.16.2 Properties of IDaqChannel

property AutoZero: WordBool;

AutoZero defines whether the zero function of a DAQ channel is set to automatic or not. Cf. to the Auto button of a DAQ channel at the mouse cursor position in Figure 104.

SLOT	ON/OFF	NAME	PHYSICAL VALUES	ZERO	Auto	SETUP
0	Used	AI 0	- [-] 5	Zero	Auto	Set ch. 0
1	Unused	AI 1	- [-] 5	Zero	Auto	Set ch. 1
2	Unused	AI 2	- [-] 5	Zero	Auto	Set ch. 2

Figure 104 AutoZero

property CardBitResolution: Integer; (read-only)

CardBitResolution returns the resolution of a DAQ card in bits.

property CardGain: Double; (read-only)

Card Gain is the gain value which is set at a DAQ card.

property CardOffset: Double; (read-only)

CardOffset is the offset value set for a DAQ card.

property ModuleGain: Double; (read-only)

ModuleGain is the gain value set at a module.

property ModuleOffset: Double; (read-only)

ModuleOffset is the offset value set at a module.

property ModuleType: Integer; (read-only)

ModuleType is the type of a module.

The association of the number to the modules is as follows:

- 2... DAQP-Bridge
- 5... DAQP-Charge
- 8... DAQP-Freq
- 9... DAQP-Acc
- 23... DAQP-Charge-A
- 24... DAQP-Bridge-A
- 26... DAQP-Freq-A
- 27... DAQP-ACC-A
- 30... DAQP-Charge-B
- 31... DAQP-Bridge-B
- 34... DAQP-V-A
- 35... DAQP-V-B
- 36... MDAQ

7.17 IDaqData

7.17.1 Methods of IDaqData

function CopyToString: WideString;

CopyToString copies the module parameters to a string.

function CopyUnitToString: WideString;

CopyUnitToString copies the unit of measurement to a string.

function ModuleAmpl: Single;

ModuleAmpl returns the module scale factor.

function ModuleOffset: Single;

ModuleOffset returns the module offset factor.

function ShortCopyToString: WideString;

ShortCopyToString copies the module parameters in a short version (only the values) to a string.

7.17.2 Properties of IDaqData

property Address: Smallint;

Address defines the address of the DAQ-module.

property CurrentSource: Byte;

CurrentSource defines the current source of ACC modules. Valid values for this property are the following:

0...4mA

1...8mA

property DaqNNames[ANameCode: Smallint]: WideString; (read-only)

DaqNNames provides the name of a DAQN-module referenced by ANameCode.

property DaqNNamesCount: Integer; (read-only)

DaqNNamesCount is the number of available DAQN-modules.

property Filters[AFilterCode: Byte]: WideString; (read-only)

Filters provides the name of a filter corresponding to AFilterCode.

property FilterCode: Byte;

FilterCode defines the filter of a DAQ-module.

property FiltersCount: Integer; (read-only)

FiltersCount is the number of filters available for DAQ-modules.

property FREQAInputCoupling: Shortint;

FREQAInputCoupling defines the input coupling-type of a FREQ-A-module, which can be:

0...AC

1...DC

property FREQAOutputFilter: Shortint;

FREQAOutputFilter defines the output filter-type of a FREQ-A-module, which can be:

0...slow

1...fast

property FREQATriggerLevel: Single;

FREQATriggerLevel defines the trigger level of a FREQ-A-module.

property HighpassType: Byte;

HighpassType defines the type of the highpass-filter set at a DAQ-module. Possible values are dependent on the module type.

property ICPInput: Byte;

ICPinput defines whether a charge-module is set to ICP or to charge. The meaning is dependant on the module-type.

property ModuleError: Byte; (read-only)

ModuleError is the error code of a module. Refer to the technical reference of the modules for detailed information.

property ModuleType: Smallint; (read-only)

ModuleType defines the type of a module.

The association of the number to the modules is as follows:

2... DAQP-Bridge
5... DAQP-Charge
8... DAQP-Freq
9... DAQP-Acc
23... DAQP-Charge-A
24... DAQP-Bridge-A
26... DAQP-Freq-A
27... DAQP-ACC-A
30... DAQP-Charge-B
31... DAQP-Bridge-B
34... DAQP-V-A
35... DAQP-V-B
36... MDAQ

property Name: WideString; (read-only)

Name provides the name of a module.

property Overflow: Byte;

Overflow will be 1 if an overflow has occurred.

property RangeCode: Byte;

RangeCode is the code denoting the measurement range of the module. Refer to the technical reference of the modules for detailed information.

property Ranges[ARangeCode: Integer]: WideString; (read-only)

Ranges allows to retrieve the range settings as a string according to the range code.

ARangeCode must be in the range of 0...RangesCount-1.

property RangesCount: Integer; (read-only)

RangesCount is the number of valid ranges of a module.

property Remote: Byte;

Remote denotes whether the module is set to local or remote mode. Refer to the technical reference of the modules for detailed information.

property VRange: Byte;

VRange is only used with DAQP-FREQ-module to indicate the trigger voltage input range.

7.18 IDaqGroup

7.18.1 Properties of IDaqGroup

property Count: Integer; (read-only)

Count is the number of channels of the type IDaqChannel within DaqGroup.

property Item[Index: Integer]: IDaqChannel; (read-only)

Item[] is the list of DaqGroups channel items of the type IDaqChannel. Index is the list index, which is in the range of 0...Count-1;

7.19 IData

7.19.1 Methods of IData

procedure ApplyChannels;

ApplyChannels has to be called after channels of a plug-in are mounted by any user-action (button-click).

procedure BuildChannelList;

BuildChannelList updates the properties AllChannels and UsedChannels. This procedure should be called before reading one of these properties after some channels have been set to used or not.

procedure EndDataSync;

EndDataSync has to be used together with StartDataSync in conjunction with IChannelConnection for synchronous manipulation of multiple channels. See 7.11 for details.

function FindChannel(const Name: WideString): IChannel;

FindChannel allows finding a channel by means of its name.

Parameters:

Name is the name of the requested channel. It must be the exact name of an existing channel in order to find the channel. The function is case-sensitive.

function FindChannelByIndex(Index: T_ChIndex): IChannel;

FindChannelByIndex allows finding a channel by its indexes.

Parameters:

Index is of the type T_ChIndex. See T_ChIndex in 7.10.3 Types / Constants .

FindChannelByIndex does not work in conjunction with LabVIEW. It is recommended to use IData.FindChannelByIndex1 instead.

function FindChannelByIndex1(IndexLevel: Integer; I1: Integer; I2: Integer; I3: Integer; I4: Integer; I5: Integer): IChannel;

FindChannelByIndex1 has the same functionality as FindChannelByIndex, namely finding a channel by its indexes. It is implemented because FindChannelByIndex does not work in conjunction with LabVIEW.

Parameters:

IndexLevel defines the number of used indexes for specifying a channel.

I1 is the group a channel corresponds to.

I2...I5 are the channel specific indexes.

See Table 2 for detailed information about the channel indexes.

function GetIndexName(Index: T_ChIndex): WideString;

GetIndexName returns the identifier specified by Index.

Parameters:

Index is of the type T_ChIndex. See T_ChIndex in 7.10.3 Types / Constants .

GetIndexName does not work in conjunction with LabVIEW. It is recommended to use IData.GetIndexName1 instead.

function GetIndexName1(IndexLevel: Integer; I1: Integer; I2: Integer; I3: Integer; I4: Integer; I5: Integer): WideString;

GetIndexName1 returns the identifier specified by its index.

Parameters:

IndexLevel specifies which index' name should be returned. If IndexLevel is 1, the name of Index1 is returned, and so on.

I1 is the group a channel corresponds to.

I2...I5 are the channel specific indexes.

See Table 2 for detailed information about the channel indexes.

function GetIndexNameShort(ChIndex: T_ChIndex): WideString;

GetIndexNameShort returns the short identifier specified by Index.

Parameters:

Index is of the type T_ChIndex. See T_ChIndex in 7.10.3 Types / Constants .

GetIndexName does not work in conjunction with LabVIEW. It is recommended to use IData.GetIndexNameShort1 instead.

function GetIndexNameShort1(IndexLevel: Integer; I1: Integer; I2: Integer; I3: Integer; I4: Integer; I5: Integer): WideString;

GetIndexNameShort1 returns the identifier specified by its index.

Parameters:

IndexLevel specifies which index' name should be returned. If IndexLevel is 1, the name of Index1 is returned, and so on.

I1 is the group a channel corresponds to.

I2...I5 are the channel specific indexes.

See Table 2 for detailed information about the channel indexes.

procedure GetSamplesAcquired(out Mid: Integer; out Dir: Integer);

GetSamplesAcquired returns information about the amount of data acquired.

Parameters:

Mid is the number of complete data blocks of the size specified by the property Samples. (See Properties  of IData)

procedure StartDataSync;

StartDataSync has to be used together with EndDataSync in conjunction with

IChannelConnection for synchronous manipulation of multiple channels. See 7.11 for details.

7.19.2 Properties of IData

property ActiveChannels: IChannelList; (read-only)

Do **not** use ActiveChannels because it is implemented for internal use only. Use AllChannels or UsedChannels instead!

ActiveChannels is a list of the active channels, which is of the type IChannelList. Active channels are those channels which are available according to the hardware setup.

property AllChannels: IChannelList; (read-only)

AllChannels is a list of all available channels, which is of the type IChannelList. (Cf. IData.UsedChannels). Call IData.BuildChannelList before reading the property to update it, if some channels have been set to used or not before.

property CurrentPos: T_RecordPosition;

CurrentPos is used in analyze mode of DEWESoft. It corresponds to the position of the yellow cursor as shown in Figure 105.




Figure 105 Current Position Cursor

property EndStamp: T_RecordPosition;

EndStamp is the last possible position of the yellow cursor.

property ExternalClock: Integer; (read-only)

ExternalClock is the external clock definition in clocks per revolution.

property Groups: IChannelGroups; (read-only)

Groups are the groups which data is dedicated to. Each kind of channel belongs to a certain group. E.g. the data group for plug-in data is 8.

property SampleRate: Integer; (read-only)

SampleRate is the sampling rate not depending on the factor of the “reduced rate”.

property Samples: Integer; (read-only)

Samples is the number of data samples within one data block.

property ShownChannels: IChannelList; (read-only)

ShownChannels is **not** recommended to use! Use AllChannels or Used Channels instead! ShownChannels is a list of the channels being set to “used” (See the mouse cursor in Figure 106 pointing at the “Used” button). This property is accurate only when the application is in measure mode and the setup screen is already left. This list is of the type IChannelList.

property StartStamp: T_RecordPosition;

StartStamp is the first possible position of the yellow cursor within the analyse mode of DEWESoft.

property StartStoreTime: TDateTime; (read-only)

StartStoreTime is the absolute time of the start of storing.

property StartStoreTimeUTC: TDateTime; (read-only)

StartStoreTimeUTC is the UTC of the start of storing.

property UsedChannels: IChannelList; (read-only)

UsedChannels is a list of the channels being set to “used” (See the mouse cursor in Figure 106 pointing at the “Used” button). This list is of the type IChannelList. (Cf. IData.AllChannels) Call IData.BuildChannelList before reading the property to update it, if some channels have been set to used or not before.




Figure 106 "Used" Button

7.20 IDataSection

7.20.1 Methods of IDataSection

function ReadData(const Channel: IChannel; out Timestamps: OleVariant): OleVariant;

ReadData reads the whole set of data of a section. A section is the part between a start and a stop event. The data section is independent of the data blocks. The data is returned as an OleVariant containing an array of data values of the type Single.

Parameters:

Channel defines the channel of which data should be retrieved.

Timestamps returns an OleVariant containing an array of timestamp data of the section.

Timestamps are of the type Double.

procedure ReadData1(const Channel: IChannel; out Data: OleVariant; out Timestamps: OleVariant);

ReadData1 is similar to ReadData but is implemented as a procedure instead of a function.

Parameters:

Channel defines the channel of which data should be retrieved.

Data returns an OleVariant containing an array of measurement data of the section. The array consists of values of the type Single.

Timestamps returns an OleVariant containing an array of timestamp data of the section.

Timestamps are of the type Double.

7.20.2 Properties of IDataSection

property DataCount: Integer; (read-only)

DataCount is the number of samples within a DataSection.

property Time: TDateTime; (read-only)

Time is the absolute start time of a section.

property TrigPos: Integer; (read-only)

TrigPos is the number of the sample where the trigger event occurred, counted from the start of the section.

7.21 IDataSections

7.21.1 Properties of IDataSections

property Count Integer; (read-only)

Count is the number of data sections where measurement data is stored.

property Item[Index: Integer]: IDataSection; (read-only)

Item[Index] is a section where data is stored, which is of the type IDataSection. Cf. 7.20.

7.22 IEvent

7.22.1 Properties of IEvent

property Data: OleVariant; (read-only)

Data contains special information about an event. E.g. this can be text or voice data. (This function is not implemented yet.)

property PosDir: Integer; (read-only)

PosDir is the position of an event within a data block.

property PosMid: Integer; (read-only)

PosMid is the number of the data block where the event has happened.

property TimeStamp: Double; (read-only)

TimeStamp is the time stamp of an event in seconds.

property Type_: Integer; (read-only)

Type_ defines the type of an event which can be one of the following:

- 1 indicating “start”,
- 2 indicating “stop”,
- 3 indicating “trigger”,
- 11 indicating “VStart” (video start storing)
- 12 indicating “VStop” (video stop storing)
- 20 indicating “Keyboard”
- 21 indicating “Notice”
- 22 indicating “Voice”
- 24 indicating “Module” (example: Bridge shunt on/off).

7.23 IEventList

7.23.1 Properties of IEventList

property Count: Integer; (read-only)

Count is the number of events.

property Item[Index: Integer]: IEvent; (read-only)

Item[Index] is the even item of the type IEvent. See 7.22.

7.24 IFileNameSettings

7.24.1 Properties of IFileNameSettings

property AutoCreate: WordBool;

AutoCreate determines whether a data file name should be generated automatically (Cf. Figure 107).



Figure 107 Data File Options – Create a multifile

property AutoFlipAbsTime: WordBool;

AutoFlipAbsTime defines whether absolute time is used or not, in case of the Unit being set to any time unit (Cf. Figure 108).



Figure 108 Data File Options – Absolute time

property AutoFlipFile: WordBool;

AutoFlipFile defines whether a new file should be created after a certain criterion (cf. Figure 109).



Figure 109 Data File Options – Make new file after

property AutoFlipSize: Single;

AutoFlipSize is the size of a certain unit after which a new file will be created (cf. Figure 110).



Figure 110 Data File Options – Size

property AutoFlipUnit: Integer;

AutoFlipUnit is the unit of the AutoFlipSize which can be MB, h, min, sec or triggers (cf. Figure 111). The value assigned to AutoFlipUnit refers to the list index of the possible selections:

- 0...MB
- 1...h
- 2...min
- 3...sec
- 4...triggers



Figure 111 Data File Options – Unit

property BaseFileName: WideString;

BaseFileName is the file name prefix for automatic naming of multi files (cf. Figure 112).



Figure 112 Data File Options – File name

property MultiFileStartIndex: Integer;

MultiFileStartIndex is the number to start from for the naming of multi files (cf. Figure 113).



Figure 113 Filename setup – Start index

property UseDate: WordBool;

UseDate determines whether the date should be included in the file name (cf. Figure 114).



Figure 114 Filename setup – Date of storing

property UseMultiFile: WordBool;

UseMultiFile determines whether to use the multi file option or not (cf. Figure 115).



Figure 115 Filename setup – Multifile

property UseTime: WordBool;

UseTime determines whether the time should be included in the file name (cf. Figure 116).



Figure 116 Filename setup – Time of storing

7.25 ILoadEngine

7.25.1 Methods of ILoadEngine

procedure CloseFile;

CloseFile closes a measurement file.

function NextDBLoad: WordBool;

NextDBLoad is used in conjunction with StartDBLoad. It proceeds to the next data block of the direct buffer. The function returns True, if a data block is available; False otherwise.

procedure ReloadBlock(Num: Integer);

ReloadBlock reloads the specified data block.

Parameters:

Num defines the data bloc to reload.

procedure Reload(Start: T_RecordPosition; Stop: T_RecordPosition);

Reload reloads a specific section of data.

Parameters:

Start is the beginning of the data section to reload.

Stop is the end of the data section to reload.

procedure ShrinkFile(const FileName: WideString);

ShrinkFile makes an export back to DEWESoft. Prior to using this function the properties Data.StartStamp and Data.EndStamp (see Properties  of IData) have to be set defining the boundaries of the new file.

Parameters:

FileName is the name of the file including the path to where the new file is stored to.

procedure StartDBLoad(Start: T_RecordPosition; Stop: T_RecordPosition; BlockSize: Integer);

StartDBLoad starts the loading of datablocks beginning at a certain position within the direct buffer, to a certain position within the direct buffer, of a certain blocksize. The function NextDBLoad has to be used to proceed to the next data block.

Parameters:

Start is the start position from where the reloading of data will begin.

Stop is the end position up to which the reloading of data will proceed.

BlockSize is the size of the data blocks being retrieved.

7.25.2 Properties of ILoadEngine

property DataSections: IDataSections; (read-only)

DataSections provides information about data sections which are the parts between a start and a stop event.

property FileOpened: WordBool; (read-only)

FileOpened specifies whether a measurement file is currently opened or not.

property NumBlocks: Integer; (read-only)

NumBlocks is the number of data blocks within a measurement file.

property ReducedOnly: WordBool; (read-only)

ReducedOnly specifies whether data has been stored using reduced rate only.

property VideoLoadEngines: IVideoLoadEngines; (read-only)

See IVideoLoadEngines;

7.26 IMasterClock

7.26.1 Methods of IMasterClock

function GetCurrentTime: Double;

GetCurrentTime returns the current time from the A/D-board before the data is transferred. The unit of this time is seconds. MasterClock can be used for time stamping asynchronous data.

7.27 IModule

7.27.1 Methods of IModule

procedure ClearModule;

ClearModule sets the address of a PAD-module back to 0.

procedure DetectModule(Address: Integer);

DetectModule detects a module at a certain address.

Parameter:

Address is the address at which the module has to be detected.

function FillModule(Address: Integer; Timeout: Integer): WordBool;

FillModule tries to set a PAD-module having address 0 to the given address and waits for pressing the button on the module.

Parameters:

Address is the new address to set for the PAD-module.

Timeout is the time to wait for the operator pressing the button on the module or the time it may take to detect the module at the given address. Its unit is ms.

procedure FREQAFindTriggerLevel;

FREQAFindTriggerLevel activates the auto-trigger of the FREQA-module.

procedure GetPadData;

GetPadData retrieves the current data from the PAD-module. The data can be read afterwards via the property PadData.

function GetSerialNumber: WideString;

GetSerialNumber reads out the serial number of the module. The return-value is a string.

function SetDaq: WordBool;

SetDaq applies the configuration to a PAD-module after previously having changed its properties.

procedure SetDaqAddress(Address: Integer; Timeout: Integer);

SetDaqAddress changes the address of the DAQ-module.

Parameters:

Address is the new address to set for the module. The values have to be in the range 0...254.

Timeout specifies the timeout-limit. Its unit is [ms].

procedure SetModule(SetType: Integer);

SetModule applies the properties of a module which were specified before.

Parameters:

SetType has to be 2 always. (Other values of SetType are for internal use only.)

procedure SetPad(NewAddress: Integer);

SetPad sets the address and applies the configuration to a PAD-module.

Parameter:

NewAddress is the address to set for the PAD-module. The values have to be within the range 0...255.

7.27.2 Properties of IModule

property DaqData: IDaqData; (read-only)

DaqData provides the data of a DAQ-module.

property Index: Smallint; (read-only)

Index is the index of the module which is in the range 0...IModules.Count-1.

property ModuleType: Smallint;

ModuleType denotes the type of a module. Its value can be one of the following:

0...none

1...PAD

2...DAQ

property PadData: IPadData; (read-only)

PadData is the data of the PAD-module. See 7.29 IPadData.

7.28 IModules

7.28.1 Properties of IModules

property Count: Integer; (read-only)

Count is the number of available modules.

property Item[Index: Integer]: IModule; (read-only)

Item is the reference to one of the modules of the type IModule. Valid indexes are in the range 0...Count-1. See 7.27 IModule.

7.29 IPadData

7.29.1 Methods of IPadData

function CopyToString: WideString;

CopyToString returns the data of the PAD-module as a string.

function CopyUnitToString: WideString;

CopyUnitToString returns the unit of the PAD-module as a string.

function ModuleAmpl: Single;

ModuleAmpl returns module scale factor.

function ModuleOffset: Single;

ModuleOffset returns the offset of the PAD-module.

function ShortCopyToString: WideString;

ShortCopyToString returns the data of the PAD-module in a short version (only the values) as a string.

7.29.2 Properties of IPadData

property Address: Smallint;

Address is the PAD-module's address.

property ConfigCode: Smallint; (read-only)

ConfigCode is the configuration code of a PAD-module.

property Data[Index: Integer]: Single; (read-only)

Data is the measurement data of the PAD-module as an array of Single values.

property ModuleType: Smallint; (read-only)

ModuleType is the type of the PAD-module which can be one of the following:

0...Unknown
1...PAD-V8
2...PAD-VTH
3...PAD-TH8
4...PAD-RTD3
5...PAD-AO1
6...PAD-CNT
7...PAD-DI8
8...PAD-DO7
9...PAD-V8-P
10...PAD-TH8-P

property Name: WideString; (read-only)

Name is the name of the PAD-Module.

property RangeCode: Smallint;

RangeCode is the range code of the PAD-module.

property RangeIndex[Index: Integer]: Integer; (read-only)

RangeIndex gives the range code of chosen range at Index.

property Ranges[Index: Integer]: WideString; (read-only)

Ranges gives the description of a range at the index.

property RangesCount: Integer; (read-only)

RangesCount defines the number of ranges available for the module.

property SpeedCode: Smallint; (read-only)

SpeedCode denotes the baudrate set on the module. The code is within the range 3...10 and having the following meaning:

3...1200 baud
4...2400 baud
5...4800 baud
6...9600 baud
7...19200 baud
8...38400 baud
9...57600 baud
10...115200 baud

7.30 IPlugin2

7.30.1 Methods of IPlugin2

procedure ClearChannelsInstance;

ClearChannelsInstance is called by DEWESoft when all channels are destroyed in DEWESoft. Therefore all instances of plug-in channels have to be set to “nil” “null” or “nothing”, depending on the programming language used for development of the plugin.

procedure Configure;

Configure is called by DEWESoft when a user presses the “Configure” button within the plug-in tab of the measurement setup screen. This button will appear, when the plug-in has no frame which could be embedded in the setup screen. At the procedure Configure a dialog

window could be opened in order to be able to make some settings to the plug-in. See Figure 4 on page 11.

procedure HideFrame;

HideFrame is called by DEWESoft when the measurement setup screen is left. This can be when switched to analyze mode or when switched to the stop screen.

procedure Initiate(const DeweApp: IApp);

Initiate is called by DEWESoft every time DEWESoft is started and the plug-in is checked in the hardware configuration (See Figure 2 on page 10) or when the hardware configuration window is closed and the plug-in is activated.

procedure LoadSetup(Data: OleVariant);

LoadSetup is called by DEWESoft every time a channel setup is loaded. This corresponds to the menu item “File >> Load Setup”. When switched from analyze mode to measurement setup, LoadSetup will also be called.

Parameters:

Data can contain any information about special settings of the plug-in if it has been stored to the setup file (.dss) at SaveSetup.

procedure NewSetup;

NewSetup is called by DEWESoft when a new setup is created. This corresponds to the menu item “File >> New Setup”. NewSetup happens also at startup of DEWESoft.

procedure OnGetData;

OnGetData is called by DEWESoft every time new data is added to a channel which happens about every 40 ms. At OnGetData it is not necessary to add new data.

procedure OnOleMsg(Msg: Integer; Param: Integer);

OnOleMsg will be called by DEWESoft after App.MainWndMessage has been called by an additional thread, other than the main thread, of the plug-in. When a plug-in has additional threads, these cannot send messages directly to DEWESoft. Therefore additional threads have to use App.MainWndMessage.

Parameters:

Msg and Param correspond to the arguments of MainWndMessage which are named equal. These parameters can be used to specify the message which has to be sent to DEWESoft.

procedure OnStartAcq;

OnStartAcq is called by DEWESoft when it is switched to one of the measurement screens e.g. “Overview”, “Recorder” etc. Implicitly this is done by starting storing when OnStartAcq has not been called by switching to one of the measurement screens before.

procedure OnStartStoring;

OnStartStoring is called by DEWESoft when the storing of data is started or a trigger for storing is armed, corresponding to the Store button.

procedure OnStopAcq;

OnStopAcq is called by DEWESoft when the acquisition is stopped. This can be by clicking the Stop button, switching to the setup screen or to the analyze mode, opening the “General setup” or the “Hardware setup” dialog, or by closing DEWESoft.

procedure OnStopStoring;

OnStopStoring is called by DEWESoft when the storing of data is stopped or a trigger for storing data is unarmed. This can be by clicking the Stop button, switching to the setup screen or to the analyze mode, opening the “General setup” or the “Hardware setup” dialog, or by closing DEWESoft.

procedure OnTrigger(Time: Double);

OnTrigger is called by DEWESoft every time a trigger occurs.

Parameters:

Time is the measurement time in seconds corresponding to the trigger event.

procedure SaveSetup(var Data: OleVariant);

SaveSetup is called by DEWESoft when a channel setup is saved. This corresponds to “File >> Save Setup”.

Parameters:

Data is of the type OleVariant and can be used to specific settings for the plug-in to a setup file (.dss). These data will read back on LoadSetup.

function ShowFrame(Parent: Integer): WordBool;

ShowFrame is called by DEWESoft when the setup screen is entered. The Boolean return value has to be true if the plug-in includes any setup frame to show, otherwise false.

Parameters:

Parent is the ID of the parent for the setup frame.

procedure UpdateFrame;

UpdateFrame is called by DEWESoft, when switched to the Plugins tab of the measurement setup screen. If there are more than one plug-ins activated in the hardware configuration, UpdateFrame will be called only for the plug-in which is currently marked in the list on the left side of the plug-ins tab.

7.30.2 Properties of IPlugin2

property Id: WideString; (read-only)

Id is the GUID (Globally Unique Identifier) of the plug-in library. This identifier is automatically generated by the development environment.

property Used: WordBool;

Used defines whether a plug-in is used or not. This corresponds to the check box in the Plugins tab of the measurement setup screen.

7.31 IPlugin3

7.31.1 Methods of IPlugin3

function GetDWTypeLibVersion: Integer;

At GetDWTypeLibVersion the version number of the DEWESoft type library should be returned. It is defined in DEWESoft’s type library as DEWESoftMinorVersion.

procedure OnAfterCalcMath;

OnAfterCalcMath is called after the Math-channels are calculated. This procedure should be used if the results of the Math-channels are relevant for the plug-in. This procedure is similar

to OnGetData of IPlugin2, but is called after calculation of the Math-channels. (DEWESoft channels are processed in the following order: Devices, Plug-ins, Math.)

procedure OnAfterStartAcq;

OnAfterStartAcquisition is called by DEWESoft on starting the acquisition. This procedure is equal to OnStartAcq of IPlugin2.

procedure OnAfterStopAcq;

OnAfterStopAcq is called by DEWESoft on stopping the Acquisition. This procedure is equal to OnStopAcq of IPlugin2.

procedure OnAlarm(CondIndex: Integer; Status: WordBool);

OnAlarm is called by DEWESoft on the occurrence of an alarm.

Parameters:

CondIndex gives the index of the related alarm condition.

Status tells whether the alarm condition has become true or false.

procedure OnBeforeStartAcq(var AllowStart: WordBool);

OnBeforeStartAcq is called by DEWESoft before the acquisition is started. Within this procedure some kind of initialization can be done by the plug-in.

Parameters:

AllowStart defines whether the acquisition is allowed to start or not. Its default value is True.

procedure OnBeforeStopAcq(var AllowStop: WordBool);

OnBeforeStopAcq is called before the acquisition is stopped.

Parameters:

AllowStop defines whether the acquisition is allowed to stop or not. Its default value is True.

procedure OnBigListLoad(const TextSetup: WideString);

OnBigListLoad is only for DEWESoft's internal use.

procedure OnExit;

OnExit is called by DEWESoft on closing.

procedure OnGetClock(var ClockLow: Integer; var ClockHigh: Integer);

At OnGetClock a clock can be provided to DEWESoft, if no AD-hardware is used.

Parameters:

ClockLow and ClockHigh are used because a 64-bit value is necessary to provide the time value.

procedure OnGetSetupData;

OnGetSetupData is similar to OnGetData, but will be called periodically when the setup screen is active. OnGetSetupData can be used for displaying acquired data during setup.

procedure OnRepaintFrame;

OnRepaintFrame is called 10 times per second and can be used to update some information displayed in the plug-in frame.

procedure OnResizeFrame(Width: Integer; Height: Integer);

OnResizeFrame allows to resize the setup frame of a plug-in according to the current size of the DEWESoft's setup screen.

Parameters:

Width is the width of the setup screen.

Height is the height of the setup screen.

procedure OnStartSetup;

OnStartSetup is called by DEWESoft on entering the setup screen.

procedure OnStopSetup;

OnStopSetup is called by DEWESoft on leaving the setup screen.

procedure OnTriggerStop(Time: Double; TrigDuration: Double);

OnStopTrigger is called by DEWESoft when the stop-trigger event happens.

Parameters:

Time is the timestamp when the stop-trigger happens.

TrigDuration is the duration of the trigger event.

procedure ProvidesClock(var Value: WordBool);

ProvidesClock sets whether the plug-in provides a clock to DEWESoft or not.

Parameters:

Value must be set to True if the plug-in provides a clock. The default value is False.

procedure SetCANPort(Port: Integer);

SetCANPort allows setting a CAN-port for using it for the plug-in.

7.32 IPluginGroup

7.32.1 Methods of IPluginGroup

procedure ClearAllChannels;

ClearAllChannels clears all mounted plug-in-channels.

function GetIndexName(Index: T_ChIndex): WideString;

GetIndexName returns the name of a channel index.

Parameters:

Index specifies the index of a channel which is of the type T_ChIndex. For detailed information on T_ChIndex please see 7.10.3 Types / Constants  of IChannel.

function MountChannel(DataType: Integer; Async: WordBool; DBSize: Integer): IChannel;

MountChannel mounts a channel to a certain group and returns the reference to a channel of the type IChannel.

Parameters:

DataType specifies the type of data the channel contains. This can be one of the following:

- 0...dtByte,
- 1...dtShortInt,
- 2...dtSmallInt,
- 3...dtWord,
- 4...dtInteger,
- 5...dtSingle,
- 6...dtInt64,
- 7...dtDouble.

Async defines whether the channel contains asynchronous or synchronous data. It has to be True if it is an asynchronous channel, otherwise False.

DBSize specifies the size of the direct buffer. If DBSize is set to -1, the default buffer size is applied.

procedure UnmountChannel(var Channel: IChannel);

UnmountChannel allows removing one channel separately.

7.32.2 Properties of IPluginGroup

property Count: Integer; (read-only)

Count is the number of mounted channels within the plug-in group.

property ExportRate: Integer;

ExportRate is the rate which is used for exporting asynchronous data to DIAdem.

property Item[Index: Integer]: IChannel; (read-only)

Item[Index] is one of the plug-in channels which is of the type IChannel.

property Name: WideString; (read-only)

Name is the name of a channel item within the plug-in group.

7.33 IScreen

7.33.1 Methods of IScreen

procedure Show;

To show one specific screen.

7.33.2 Properties of IScreen

property Id: Integer; (read-only)

Id is the identification number of a screen. A screen can be e.g. an “Overview”, a “Scope”, a “Recorder”, etc. Each of these categories can have more than one screen.

property IsCurrent: WordBool; (read-only);

IsCurrent is True if the screen is currently shown.

property Name: WideString; (read-only)

Name is the name of the screen how it appears at the buttons for selecting one of the screens. This can be e.g. “Overview”, “Overview 2”, “Scope”, etc.

7.34 IScreens

7.34.1 Properties of IScreens

property Count: Integer; (read-only)

Count is the number of screens. A screen can be e.g. an “Overview”, a “Scope”, a “Recorder”, etc. Each of these categories can have more than one screen

property Item[Index: Integer]: IScreen; (read-only)

Item[Index] is one of the screen items which is of the type IScreen.

7.35 IStoreEngine

7.35.1 Methods of IStoreEngine

procedure AddNewEvent(Type_: EventType; Data: OleVariant);

AddNewEvent adds an event during storing of data.

Parameters:

EventType defines the type of event to add. This can be etText (= \$00000015) or etKeyboard (= \$00000014).

Data is a String, if the EventType is set to etText.

7.35.2 Properties of IStoreEngine

property IsTriggering: WordBool; (read-only)

IsTriggering indicates whether the application is currently triggering. This corresponds to the state between a start- and a stop-trigger. E.g., if the storing option is set to “fast on trigger”, IsTriggering will be True while data is stored, otherwise False.

property FileSize: Largeuint; (read-only)

FileSize is the current size of the measurement file in bytes.

property StoreMode: Integer; (read-only)

StoreMode corresponds to the store options that can be set in the measurement setup See Figure 117. This mode can be set to one of the following values:

0... “always fast”

1... “always slow”

2... “fast on trigger”

3... “fast on trigger, slow otherwise”



Figure 117 Storing Options

property Storing: WordBool; (read-only)

Storing is true, if storing is currently in progress; false otherwise.

7.36 ITrig

7.36.1 Properties of ITrig

property NotOrList: ITriggerCondList; (read-only)

NotOrList provides a trigger condition list of the type ITriggerCondList. The trigger conditions of this list are equal to the “Don’t store” conditions as found in DEWESoft’s measurement setup.

property OrList: ITriggerCondList; (read-only)

OrList provides a trigger condition list of the type ITriggerCondList. The trigger conditions of this list are OR-combined.

property TrigIndex: Integer; (read-only)

TrigIndex is the Index of the condition in the OrList which caused the trigger.

7.37 ITrigger

7.37.1 Properties of ITrigger

property HoldoffTime: Single

HoldoffTime is the holdoff time in ms which is set for the trigger.

property HoldoffTimeUsed: WordBool;

HoldoffTimeUsed defines whether the holdoff time is used or not.

property PostTime: Single

PostTime is the post trigger time. (Cf. Figure 118)



Figure 118 Trigger Properties

property PostTimeUsed: WordBool

PostTimeUsed determines whether the PostTime will be used or not. (Cf. Figure 118)

property PostTimeExtensionUsed: WordBool

PostTimeExtensionUsed defines whether the post time extension is used or not.

property PreTime: Single

PreTime is the pre trigger time. (Cf. Figure 118)

property PreTimeUsed: WordBool

PreTimeUsed determines whether the PreTime will be used or not. (Cf. Figure 118)

property StartTrig: ITrig (read-only)

Start trigger

property StopTrig: ITrig (read-only)

Stop trigger

7.38 ITriggerCondition

7.38.1 Properties of ITriggerCondition

property Direction: Integer;

Direction defines the direction of a trigger condition. Valid values of this property are dependant on the Mode.

For modes 0,1,4,5:

- 0...positive
- 1...negative

2...any edge
For modes 2, 3:
0...enter
1...leave

property Level1: Single;

Level1 is the first trigger level. If only one of the trigger levels is available, this has to be assigned. So, it will be used in conjunction with any trigger mode if the trigger type is 0 (“on data”).

property Level2: Single;

Level2 is an additional trigger level which will be used in conjunction with the trigger modes tmFilteredEdge (1), tmWindow (2) and tmWindowPulsewidth (4), when the trigger type is 0 (“on data”).

property Mode: Integer;

Mode defines the trigger mode of the trigger condition, which can be one of the following:

0... tmSimpleEdge
1... tmFilteredEdge
2... tmWindow
3... tmPulsewidth
4... tmWindowPulsewidth
5... tmSlope

property TrigType: Integer;

TrigType defines the type of a trigger which can be one of the following:

0...on data
1...on time
2...on FFT

property TrigValue: Integer;

TrigValue determines which kind of value is used for the recognition of any trigger condition. This can be one of the following:

0...real data
1...average
2...RMS

7.39 ITriggerCondList

7.39.1 Properties of ITriggerCondList

property Count: Integer; (read-only)

Count is the number of trigger conditions within the trigger condition list.

property Item[Index: Integer]: ITriggerCondition; (read-only)

Item[] is an array of trigger conditions of the type ITriggerCondition. The index can be within the range of 0...Count-1.

7.39.2 Methods of ITriggerCondList

function Add: ITriggerCondition;

Add adds a trigger condition of the type ITriggerCondition to the list of trigger conditions.

procedure Remove(Ind: Integer);

Remove removes the trigger condition specified by the index Ind. Ind has to be within the range 0... Count-1.

7.40 IVideoLoadEngine

7.40.1 Methods of IVideoLoadEngine

procedure GetFramesInfo(out Frames: OleVariant);

GetFramesInfo gives information about the timestamps of the video-frames of one video file.

Parameters:

Frames is an OleVariant containing an array of timestamps of the type Double. The index of the array matches to the frame-index of the video file.

7.41 IVideoLoadEngines

7.41.1 Properties of IVideoLoadEngines

property Count: Integer; (read-only)

Count is the number of VideoLoadEngines which is equal to the number of videos captured.

property Item[Index: Integer]: IVideoLoadEngine; (read-only)

Item is one of the VideoLoadEngines which is of the type IVideoLoadEngine. The Index must be in the range 0...Count - 1.

8 DEWESoft DCOM Interface Tree




Figure 119 DEWESoft DCOM Interface Tree

9 DEWESoft DCOM Interface – Properties and Methods

-  ...Property
-  ...Method
-  ...Event
-  ...Constant
-  ...Enumeration
-  ...Type
- autom....Automation

Table 3 List of Properties and Methods

Type	Name		Access	Use only for	Description
IAISetupScreen					
	AISetupScreen.ShowChannelSetup	procedure ShowChannelSetup (ChNo: Integer);			To open the setup dialog of the channel ChNo.
	AISetupScreen.SetColumnVisible	procedure SetColumnVisible (ColNo: Integer; Visible: WordBool);			To show or hide column of the setup screen specified by ColNo. (only for analog channels)
IAlarms					
	Alarms.ActiveCount	ActiveCount: Integer;	read-only		ActiveCount is the number of alarm conditions which are currently active.
	Alarms.ActiveItem[]	ActiveItem[I: Integer]: IAlarmCond;	read-only		ActiveItem[I] is the active alarm condition at the index I. I is in the range of 0...ActiveCount-1. ActiveItem list is consistent only during measurement.
	Alarms.Count	Count: Integer;	read-only		Count is the number of alarm conditions which are set.
	Alarms.Item[]	Item[I: Integer]: IAlarmCond;	read-only		Item[I] is the alarm condition at index I. I is in the range of 0...Count-1.
IAlarmCond					
	AlarmCond.EndAlarm	procedure EndAlarm ;			EndAlarm can be called in order to stop an alarm having StopOption set to 1 (manual).
	AlarmCond.Index	Index: Integer;	read-only		Returns the Index of the alarm condition.
	AlarmCond.Name	Name: WideString	read-only		The name assigned to an alarm condition.

The DCOM Interface of DEWESoft 6.4 – DEWESoft DCOM Interface – Properties and Methods

	AlarmCond.Status	Status: WordBool	read-only		Status is true if an alarm condition is met and the alarm is currently still active.
	AlarmCond.StopOption	StopOption: Integer;			StopOption defines how and whether an alarm condition is stopped. This can be one of the following: 0...never 1...manual 2...on stop condition 3...on time
	AlarmCond.StopTime	StopTime: Single;			StopTime is the time after which an alarm is stopped if the StopOption is set to 3 (on time). The unit of StopTime is seconds.
	AlarmCond.StopTrigger	StopTrigger: ITrig;	read-only		StopTrigger is the combination of trigger conditions deactivating an alarm, if StopOption is set to 2.
	AlarmCond.Trigger	Trigger: ITrig;	read-only		Trigger is the combination of trigger conditions activating an alarm.
IAOChannel					
	AOChannel.Ampl	Ampl: Single	read/write		The amplitude of the output signal.
	AOChannel.FilterFreq1	FilterFreq1: Single	read/write		The first frequency of a filter.
	AOChannel.FilterFreq2	FilterFreq2: Single	read/write		The second frequency of a filter.
	AOChannel.FilterType	FilterType: Integer	read/write		The type of filter.
	AOChannel.FilterOrder	FilterOrder: Integer	read/write		The order of a low/band pass filter.
	AOChannel.FilterProtoType	FilterProtoType: Integer	read/write		The filter prototype.
	AOChannel.Offset	Offset: Single	read/write		The offset of the output signal.
	AOChannel.Phase	Phase: Single	read/write		The phase angle of the output signal.
	AOChannel.Range	Range: Integer	read/write		The voltage range of the analog output channel.
	AOChannel.WaveForm	WaveForm: AOWaveForm	read/write		The type of waveform to output. 0...Sine 1...Triangular 2...Rectangular 3...Saw 4...Noise 5...Arbitrary
IAOGroup					
	AOGroup.AmplChangeFactor	AmplChangeFactor: Single			The rate for amplitude changes. [V/s]

The DCOM Interface of DEWESoft 6.4 – DEWESoft DCOM Interface – Properties and Methods

	AOGroup.AOChannels	AOChannels: IChannelList	read-only		The list of analog output channels.
	AOGroup.ControlsClock	ControlsClock: WordBool	read-only		True, if the analog output-board is the master clock.
	AOGroup.DCChangeFactor	DCChangeFactor: Single			The rate for DC value changes. [V/s]
	AOGroup.DeltaFreq	DeltaFreq: Single			The frequency step-size for a “Step sweep” signal.
	AOGroup.Freq	Freq: Single			The frequency of a signal.
	AOGroup.FreqChangeFactor	FreqChangeFactor: Single			The rate for frequency changes. [Hz/s]
	AOGroup.LogSweep	LogSweep: WordBool			Logarithmic frequency change of a sweep.
	AOGroup.OperationMode	OperationMode: AOOperationMode			The mode of the function generator 0...Fixed Frequency 1...Sweep 2...Step sweep 3...Burst 4...Chirp
	AOGroup.PhaseChangeFactor	PhaseChangeFactor: Single			The rate for phase changes. [°/s]
	AOGroup.SampleRate	SampleRate: Integer			The sample rate for analog output.
	AOGroup.ShowInfoChannels	ShowInfoChannels: WordBool			Whether channels indicating “Ampl”, “Phase”, “Offset” and “Freq” should be available.
	AOGroup.StartFreq	StartFreq: Single			The start frequency of a signal.
	AOGroup.StartTime	StartTime: Single			The startup time of a waveform.
	AOGroup.StopFreq	StopFreq: Single			The end frequency of a signal.
	AOGroup.StopTime	StopTime: Single			The fall time of a waveform.
	AOGroup.SweepMode	SweepMode: AOSweepMode			Repeated or single output. 0...Loop 1...Single
IApp					
	App.ActiveScreen	ActiveScreen: Integer	read-only		Returns number of the active screen. This can be 0...“Overview”, 1... “Scope”, 2... “Recorder”, 3...”FFT”, 4...”Video”, 5...”GPS”, 6...”Vert. rec.”, 7...”Power”.
	App.Acquiring	Acquiring: WordBool	read-only		Whether DEWESoft is acquiring data.

The DCOM Interface of DEWESoft 6.4 – DEWESoft DCOM Interface – Properties and Methods

	App.ActualRunMode	ActualRunMode: Integer	read-only	Returns the actual run-mode which can be 0...none, 1...measure, 2...analyse.
	App.AISetupScreen	AISetupScreen: IAISetupScreen	read-only	See IAISetupScreen.
	App.Alarms	Alarms: IAlarms	read-only	See IAlarms
	App.AlwaysEnableTrigger	AlwaysEnableTrigger: WordBool	read/write	To show the Trigger tab in setup screen anyway.
	App.AOGroup	AOGroup: IAOGroup	read-only	See IAOGroup.
	App.AOGetManualAvail	function AOGetManualAvail: WordBool;		Whether the manual start/stop feature of analog output is available.
	App.AOSetManual	procedure AOSetManual;		To manually start or stop the AO.
	App.AveragedCPB	AveragedCPB: IAveragedFFT	read-only	See IAveragedFFT.
	App.CAN	CAN: ICAN	read-only	See ICAN.
	App.ChangeDaqType	procedure ChangeDaqType (DaqType: Integer);		Changes the device type for analog acquisition. 0...No A/D 1...Dewetron DAQ 2...Dewetron DSA 3...Spectrum 4...National Instruments 5...National Instruments MX 6...National Instruments DSA 7...Data Translation 8...Microstar DAP
	App.ChangeComPort	ChangeComPort (ComPort: Integer);		To change the com port being used for the modules. (0... com1; 1... com2;...)
	App.Data	Data: IData	read-only	Returns the Measurement Data; see IData.
	App.DataLost	DataLost: WordBool	read-only	Whether loss of data has occurred.
	App.DaqGroup	DaqGroup: IDaqGroup	read-only	The analog input group. See IDaqGroup.
	App.DisableStoring	DisableStoring: WordBool	read/write	To hide the Store button.
	App.Enabled	Enabled: WordBool	read/write	Whether DEWESoft is enabled or disabled.
	App.EventList	EventList: IEventList	read-only	Returns the list of events.

The DCOM Interface of DEWESoft 6.4 – DEWESoft DCOM Interface – Properties and Methods

	App.ExportData	procedure ExportData (ExportType: Integer; const FileName: WideString);			Call to export data of a certain type to a specified file. The ExportType can be: 0...Flexpro (*.fpd) 1...Excel (.xls) 2...DIAdem (*.dat) 3...Matlab (*.mat) 4...Universal File Format 58 (*.unv) 5...FAMOS (*.dat) 6...NSoft time series (*.dac) 7...Text (*.txt) 8...Sony (*.log) 9...RPCIII (*.rsp) 10...Comptade (*.cfg) FileName specifies the target-file path.
	App.FileNameSettings	FileNameSettings: IFileNameSettings	read-only		See IFileNameSettings.
	App.GetInterfaceVersion	procedure GetInterfaceVersion (var Major: Integer; var Minor: Integer; var Revision: Integer);			To find out the version number of DEWESoft's DCOM interface.
	App.HardwareSetup	procedure HardwareSetup (Plugins: WordBool);			Starting the dialog window of the hardware setup. When Plugins is set to true, the windows registry will be searched for plug-ins and all the plug-ins will be reinitialized, like on startup of DEWESoft.
	App.Height	Height: Long	read/write		Height of the application window expressed in pixels.
	App.IniFileDir	IniFileDir: String	read/write		Path of the ini-file directory.
	App.Init	procedure Init ;			To start the initialization of the application.
	App.IsSetupMode	IsSetupMode: WordBool	read-only		Whether DEWESoft is in setup mode or not.
	App.Left	Left: Integer	read/write		Left property of the application window expressed in pixels.
	App.LoadDBC	LoadDBC (PortNo: Integer; const FileName: WideString);			To load the DBC file FileName for the port specified by PortNo (first port is 0).
	App.LoadDisplaySetup	procedure LoadDisplaySetup (const FileName: WideString);			To load a display setup.
	App.LoadEngine	LoadEngine: ILoadEngine	read-only		See ILoadEngine.
	App.LoadFile	procedure LoadFile (const FileName: WideString);			To load a data file specified by FileName.

The DCOM Interface of DEWESoft 6.4 – DEWESoft DCOM Interface – Properties and Methods

	App.LoadModuleSetup	LoadModuleSetup(const FileName: WideString);			To load a DEWESoft setup for modules only.
	App.LoadSetup	procedure LoadSetup (const FileName: WideString);			To load a setup file specified by FileName.
	App.MainDataDir	MainDataDir: WideString	read-only		The path of the data directory.
	App.MainWndMessage	procedure MainWndMessage (Msg: Integer; WParam: Integer; Wait: WordBool);			This is the only allowed message to be called from any thread within a plug-in. If it is necessary to send a message to DEWESoft from an additional thread of a plug-in, MainWndMessage has to be used. “Msg” and “Param” will be available at “IPlugin2.OnOleMsg” which will follow. On this, the message has to be sent to DEWESoft from the main thread of the plug-in. “Wait” specifies whether the thread from which MainWndMessage was called will wait or continue execution.
	App.ManualStart	procedure ManualStart ;			To cause a manual start trigger.
	App.ManualStop	procedure ManualStop ;			To cause a manual stop trigger.
	App.MasterClock	MasterClock: IMasterClock	read-only		Returns the current time from the A/D-board in seconds before the data is transferred. (used for time-stamping asynchronous data)
	App.Measure	procedure Measure ;			To switch to measure mode.
	App.MeasureSampleRate	MeasureSampleRate: Integer	read/write		The sample rate for acquisition.
	App.MenuClick	procedure MenuClick (Item: MenuItem);			To cause a menu item to be clicked. See MenuItem.
	App.Modules	Modules: IModules	read-only		See IModules.
	App.NewSetup	procedure NewSetup ;			Equals to menu selection “File >> New Setup”
	App.OnAlarm	procedure OnAlarm ;		autom.	When an alarm occurs.
	App.OnDataLost	procedure OnDataLost ;		autom.	When data lost is reported by the DAQ object.

The DCOM Interface of DEWESoft 6.4 – DEWESoft DCOM Interface – Properties and Methods

	App.OnEvent	procedure OnEvent (Reason: EventReason; Param: OleVariant);		autom.	On several events specified by Reason which can be 1 indicating “start”, 2 indicating “stop”, 3 indicating “trigger”, 11 indicating “VStart” (video start storing) 12 indicating “VStop” (video stop storing) 20 indicating “Keyboard” 21 indicating “Notice” 22 indicating “Voice” 24 indicating “Module” (example: Bridge shunt on/off).
	App.OnException	procedure OnException (const Str: WideString);		autom.	When an exception occurs.
	App.OnExit	procedure OnExit ;		autom.	When DEWESoft is closed.
	App.OnGetData	procedure OnGetData ;		autom.	When new data is added to a channel. This happens every 40 ms.
	App.OnGetTime	procedure OnGetTime (var TimeLo: Integer; var TimeHi: Integer);		autom.	To provide a clock to DEWESoft, if no AD-hardware is used.
	App.OnStartStoring	procedure OnStartStoring ;		autom.	When the storing of data is started.
	App.OnStopStoring	procedure OnStopStoring ;		autom.	When the storing of data is stopped.
	App.OnTrigger	procedure OnTrigger (Mid: Integer; Dir: Integer; Time: Double);		autom.	When a trigger occurs. Returns: Mid...the number of the current data block, Dir...the position within the current data block and Time...the current time in seconds.
	App.OnTriggerStop	procedure OnTriggerStop (Mid: Integer; Dir: Integer; Time: Double);		autom.	When the stop trigger occurs.
	App.Parent	Parent : Integer	read/write	autom.	To reference the windows handle of a form as the DEWESoft parent.
	App.PauseStoring	procedure PauseStoring ;			To pause storing of data.
	App.PrintScreen	procedure PrintScreen (ShowDialog: WordBool);			To print the current screen.
	App.ResumeStoring	procedure ResumeStoring ;			To resume storing of data.
	App.SaveSetup	procedure SaveSetup (const FileName: WideString);			To save a channel setup to the file specified by FileName. (corresponds to File >> Save Setup)
	App.Screens	Screens As IScreens	read-only		See IScreens.

The DCOM Interface of DEWESoft 6.4 – DEWESoft DCOM Interface – Properties and Methods

	App.SendCommand	function SendCommand (const Cmd: WideString; Timeout: Integer): WideString;			To send a command to a hardware module via the (internal) module bus. Returns the answer of the device.
	App.SetFullScreen	procedure SetFullScreen (Full: WordBool);			To toggle between full screen display and standard display mode. (similar to pressing <CTRL> + <F>)
	App.SetHeaderData	procedure SetHeaderData (const Caption: WideString; const Header: WideString);			To set header information to a measurement file.
	App.SetInstrument	procedure SetInstrument (Id: Integer);			To set a screen. Id can be 0...“Overview”, 1... “Scope”, 2... “Recorder”, 3...”FFT”, 4...”Video”, 5...”GPS”, 6...”Vert. rec.”, 7...”Power”.
	App.SetMainDataDir	procedure SetMainDataDir (const DataDir: WideString);			For setting the main data dorectory used by DEWESoft.
	App.SetScopeParams	function SetScopeParams (PreTime: TDateTime; PostTime: TDateTime; const Channel: IChannel; Level: Single): Integer;			To set the pre- and the post-trigger time, the trigger channel and the trigger level of the scope. Returns the number of samples from the whole shot.
	App.SetScopeUsed	procedure SetScopeUsed (Value: WordBool);			To specify whether the scope trigger is used or not.
	App.SetScreenIndex	procedure SetScreenIndex (Index: Integer);			To set the screen index of active screen. (If more than one screen exists of any kind.)
	App.SetStoreMode	procedure SetStoreMode (Mode: Integer);			To set the storing option.
	App.SetupScreen	procedure SetupScreen ;			To switch to the setup screen.
	App.ShowPropertyFrame	ShowPropertyFrame : WordBool	read/write		To show or hide the property frame in measure mode.
	App.ShowSensorEditor	ShowSensorEditor ;			To open the sensor editor window.
	App.ShowSROptions	ShowSROptions : WordBool	read/write		To show or hide the sample rate options in measure mode.
	App.ShowStoreOptions	ShowStoreOptions : WordBool	read/write		To show or hide the store options in measure mode.

The DCOM Interface of DEWESoft 6.4 – DEWESoft DCOM Interface – Properties and Methods

	App.ShowStyle	ShowStyle: Integer	read/write		To change the appearance of the menu bar. 0...hides the whole menu bar (hides menu and buttons), 1...shows the menu bar but hides the drop-down menu bar (shows only buttons), 2... shows the menu bar including the drop-down menu bar (shows menu and buttons).
	App.StartModuleScan	procedure StartModuleScan ;			To (re)start scanning of the module.
	App.StartStoring	procedure StartStoring (const FileName: WideString);			To start storing. FileName is the path to the target data file. If FileName is empty, then the settings of DEWESoft are used.
	App.StayOnTop	StayOnTop: WordBool	read/write		Set whether the application window should stay on top or not.
	App.Stop	procedure Stop ;			To stop the application. Goes to stop-screen. (cf. stop-button)
	App.StopModuleScan	procedure StopModuleScan ;			To stop the scanning of the modules.
	App.StoreEngine	StoreEngine: IStoreEngine	read-only		See IStoreEngine.
	App.TimerInterval	TimerInterval: Integer	read/write		The timer interval for DEWESoft acquisition in ms. The default is 33.
	App.Top	Top: Integer	read/write		The top property of the application window expressed in pixels.
	App.Trigger	Trigger: ITrigger;	read-only		See ITrigger.
	App.UpdateHardwareSetup	procedure UpdateHardwareSetup ;			Has to be called after changes within the hardware setup. See App.HardwareSetup().
	App.UsedDatafile	UsedDatafile: WideString	read/write		The data file path to use.
	App.UsedSetupfile	UsedSetupfile: WideString	read-only		The currently used setup file.
	App.Version	Version: WideString	read-only		Returns the version number of the application.
	App.Visible	Visible: WordBool	read/write		Whether the application should be visible or not.
	App.Width	Width: Integer	read/write		The width of the application window expressed in pixels.
	App.WriteErrorMessage	procedure WriteErrorMessage (const ErrorMsg: WideString);			To write error messages to the caption of DEWESoft.
	App.ZeroAllAutoChannels	procedure ZeroAllAutoChannels (Zero: WordBool);			To zero all DaqChannels having AutoZero set to True. Zero determines whether the offset will be set or cleared.
IAveragedFFT					
	IAveragedFFT.AveCount	AveCount: Integer	read/write		The number of averages for FFT/CPB calculation.

The DCOM Interface of DEWESoft 6.4 – DEWESoft DCOM Interface – Properties and Methods

	IAveragedFFT.AverageType	AverageType: Integer	read/write		The averaging type for FFT/CPB calculation.
	IAveragedFFT.CalculateFromPos	function CalculateFromPos (Mid: Integer; Dir: Integer): WordBool;			For performing the FFT/CPB calculation from the defined start position.
	IAveragedFFT.GetChannels	procedure GetChannels (Channels: OleVariant);			Provides a list of all channels used in AveragedFFT.
	IAveragedFFT.GetData	procedure GetData (ChNo: Integer; OctaveDivider: Integer; Weighting: Integer; out BandCount: Integer; out Data: OleVariant);			To retrieve the calculated FFT/CPB data.
	IAveragedFFT.Lines	Lines: Integer	read/write		The number of FFT lines.
	IAveragedFFT.Overlap	Overlap: Integer	read/write		The amount of overlap for averaging in percent.
	IAveragedFFT.Window	Window: Integer	read/write		The window type for averaging.
ICAN					
	CAN.SupportsOutput	SupportsOutput: WordBool	read-only		Whether output is supported.
	CAN.Count	Count: Integer	read-only		The number of available CAN ports.
	CAN.Item	Item [Index: Integer]: ICANPort	read-only		See ICANPort.
ICANPort					
	CANPort.EnableOutput	procedure EnableOutput (Enable: WordBool);			Enable CANPort for output.
	CANPort.EndRead	procedure EndRead ;			Must be called after reading of CAN data.
	CANPort.GetBaudRate	function GetBaudRate: Integer;			Returns the Baud rate of a CAN-port.
	CANPort.GetBaudRateList	function GetBaudRateList: OleVariant;			Returns an array of Strings of available Baud rates.
	CANPort.MessageCount	MessageCount: Integer	read-only		The number of messages available.
	CANPort.ReadMessage	function ReadMessage (var TimeStamp: Double; var ArbId: Integer; var DataLo: Integer; var DataHi: Integer): WordBool;			Read a message from the CAN-port
	CANPort.SendFrame	function SendFrame (Extended: WordBool; ArbId: Integer; Data: T_CANFrame; Size: Integer): WordBool;			Send a message on the CAN port.
	CANPort.SetBaudRate	procedure SetBaudRate (BaudRate: Integer);			Sets the Baud rate of a CAN-port.
	CANPort.StartRead	procedure StartRead ;			Must be called after reading of CAN data.
ConnTypes 					
	ConnTypes.ctLast	Const ctLast = 0			See IChannelConnection.AType.
	ConnTypes.ctOverlap	Const ctOverlap = 1			See IChannelConnection.AType.
	ConnTypes.ctTrigger	Const ctTrigger = 2			See IChannelConnection.AType.
	ConnTypes.ctNew	Const ctNew = 3			See IChannelConnection.AType.

The DCOM Interface of DEWESoft 6.4 – DEWESoft DCOM Interface – Properties and Methods

ExportTypes					
	ExportTypes.etChannelBased	Const etChannelBased = 1			Export type for exporting each channel after the other. (all data of one channel before all data of the next channel)
	ExportTypes.etValueBased	Const etValueBased = 0			Export type for exporting each value after the other. (one sample of each channel before next sample of each channel)
IChannel					
	Channel.AddAsyncByteSample	procedure AddAsyncByteSample (Value: Byte; TimeStamp: Double);			Called for adding asynchronous samples of the type byte.
	Channel.AddAsyncDoubleSample	procedure AddAsyncDoubleSample (Value: Double; TimeStamp: Double);			Called for adding asynchronous samples of the type Double.
	Channel.AddAsyncSingleSample	procedure AddAsyncSingleSample (Value: Single; TimeStamp: Double);			Called for adding asynchronous samples of the type Single.
	Channel.AddSingleSample	procedure AddSingleSample (Value: Single);			Called for adding synchronous samples of the type Single.
	Channel.AddSingleSamples	procedure AddSingleSamples (Count: Integer; Data: OleVariant; Timestamps: OleVariant);			Called for adding multiple synchronous samples of the type Single.
	Channel.Async	Async : WordBool	read-only		Whether a channel is asynchronous or not.
	Channel.Bytes	Bytes : Integer	read-only		The number of bytes used for one data sample (depending on the data type).
	Channel.CreateConnection	function CreateConnection : IChannelConnection;			To create a connection to a channel to access its data. See IChannelConnection.
	Channel.DataType	DataType : Integer	read-only		The data type, e.g. Single, Double, etc.
	Channel.DBBufSize	DBBufSize : Integer	read-only		The size of the direct buffer.
	Channel.DBDataSize	DBDataSize : Integer	read-only		The size of the data stored in the direct buffer.
	Channel.DBPos	DBPos : Integer	read-only		The next position in the direct buffer to be written to.
	Channel.DBTimeStamp	DBTimeStamp [Index: Integer]: Double	read-only		The time stamp data of asynchronous data in the direct buffer.
	Channel.DBValues	DBValues [Index: Integer]: Single	read-only		The data values within the direct buffer.
	Channel.Description	Description : WideString	read/write		The description of a channel.
	Channel.ExportOrder	property ExportOrder : Integer	read/write		The order of the channels for exporting.
	Channel.GetDBAddress	function GetDBAddress : Integer;			Returns the pointer of the next position in direct buffer to be written to.

The DCOM Interface of DEWESoft 6.4 – DEWESoft DCOM Interface – Properties and Methods

	Channel.GetIBValues	procedure GetIBValues (Pos: Integer; out Min: Single; out Max: Single; out Ave: Single; out Rms: Single);			Similar to reading the property IChannel.IBValues. The property IBValues cannot be read by LabVIEW. So this procedure can be used instead.
	Channel.GetIndex1	procedure GetIndex1 (out IndexLevel: Integer; out I1: Integer; out I2: Integer; out I3: Integer; out I4: Integer; out I5: Integer);			Similar to reading the property IChannel.Index. The property Index cannot be read by LabVIEW, so this procedure can be used instead.
	Channel.GetRBValues	procedure GetRBValues (Pos: Integer; out Min: Single; out Max: Single; out Ave: Single; out Rms: Single);			Similar to reading the property IChannel.RBValues. The property RBValues cannot be read by LabVIEW. So this procedure can be used instead.
	Channel.GetScaledData	function GetScaledData : OleVariant;			Returns scaled data from the circular buffer. (The data type of scaled data is always “Single”)
	Channel.GetScaledDataEx	function GetScaledDataEx (Start: Integer; Count: Integer): OleVariant;			Returns scaled data from the direct buffer which is already linearized.
	Channel.GetScaledDataEx1	procedure GetScaledDataEx1 (Start: Integer; Count: Integer; out Data: OleVariant);			Same as above implemented as a procedure.
	Channel.GetTSDData	function GetTSDData : OleVariant;			Returns the time stamp data.
	Channel.GetTSDDataEx	function GetTSDDataEx (Start: Integer; Count: Integer): OleVariant;			Returns a certain amount of the time stamp data, specified by Count, from a certain position, specified by Start.
	Channel.GetTSDDataEx1	procedure GetTSDDataEx1 (Start: Integer; Count: Integer; out Data: OleVariant);			Same as above implemented as a procedure.
	Channel.GetUnscaledData	function GetUnscaledData : OleVariant;			Returns unscaled data from the circular buffer.
	Channel.GetUnscaledDataEx	function GetUnscaledDataEx (Start: Integer; Count: Integer): OleVariant;			Returns unscaled data from the direct buffer, which is already linearized.
	Channel.GetUnscaledDataEx1	procedure GetUnscaledDataEx1 (Start: Integer; Count: Integer; out Data: OleVariant);			Same as above implemented as a procedure.
	Channel.Group	Group : IChannelGroup	read-only		A group containing the channels. (Channels of a plug-in have to be mounted to the group 8)
	Channel.IBBufSize	IBBufSize : Integer	read-only		The size of the intermediate buffer.
	Channel.IBDataSize	IBDataSize : Integer	read-only		The size of the data within the intermediate buffer.
	Channel.IBPos	IBPos : Integer	read-only		The next position in the intermediate buffer to be written to.

The DCOM Interface of DEWESoft 6.4 – DEWESoft DCOM Interface – Properties and Methods

	Channel.IBValues	IBValues [Index: Integer]: T_ReducedRec	read-only		The data values within the intermediate buffer. (Min, Max, Ave and RMS)
	Channel.IncDBSamples	procedure IncDBSamples (Count: Integer);			To increment the direct buffer position by a certain amount of samples.
	Channel.Index	Index : T_ChIndex	read-only		See T_ChIndex and Table 2
	Channel.MainDisplayColor	MainDisplayColor : Int64	read/write		Specifies the color of a channel.
	Channel.Measurement	Measurement : WideString	read/write		The description of a channel. Equal to “Description”.
	Channel.Name	Name : WideString	read/write		The name of a channel.
	Channel.Offset	Offset : Double	read/write		The offset value of a channel.
	Channel.RBBufSize	RBBufSize : Integer	read-only		The size of the reduced buffer.
	Channel.RBDataSize	RBDataSize : Integer	read-only		The size of the data within the reduced buffer.
	Channel.RBPos	RBPos : Integer	read-only		The next position in the reduced buffer to be written to.
	Channel.RBValues	RBValues [Index: Integer]: T_ReducedRec	read-only		The data values within the reduced buffer. (Min, Max, Ave and RMS).
	Channel.Scale	Scale : Double;	read/write		The scaling value of a channel.
	Channel.ScaleValue	function ScaleValue (Value: Single): Single;			To scale an unscaled value.
	Channel.SetSRDiv	procedure SetSRDiv (SRDiv: Integer);			To set the sample rate divider.
	Channel.SetSRDivType	procedure SetSRDivType (AType: T_SRDivType);			To set the type of sample rate divider.
	Channel.Shown	Shown : WordBool	read/write		If it is possible to show a channel.
	Channel.SRDiv	SRDiv : Integer	read-only		The sample rate divider of a channel.
	Channel.TypicalMaxValue	TypicalMaxValue : Single	read-only		Maximum value of the y-axis of a graph.
	Channel.TypicalMinValue	TypicalMinValue : Single	read-only		Minimum value of the y-axis of a graph.
	Channel.Unit	Unit : WideString	read/write		The unit assigned to a channel.
	Channel.Used	Used : WordBool	read/write		Whether a channel is used or not.
	Channel.UserScaleMax	UserScaleMax : Single	read/write		User defined maximum value of the y-axis.
	Channel.UserScaleMin	UserScaleMin : Single	read/write		User defined minimum value of the y-axis.

IChannelConnection					
	ChannelConnection.AType	AType: ConnTypes	read/write		The type of IChannelConnection can be ctLast... for reading a certain amount (specified by “BlockSize”) of the last data; ctOverlap... for reading blocks (size specified by “BlockSize”) of data; The percentage of an overlap of the data blocks can be specified by Overlap; ctTrigger... for reading the data which is displayed in the Scope-screen on triggers (Before, the trigger has to be set up manually. Setting up the trigger via a plug-in will be possible in future.); ctNew... for reading a certain amount (specified by “BlockSize” or “NumValues”) of the last data, but only if such an amount of new data (not read yet) is available;
	ChannelConnection.BlockSize	BlockSize: Integer	read/write		The size of the data block(s) to read.
	ChannelConnection.Channel	Channel As IChannel	read-only		See IChannel.
	ChannelConnection.GetDataBlocks	function GetDataBlocks (NumBlocks: Integer): OleVariant;			Returns the amount of data blocks specified by “NumBlocks”.
	ChannelConnection.GetDataBlocks1	procedure GetDataBlocks1 (NumBlocks: Integer; out Data: OleVariant);			Same as above implemented as a procedure.
	ChannelConnection.GetDataValues	function GetDataValues (NumValues: Integer): OleVariant;			Returns a certain amount (specified by “NumValues”) of data starting at the position where data has not been read yet.
	ChannelConnection.GetDataValues1	procedure GetDataValues1 (NumValues: Integer; out Data: OleVariant);			Same as above implemented as a procedure.
	ChannelConnection.NumBlocks	NumBlocks: Integer	read-only		The number of available blocks of the size specified by “BlockSize” not read yet.
	ChannelConnection.NumValues	NumValues: Integer	read-only		The number of values not read yet.
	ChannelConnection.Overlap	Overlap: Integer	read/write		The percentage of how much the data blocks to read overlap each other.
	ChannelConnection.Reset	procedure Reset ;			To reset a ChannelConnection to a certain moment. (Sets back “NumValues” to 0.)
	ChannelConnection.Start	procedure Start ;			Sets the ChannelConnection to the start of the acquisition.

The DCOM Interface of DEWESoft 6.4 – DEWESoft DCOM Interface – Properties and Methods

	ChannelConnection.GetTSBlocks	function GetTSBlocks (NumBlocks: Integer): OleVariant;			Returns the amount of timestamp blocks specified by “NumBlocks”.
	ChannelConnection.GetTSBlocks1	procedure GetTSBlocks1 (NumBlocks: Integer; out Data: OleVariant);			Same as above implemented as a procedure.
	ChannelConnection.GetTSValues	function GetTSValues (NumValues: Integer): OleVariant;			Returns a certain amount (specified by “NumValues”) of timestamps starting at the position where timestamp data has not been read yet.
	ChannelConnection.GetTSValues1	procedure GetTSValues1 (NumValues: Integer; out Data: OleVariant);			Same functionality as above, but implemented as a procedure.
IChannelGroup					
	ChannelGroup.Count	Count: Integer	read-only		The number of channels in a group.
	ChannelGroup.ExportRate	ExportRate: Integer	read/write		Sample rate for exporting asynchronous data to DIAdem. (can be set for each group type separately)
	ChannelGroup.GetIndexName	function GetIndexName (Index: T_ChIndex): WideString;			Returns the name of the ChannelGroup specified by Index.
	ChannelGroup.Item	Item [Index: Integer]: IChannel;	read-only		The items of a group (These items are the channels of the type IChannel).
	ChannelGroup.Name	Name: WideString	read-only		The name of a group.
IChannelGroup2 (includes the properties and methods of IChannelGroup)					
	ChannelGroup2.GetIndexNameShort	function GetIndexName (Index: T_ChIndex): WideString;			Returns the name of the index in an abbreviated version.
IChannelGroups					
	ChannelGroups.Count	Count: Integer	read-only		The number of channel groups.
	ChannelGroups.Item	Item (Index As Long) As IChannelGroup	read-only		The group items (These items are of the type IChannelGroup, containing the channels of the type IChannel).
IChannelList					
	ChannelList.Count	Count: Integer	read-only		The number of channels within a channel list.
	ChannelList.Item	Item [Index: Integer]: IChannel	read-only		One of the channels within the channel list.
ICustomExport					
	CustomExport.AbsoluteTime	AbsoluteTime: WordBool		Custom Export	Whether the absolute or relative time data is exported.
	CustomExport.DataCount	DataCount: Largeuint		Custom Export	The number of samples of a channel.
	CustomExport.EndChannel	function EndChannel: HRESULT;		Custom Export	Ends the export of a channel. (ExportType = etChannelBased)

The DCOM Interface of DEWESoft 6.4 – DEWESoft DCOM Interface – Properties and Methods

	CustomExport.EndDataFolder	function EndDataFolder : HRESULT;		Custom Export	Ends a data folder.
	CustomExport.EndExport	function EndExport : HRESULT;		Custom Export	Ends the export.
	CustomExport.EndHeader	function EndHeader : HRESULT;		Custom Export	Ends the export of the header information.
	CustomExport.EndInfo	function EndInfo : HRESULT;		Custom Export	Ends the export of general information.
	CustomExport.EndValue	function EndValue : HRESULT;		Custom Export	Ends the export of one value of each channel. (ExportType = etValueBased)
	CustomExport.ExportType	ExportType : ExportTypes	read-only	Custom Export	Whether the export will be performed value- or channel-based. (etValueBased = 0; etChannelBased = 1)
	CustomExport.Extension	Extension : WideString	read-only	Custom Export	The file extension for the export file.
	CustomExport.FileName	FileName : WideString		Custom Export	The name of the export file.
	CustomExport.StartAbsValue	function StartAbsValue (DateTime: TDateTime): HRESULT;		Custom Export	Starts the export of one absolute value of eachchannel. (ExportType = etValueBased; absolute time axis)
	CustomExport.StartChannel	function StartChannel (const FieldName: WideString; const FieldUnit: WideString; Async: WordBool): HRESULT;		Custom Export	Starts the export of one channel. (ExportType = etChannelBased)
	CustomExport.StartDataField	function StartDataField (const FieldName: WideString; const FieldUnit: WideString; ExportRate: Integer): HRESULT;		Custom Export	Exporting the name, the unit and the rate for each channel.
	CustomExport.StartDataFolder	function StartDataFolder (const FolderName: WideString; AbsTime: TDateTime): HRESULT;		Custom Export	Exporting the name and the absolute start time of a data folder at the beginning of the export of a data folder.
	CustomExport.StartExport	function StartExport (const App: IApp): HRESULT;		Custom Export	Initializing the export.
	CustomExport.StartInfo	function StartInfo (const Info: WideString): HRESULT;		Custom Export	Start of exporting general information.
	CustomExportStartTimeField	function StartTimeField (const FieldName: WideString; const FieldUnit: WideString): HRESULT;		Custom Export	Exports the name and the unit of the time channel.
	CustomExport.StartValue	function StartValue (TimeValue: Double): HRESULT;		Custom Export	Starts the export of one value of each channel. (ExportType = etValueBased; relative time axis)

The DCOM Interface of DEWESoft 6.4 – DEWESoft DCOM Interface – Properties and Methods

	CustomExport.SupportsAsync	SupportsAsync: WordBool	read-only	Custom Export	Whether export of asynchronous data is supported or not.
	CustomExport.SupportsSRDiv	SupportsSRDiv: WordBool	read-only	Custom Export	Whether sample rate dividers are supported or not.
	CustomExport.TimeIncrease	TimeIncrease: Double	read/write	Custom Export	The interval between two subsequent values of synchronous data.
	CustomExport.WriteAsyncValue	function WriteAsyncValue (TimeStamp: Double; Value: Single): HRESULT;		Custom Export	Export of one asynchronous value. (ExportType = etChannelBased)
	CustomExport.WriteInfoDate	function WriteInfoDate (const Description: WideString; Value: TDateTime): HRESULT;		Custom Export	Exports date information to the header of the export file.
	CustomExport.WriteInfoInteger	function WriteInfoInteger (const Description: WideString; Param: Integer): HRESULT;		Custom Export	Exports Integer data to the header of the export file.
	CustomExport.WriteInfoSingle	function WriteInfoSingle (const Description: WideString; Value: Single): HRESULT;		Custom Export	Exports Single data to the header of the export file.
	CustomExport.WriteInfoString	function WriteInfoString (const Description: WideString; const Value: WideString): HRESULT;		Custom Export	Exports String data to the header of the export file.
	CustomExport.WriteValue	function WriteValue (Value: Single): HRESULT;		Custom Export	Exports one value. (ExportType = etValueBased, or for synchronous values when ExportType = etChannelBased)
ICustomExport2					
	CustomExport2.GetDWTypeLibVersion	function GetDWTypeLibVersion (out Value: Integer): HRESULT;		Custom Export	The DEWESoft type library version (DEWESoftMinorVersion) should be returned.
	CustomExport2.Get_SupportsDouble	function Get_SupportsDouble (out Value: WordBool): HRESULT;		Custom Export	Whether the export supports values of the type Double.
	CustomExport2.SetAbsMax	function SetAbsMax (AbsMax: Single): HRESULT;		Custom Export	Sets the absolute maximum value of a channel.
	CustomExport2.SetAbsMin	function SetAbsMin (AbsMin: Single): HRESULT;		Custom Export	Sets the absolute minimum value of a channel.
	CustomExport2.SetApp	function SetApp (const App: IApp): HRESULT;		Custom Export	Provides a reference to IApp.
	CustomExport2.SetChannel	function SetChannel (const Ch: IChannel): HRESULT;		Custom Export	Provides a reference to IChannel.
	CustomExport2.SetChannelColor	function SetChannelColor (Color: Integer): HRESULT;		Custom Export	Sets the color of the channel.
	CustomExport2.SetDoubleFloat	function SetDoubleFloat (DoubleFloat: WordBool): HRESULT;		Custom Export	Sets whether a channel contains data of the type Double.

The DCOM Interface of DEWESoft 6.4 – DEWESoft DCOM Interface – Properties and Methods

	CustomExport2.SetRangeMax	function SetRangeMax (Value: Single): HRESULT;		Custom Export	Sets the maximum measurement range.
	CustomExport2.SetRangeMin	function SetRangeMin (Value: Single): HRESULT;		Custom Export	Sets the minimum measurement range.
	CustomExport2.SetTrigOffset	function SetTrigOffset (TrigTime: Double): HRESULT;		Custom Export	Sets the pretrigger time of a trigger.
	CustomExport2.StartEvents	function StartEvents : HRESULT;		Custom Export	Indicates the start of writing the events.
	CustomExport2.StopEvents	function StopEvents : HRESULT;		Custom Export	Indicates the end of writing the events.
	CustomExport2.WriteAsyncDoubleValue	function WriteAsyncDoubleValue (TimeStamp: Double; Value: Double): HRESULT;		Custom Export	Writes an asynchronous value of the type Double.
	CustomExport2.WriteDoubleValue	function WriteDoubleValue (Value: Double): HRESULT;		Custom Export	Writes a synchronous value of the type Double.
	CustomExport2.WriteEvent	function WriteEvent (EventType: Integer; const EventTypeString: WideString; Time: Double; const Comment: WideString): HRESULT;		Custom Export	Writes an event.
IDaqChannel					
	DaqChannel.AutoZero	AutoZero : WordBool;	read/write		Whether zeroing of a channel is set to automatic.
	DaqChannel.CardBitResolution	CardBitResolution : Integer	read-only		The resolution of the DAQ card in bits.
	DaqChannel.CardGain	CardGain : Double;	read-only		The gain value set at a DAQ card.
	DaqChannel.CardOffset	CardOffset : Double;	read-only		The offset value set at a DQ card.
	DaqChannel.ModuleGain	ModuleGain : Double;	read-only		The gain value set at a module.
	DaqChannel.ModuleOffset	ModuleOffset : Double;	read-only		The offset value set at a module.
	DaqChannel.ModuleType	ModuleType : Double;	read-only		The type number of a module.
	DaqChannel.SetCardGain	procedure SetCardGain (Gain: Single);			To set the gain of the DAQ card.
IDaqData					
	DaqData.Address	Address : Smallint			The address of a DAQ-module.
	DaqData.CopyToString	function CopyToString : WideString;			Copies the module parameters to a string.
	DaqData.CopyUnitToString	function CopyUnitToString : WideString;			Copies the unit of measurement to a string.
	DaqData.CurrentSource	CurrentSource : Byte;			The type of current source of ACC modules. 0...4mA 1...8mA
	DaqData.DaqNNames	DaqNNames [ANameCode: Smallint]: WideString	read-only		The name of the DAQN-module.
	DaqData.DaqNNamesCount	DaqNNamesCount : Integer	read-only		The number of available DAQN-modules

The DCOM Interface of DEWESoft 6.4 – DEWESoft DCOM Interface – Properties and Methods

	DaqData.Filters	Filters [AFilterCode: Byte]: WideString	read-only		The name of a filter.
	DaqData.FilterCode	FilterCode : Byte			The filter of a DAQ-module.
	DaqData.FiltersCount	FiltersCount : Integer	read-only		The number of available filters.
	DaqData.FREQAInputCoupling	FREQAInputCoupling : Shortint			The input coupling type of a FREQ-A-module. 0...AC 1...DC
	DaqData.FREQAOutputFilter	FREQAOutputFilter : Shortint			The output filter type of a FREQ-A-module. 0...slow 1...fast
	DaqData.FREQATriggerLevel	FREQATriggerLevel : Single			The trigger level of a FREQ-A-module.
	DaqData.HighpassType	HighpassType : Byte			The highpass-filter at a DAQ-module.
	DaqData.ICPInput	ICPInput : Byte			Whether a charge-module is set to ICP or charge.
	DaqData.ModuleAmpl	function ModuleAmpl : Single;			Returns the module scale factor.
	DaqData.ModuleError	ModuleError : Byte	read-only		The error code of a module.
	DaqData.ModuleOffset	function ModuleOffset : Single;	read-only		Returns the module offset.
	DaqData.ModuleType	ModuleType : Smallint			The type of a module. 2... DAQP-Bridge 5... DAQP-Charge 8... DAQP-Freq 9... DAQP-Acc 23... DAQP-Charge-A 24... DAQP-Bridge-A 26... DAQP-Freq-A 27... DAQP-ACC-A 30... DAQP-Charge-B 31... DAQP-Bridge-B 34... DAQP-V-A 35... DAQP-V-B 36... MDAQ
	DaqData.Name	Name : WideString	read-only		The name of a module.
	DaqData.Overflow	Overflow : Byte			If an overflow has occurred it will be 1.
	DaqData.RangeCode	RangeCode : Byte			The code defining the range of a module.
	DaqData.Ranges	Ranges [ARangeCode: Integer]: WideString	read-only		The range settings according to the range code.
	DaqData.RangesCount	RangesCount : Integer	read-only		The number of valid ranges of a module.
	DaqData.Remote	Remote : Byte			Whether the module is set to remote mode.
	DaqData.ShortCopyToString	function ShortCopyToString : WideString;			Copies the module parameters to a string.

The DCOM Interface of DEWESoft 6.4 – DEWESoft DCOM Interface – Properties and Methods

	DaqData.ThermLinearize	function ThermLinearize (InputVoltage: Double): Double;			Calculates the thermal linearized value of the input voltage
	DaqData.VRange	VRange : Byte			Is only used with DAQP-FREQ-module to indicate the trigger voltage input range.
IDaqGroup					
	DaqGroup.Count	Count : Integer	read-only		The number of channels within DaqGroup.
	DaqGroup.Item	Item [Index: Integer]: IDaqChannel	read-only		The list of items of the type IDaqChannel within DaqGroup.
IData					
	Data.ActiveChannels	ActiveChannels : IChannelList	read-only		All channels available according to the hardware setup. (only for internal use)
	Data.AllChannels	AllChannels : IChannelList	read-only		All channels available according to the hardware setup.
	Data.ApplyChannels	procedure ApplyChannels ;			Has to be called after channels of a plug-in are mounted by any user-action.
	Data.BuildChannelList	procedure BuildChannelList ;			To update the properties AllChannels and UsedChannels.
	Data.CurrentPos	CurrentPos : T_RecordPosition	read/write		Used in analyze mode; (corresponds to the yellow line)
	Data.EndDataSync	procedure EndDataSync ;			Used together with StartDataSync and IChannelConnection for synchronous manipulation of multiple channels.
	Data.EndStamp	EndStamp : T_RecordPosition	read/write		Last possible position of the cursor.
	Data.ExternalClock	ExternalClock As Long	read-only		Returns the external clock definition in clocks per revolution.
	Data.FindChannel	function FindChannel (const Name: WideString): IChannel;			To find a channel by its name (Must be the exact name; function is case-sensitive).
	Data.FindChannelByIndex	function FindChannelByIndex (Index: T_ChIndex): IChannel;			To find a channel by its indexes.
	Data.FindChannelByIndex1	function FindChannelByIndex1 (IndexLevel: Integer; I1: Integer; I2: Integer; I3: Integer; I4: Integer; I5: Integer): IChannel;			To find a channel by its indexes. This function is similar to IData.FindChannelByIndex. It is implemented because FindChannelByIndex does not work in conjunction with LabVIEW.
	Data.GetIndexName	function GetIndexName (Index: T_ChIndex): WideString;			Returns the identifier of a certain index.

The DCOM Interface of DEWESoft 6.4 – DEWESoft DCOM Interface – Properties and Methods

	Data.GetIndexName1	function GetIndexName1 (IndexLevel: Integer; I1: Integer; I2: Integer; I3: Integer; I4: Integer; I5: Integer): WideString;			Returns the identifier of a certain index. This function is similar to IData.GetIndexName. GetIndexName1 is implemented because GetIndexName dose not work in conjunction with LabVIEW.
	Data.GetIndexNameShort	function GetIndexNameShort (ChIndex: T_ChIndex): WideString;			Returns the short identifier of a certain index.
	Data.GetIndexNameShort1	function GetIndexNameShort1 (IndexLevel: Integer; I1: Integer; I2: Integer; I3: Integer; I4: Integer; I5: Integer): WideString;			Returns the short identifier of a certain index. This function is similar to IData.GetIndexNameShort. GetIndexName1 is implemented because GetIndexNameShort dose not work in conjunction with LabVIEW.
	Data.GetSamplesAcquired	procedure GetSamplesAcquired (out Mid: Integer; out Dir: Integer);			Called to get information about the amount of acquired data.
	Data.Groups	Groups: IChannelGroups	read-only		The groups to which data is dedicated. E.g. the data group for plug-in data is 8.
	Data.SampleRate	SampleRate: Integer	read-only		The sampling rate; not depending on the factor of the “reduced rate”.
	Data.Samples	Samples: Integer	read-only		The number of samples within a data block.
	Data.ShownChannels	ShownChannels: IChannelList	read-only		The list of channels which can be shown (e.g. CAN-bus messages cannot be shown).
	Data.StartDataSync	procedure StartDataSync ;			Used together with EndDataSync and IChannelConnection for synchronous manipulation of multiple channels.
	Data.StartStamp	StartStamp: T_RecordPosition	read/write		First possible position of the cursor.
	Data.StartStoreTime	StartStoreTime: TDateTime	read-only		Absolute time of the start of storing.
	Data.StartStoreTimeUTC	StartStoreTime: TDateTime	read-only		Absolute UTC of the start of storing.
	Data.UsedChannels	UsedChannels: IChannelList	read-only		A list of the channels which are set to used.
IDataSection					
	DataSection.DataCount	DataCount: Integer	read-only		The number of samples within a DataSection.
	DataSection.ReadData	function ReadData (const Channel: IChannel; out Timestamps: OleVariant): OleVariant;			Reading the whole data of a section (part between a start and a stop event), independent of the data blocks.
	DataSection.ReadData1	procedure ReadData1 (const Channel: IChannel; out Data: OleVariant; out Timestamps: OleVariant);			Same as above implemented as a procedure.
	DataSection.Time	Time: TDateTime	read-only		Absolute start time of a section.

The DCOM Interface of DEWESoft 6.4 – DEWESoft DCOM Interface – Properties and Methods

	DataSection.TrigPos	TrigPos: Integer	read-only		The sample position of the trigger event within a section, counted from the start of the section.
IDataSections					
	DataSections.Count	Count: Integer	read-only		The number of sections where data is stored.
	DataSections.Item	Item[Index: Integer]: IDataSection	read-only		The sections where data is stored.
IEvent					
	Event.Data	Data: OleVariant	read-only		The data of an event. This can be e.g. text or voice data. (not yet implemented)
	Event.PosDir	PosDir: Integer	read-only		Position within a data block.
	Event.PosMid	PosMid: Integer	read-only		Number of the data block.
	Event.TimeStamp	TimeStamp: Double	read-only		The time stamp of an event in seconds.
	Event.Type_	Type_: Integer	read-only		The type of an event. This can be: 1 indicating “start”, 2 indicating “stop”, 3 indicating “trigger”, 11 indicating “VStart” (video start storing) 12 indicating “VStop” (video stop storing) 20 indicating “Keyboard” 21 indicating “Notice” 22 indicating “Voice” 24 indicating “Module” (example: Bridge shunt on/off).
IEventList					
	EventList.Count	Count: Integer	read-only		The number of events.
	EventList.Item	Item[Index: Integer]: IEvent	read-only		The event items.
IExportFrame					
	ExportFrame.Apply	procedure Apply;			When the “Export data” button is clicked.
	ExportFrame.HideFrame	procedure HideFrame;			When the custom export is left.
	ExportFrame.ShowFrame	procedure ShowFrame(Handle: Integer; out FrameHeight: Integer);			When the setup frame of the custom export is shown.
IFilenameSettings					
	FileNameSettings.AutoCreate	AutoCreate: WordBool	read/write		Whether a data file name should be generated automatically.
	FileNameSettings.AutoFlipAbsTime	AutoFlipAbsTime: WordBool	read/write		Whether absolute time is used or not.
	FileNameSettings.AutoFlipFile	AutoFlipFile: WordBool	read/write		Whether a new file should be created after a certain criterion.
	FileNameSettings.AutoFlipSize	AutoFlipSize: Single	read/write		The size of a certain unit after which a new file will be created.

The DCOM Interface of DEWESoft 6.4 – DEWESoft DCOM Interface – Properties and Methods

	FileNameSettings.AutoFlipUnit	AutoFlipUnit: Integer	read/write		The unit of the AutoFlipSize which can be MB, h, min, sec or triggers.
	FileNameSettings.BaseFileName	BaseFileName: WideString	read/write		The file name prefix for automatic naming.
	FileNameSettings.MultiFileStartIndex	MultiFileStartIndex: Integer	read/write		The number to start from for the naming of multi files.
	FileNameSettings.UseDate	UseDate: WordBool	read/write		Whether the date should be included in the file name.
	FileNameSettings.UseMultiFile	UseMultiFile: WordBool	read/write		Whether to use the multi file option or not.
	FileNameSettings.UseTime	UseTime: WordBool	read/write		Whether the time should be included in the file name.
ILoadEngine					
	LoadEngine.CloseFile	procedure CloseFile ;			To close a measurement file.
	LoadEngine.DataSections	DataSections: IDataSections	read-only	autom.	See IDataSection.
	LoadEngine.FileOpened	FileOpened: WordBool	read-only	autom.	Whether a measurement file is opened or not.
	LoadEngine.NextDBLoad	function NextDBLoad: WordBool;		autom.	Proceeds to the next data block of the direct buffer. (See StartDBLoad)
	LoadEngine.NumBlocks	NumBlocks: Integer	read-only	autom.	Returns the number of data blocks.
	LoadEngine.ReducedOnly	ReducedOnly: WordBool	read-only	autom.	Whether data has been stored reduced only.
	LoadEngine.Reload	procedure Reload (Start: T_RecordPosition; Stop: T_RecordPosition);		autom.	Reloads a specific section of data.
	LoadEngine.ReloadBlock	procedure ReloadBlock (Num: Integer);		autom.	Called to reload a data block.
	LoadEngine.ShrinkFile	procedure ShrinkFile (const FileName: WideString);		autom.	For exporting a part of a measurement limited by Data.StartStamp und Data.EndStamp.
	LoadEngine.StartDBLoad	procedure StartDBLoad (Start: T_RecordPosition; Stop: T_RecordPosition; BlockSize: Integer);		autom.	Starts the loading of datablocks beginning at a certain position within the direct buffer, to a certain position within the direct buffer, of a certain blocksize. (See NextDBLoad)
	LoadEngine.VideoLoadEngine	VideoLoadEngines: IVideoLoadEngines	read-only	autom.	See IVideoLoadEngines.
IMasterClock					
	MasterClock.GetCurrentTime	function GetCurrentTime: Double;			The current time stamp during measurement.
IModule					
	Module.ClearModule	procedure ClearModule ;			Sets the address of a PAD-module back to 0.
	Module.DaqData	DaqData: IDaqData	read-only		See IDaqData.
	Module.DetectModule	procedure DetectModule (Address: Integer);			Detects a module at a certain address.
	Module.FillModule	function FillModule (Address: Integer; Timeout: Integer): WordBool;			Tries to set a PAD-module having address 0 to the given address and waits for pressing the button on the module.

The DCOM Interface of DEWESoft 6.4 – DEWESoft DCOM Interface – Properties and Methods

	Module.FREQAFindTriggerLeve	procedure FREQAFindTriggerLevel ;			Activates the auto-trigger of the FREQA-module.
	Module.GetPadData	procedure GetPadData ;			Retrieves the current data from the PAD-module.
	Module.GetSerialNumber	function GetSerialNumber : WideString;			Reads out the serial number of the module.
	Module.Index	property Index : Smallint	read-only		The index of the module.
	Module.ModuleType	property ModuleType : Smallint			The type of a module. 0...none 1...PAD 2...DAQ
	Module.PadData	property PadData : IPadData	read-only		See IPadData.
	Module.SetDaq	function SetDaq : WordBool;			Applies the configuration to a PAD-module.
	Module.SetDaqAddress	procedure SetDaqAddress (Address: Integer; Timeout: Integer);			Changes the address of the DAQ-module.
	Module.SetModule	procedure SetModule (SetType: Integer);			To apply the setting to a module. SetType always has to 2.
	Module.SetPad	procedure SetPad (NewAddress: Integer);			Sets the address and applies the configuration to a PAD-module.
IModules					
	Modules.Count	Count : Integer	read-only		The number of available modules.
	Modules.Item	Item [Index: Integer]: IModule	read-only		The array of modules of the type IModule.
IPadData					
	PadData.Address	Address : Smallint			The PAD-module's address.
	PadData.ConfigCode	ConfigCode : Smallint	read-only		The configuration code of a PAD-module
	PadData.CopyToString	function CopyToString : WideString;			Returns the data of the PAD-module as a string.
	PadData.CopyUnitToString	function CopyUnitToString : WideString;			Returns the unit of the PAD-module as a string.
	PadData.Data[]	Data [Index: Integer]: Single	read-only		The measurement data of the PAD-module as an array of Single values.
	PadData.ModuleAmpl	function ModuleAmpl : Single;			Returns module scale factor.
	PadData.ModuleOffset	function ModuleOffset : Single;			Returns the offset of the PAD-module.

	PadData.ModuleType	ModuleType: Smallint	read-only		the type of the PAD-module which can be one of the following: 0...Unknown 1...PAD-V8 2...PAD-VTH 3...PAD-TH8 4...PAD-RTD3 5...PAD-AO1 6...PAD-CNT 7...PAD-DI8 8...PAD-DO7 9...PAD-V8-P 10...PAD-TH8-P
	PadData.Name	Name: WideString	read-only		The name of the PAD-Module.
	PadData.RangeCode	RangeCode: Smallint			The range code of the PAD-module.
	PadData.RangeIndex[]	RangeIndex[Index: Integer]: Integer	read-only		Gives the range code of choosen range at Index.
	PadData.Ranges[]	Ranges[Index: Integer]: WideString	read-only		Gives the description of a range at the index.
	PadData.RangesCount	RangesCount: Integer	read-only		The number of ranges available for the module.
	PadData.ShortCopyToString	function ShortCopyToString: WideString;			Returns the data of the PAD-module in a short version (only the values) as a string.
	PadData.SpeedCode	SpeedCode: Smallint	read-only		The baudrate set on the module. The code is within the range 3...10 and having the following meaning: 3...1200 baud 4...2400 baud 5...4800 baud 6...9600 baud 7...19200 baud 8...38400 baud 9...57600 baud 10...115200 baud
IPlugin2					
	Plugin2.ClearChannelsInstance	procedure ClearChannelsInstance;		Plug-in	Before all channels are destroyed in DEWESoft. All instances have to be set to “nil” or “nothing”.
	Plugin2.Configure	procedure Configure;		Plug-in	When the “Configure”-Button is clicked. This button appears if there is no plug-in frame. Clicking can e.g. cause a configuration dialog to be opened.

The DCOM Interface of DEWESoft 6.4 – DEWESoft DCOM Interface – Properties and Methods

	Plugin2.HideFrame	procedure HideFrame ;		Plug-in	When the setup screen is left.
	Plugin2.Id	Id : WideString	read-only	Plug-in	GUID (Globally Unique Identifier) of the plug-in library.
	Plugin2.Initiate	procedure Initiate (const DeweApp: IApp);	read-only	Plug-in	When DEWESoft is started and the plug-in is checked in the hardware configuration.
	Plugin2.LoadSetup	procedure LoadSetup (Data: OleVariant);		Plug-in	When a channel setup is loaded (corresponds to File >> Load Setup). Data is an OleVariant and will contain plug-in specific settings if such settings are stored using SaveSetup(Data).
	Plugin2.NewSetup	procedure NewSetup ;		Plug-in	When a new channel setup is created (corresponds to File >> New Setup).
	Plugin2.OnGetData	procedure OnGetData ;		Plug-in	When new data is added to a channel. This happens every 40 ms. It is not necessary to add any new data.
	Plugin2.OnOleMsg	procedure OnOleMsg (Msg: Integer; Param: Integer);		Plug-in	When a plug-in has additional threads, these threads cannot directly send messages to DEWESoft at any time. Therefore additional threads have to use “App.MainWndMessage”. “OnOleMsg” will follow in order to be able to send the message to DEWESoft from within the main thread. (See App.MainWndMessage)
	Plugin2.OnStartAcq	procedure OnStartAcq ;		Plug-in	When data acquisition starts.
	Plugin2.OnStartStoring	procedure OnStartStoring ;		Plug-in	When the storing of data is started.
	Plugin2.OnStopAcq	procedure OnStopAcq ;		Plug-in	When data acquisition is stopped.
	Plugin2.OnStopStoring	procedure OnStopStoring ;		Plug-in	When the storing of data is stopped.
	Plugin2.OnTrigger	procedure OnTrigger (Time: Double);		Plug-in	When a trigger occurs. Returns the corresponding measurement time in seconds.
	Plugin2.SaveSetup	procedure SaveSetup (var Data: OleVariant);		Plug-in	When a channel setup is saved (corresponds to File >> Save Setup). The OleVariant Data can be used to store plug-in specific settings, which will be read again at LoadSetup(Data).
	Plugin2.ShowFrame	function ShowFrame (Parent: Integer): WordBool;		Plug-in	When entering the setup screen. True if there is any frame to show; otherwise false. Returns “Parent”. Only useful with programming environments supporting frames (e.g. not MS Visual Basic).

The DCOM Interface of DEWESoft 6.4 – DEWESoft DCOM Interface – Properties and Methods

	Plugin2.UpdateFrame	procedure UpdateFrame ;		Plug-in	When the frame is updated. This happens every 0.1 seconds when the application is in setup mode.
	Plugin2.Used	Used: WordBool	read/write	Plug-in	Corresponds to the check box in the hardware configuration in the plug-in tab.
IPlugin3					
	Plugin3.GetDWTypeLibVersion	function GetDWTypeLibVersion : Integer;		Plug-in	To return the DEWESoft type library version.
	Plugin3.OnAfterCalcMath	procedure OnAfterCalcMath ;		Plug-in	Similar to IPlugin2.OnGetData but called after calculation of Math channels, to be used if the results of the Math channels are relevant for the Plug-in.
	Plugin3.OnAfterStartAcq	procedure OnAfterStartAcq ;		Plug-in	Called by DEWESoft on starting the acquisition (equal to IPlugin2.OnStartAcq).
	Plugin3.OnAfterStopAcq	procedure OnAfterStopAcq ;		Plug-in	Called by DEWESoft on stopping the acquisition (equal to IPlugin2.OnStopAcq).
	Plugin3.OnAlarm	procedure OnAlarm (CondIndex: Integer; Status: WordBool);		Plug-in	Called by DEWESoft on the occurrence of an alarm.
	Plugin3.OnBeforeStartAcq	procedure OnBeforeStartAcq (var AllowStart: WordBool);		Plug-in	Called by DEWESoft before the acquisition is started. (For initialization of the plug-in.)
	Plugin3.OnBeforeStopAcq	procedure OnBeforeStopAcq (var AllowStop: WordBool);		Plug-in	Called by DEWESoft before the acquisition is stopped. AllowStop determines whether the acquisition is allowed to stop (default: True).
	Plugin3.OnBigListLoad	procedure OnBigListLoad (const TextSetup: WideString);		Plug-in	For internal use only.
	Plugin3.OnExit	procedure OnExit ;		Plug-in	Called by DEWESoft on closing.
	Plugin3.OnGetClock	procedure OnGetClock (var ClockLow: Integer; var ClockHigh: Integer);		Plug-in	To provide a clock to DEWESoft, if no AD-hardware is used.
	Plugin3.OnGetSetupData.	procedure OnGetSetupData ;		Plug-in	Similar to OnGetData, but will be called periodically when the setup screen is active.
	Plugin3.OnRepaintFrame	procedure OnRepaintFrame ;		Plug-in	Is called by DEWESoft 10 times per second for updating some information displayed in the plug-in frame.
	Plugin3.OnStartSetup	procedure OnStartSetup ;		Plug-in	Called by DEWESoft when the setup screen is entered.
	Plugin3.OnStopSetup	procedure OnStopSetup ;		Plug-in	Called by DEWESoft, when the setup screen is left.
	Plugin3.OnTriggerStop	procedure OnTriggerStop (Time: Double; TrigDuration: Double);		Plug-in	When the stop-trigger event happens

The DCOM Interface of DEWESoft 6.4 – DEWESoft DCOM Interface – Properties and Methods

	Plugin3.ProvidesClock	procedure ProvidesClock (var Value: WordBool);		Plug-in	Sets whether the plug-in provides a clock to DEWESoft or not.
	Plugin3.SetCANPort	procedure SetCANPort (Port: Integer);		Plug-in	Setting a CAN-port for using it for the plug-in.
IPluginGroup					
	PluginGroup.ClearAllChannels	procedure ClearAllChannels ;		Plug-in	Clear all mounted channels.
	PluginGroup.Count	Count : Integer	read-only	Plug-in	The number of mounted channels within the plug-in group.
	PluginGroup.ExportRate	ExportRate : Integer	read/write	Plug-in	Sample rate for exporting asynchronous data to DIAdem.
	PluginGroup.GetIndexName	function GetIndexName (Index: T_ChIndex): WideString;		Plug-in	Returns the name of an index of a channel.
	PluginGroup.Item	Item [Index: Integer]: IChannel	read-only	Plug-in	The item of a PluginGroup specified by Index.
	PluginGroup.MountChannel	function MountChannel (DataType: Integer; Async: WordBool; DBSize: Integer): IChannel;		Plug-in	To mount a channel to a certain group. DataType can be: 0...dtByte, 1...dtShortInt, 2...dtSmallInt, 3...dtWord, 4...dtInteger, 5...dtSingle, 6...dtInt64, 7...dtDouble. Async has to be True if it is an asynchronous channel, otherwise False. DBSize specifies the size of the direct buffer. If DBSize is set to -1, the default buffer size is applied.
	PluginGroup.Name	Name : WideString	read-only	Plug-in	The name of a channel within the plug-in group.
	PluginGroup.UnmountChannel	procedure UnmountChannel (var Channel: IChannel);		Plug-in	Allows removing one channel separately.
IScreen					
	Screen.Id	Id : Integer	read-only		The ID of a screen e.g. an “Overview”, a “Scope”, a “Recorder”, etc. (each of these categories can have more than one screen).
	Screen.IsCurrent	IsCurrent : WordBool	read-only		True, if the screen is currently shown.
	Screen.Name	Name : WideString	read-only		The name of a screen.
	Screen.Show	procedure Show ;			To show one specific screen.

The DCOM Interface of DEWESoft 6.4 – DEWESoft DCOM Interface – Properties and Methods

IScreens					
	Screens.Count	Count: Integer	read-only		The number of screens.
	Screens.Item	Item [Index: Integer]: IScreen	read-only		The screen items.
IStoreEngine					
	StoreEngine.AddNewEvent	procedure AddNewEvent (Type_: EventType; Data: OleVariant);			To add an event during storing of data.
	StoreEngine.FileSize	FileSize: Largeuint	read-only		The current file size in bytes.
	StoreEngine.IsTriggering	IsTriggering: WordBool	read-only		The state between a start- and a stop-trigger.
	StoreEngine.StoreMode	StoreMode: Integer	read-only		The Storing options like in the measurement setup. 0... “always fast” 1... “always slow” 2... “fast on trigger” 3... “fast on trigger, slow otherwise”
	StoreEngine.Storing	Storing: WordBool	read-only		Whether storing is currently active or not.
ITrig					
	Trig.NotOrList	NotOrList: ITriggerCondList;	read-only		NotOrList provides a trigger condition list of the type ITriggerCondList. The trigger conditions of this list are equal to the “Don’t store” conditions as found in DEWESoft’s measurement setup.
	Trig.OrList	OrList: ITriggerCondList;	read-only		OrList provides a trigger condition list of the type ITriggerCondList. The trigger conditions of this list are OR-combined.
	Trig.TrigIndex	TrigIndex: Integer	read-only		The index of the condition in the OrList which caused the trigger.
ITrigger					
	Trigger.HoldoffTime	HoldoffTime: Single	read/write		The holdoff time in ms.
	Trigger.HoldoffTimeUsed	HoldoffTimeUsed: WordBool	read/write		Whether the holdoff time is used or not.
	Trigger.PostTime	PostTime: Single	read/write		The post trigger time.
	Trigger.PostTimeUsed	PostTimeUsed: WordBool	read/write		Whether the PostTime is used or not.
	Trigger.PostTimeExtensionUsed	PostTimeExtensionUsed: WordBool	read/write		Whether the post time extension is used or not.
	Trigger.PreTime	PreTime: Single	read/write		The pre trigger time.
	Trigger.PreTimeUsed	PreTimeUsed: WordBool	read/write		Whether the PreTime is used or not.
	Trigger.StartTrig	StartTrig: ITrig	read-only		Start trigger
	Trigger.StopTrig	StopTrig: ITrig	read-only		Stop trigger

ITriggerCondition					
	TriggerCondition.Direction	Direction: Integer;			Direction defines the direction of a trigger condition. Valid values of this property are dependant on the Mode. For modes 0,1,4,5: 0...positive 1...negative 2...any edge For modes 2, 3: 0...enter 1...leave
	TriggerCondition.Level1	Level1: Single;			Level1 is the first trigger level.If only one of the trigger levels is available, this has to be assigned. So, it will be used in conjunction with any trigger mode if the trigger type is 0 (“on data”).
	TriggerCondition.Level2	Level2: Single;			Level2 is an additional trigger level which will be used in conjunction with the trigger modes tmFilteredEdge (1), tmWindow (2) and tmWindowPulsewidth (4), when the trigger type is 0 (“on data”).
	TriggerCondition.Mode	Mode: Integer;			Mode defines the trigger mode of the trigger condition, which can be one of the following: 0... tmSimpleEdge 1... tmFilteredEdge 2... tmWindow 3... tmPulsewidth 4... tmWindowPulsewidth 5... tmSlope
	TriggerCondition.TrigType	TrigType: Integer;			TrigType defines the type of a trigger which can be one of the following: 0...on data 1...on time 2...on FFT

The DCOM Interface of DEWESoft 6.4 – DEWESoft DCOM Interface – Properties and Methods

	TriggerCondition.TrigValue	TrigValue: Integer;			TrigValue determines which kind of value is used for the recognition of any trigger condition. This can be one of the following: 0...real data 1...average 2...RMS
ITriggerCondList					
	TriggerCondList.Add	function Add: ITriggerCondition;			Adds a trigger condition of the type ITriggerCondition to the list of trigger conditions.
	TriggerCondList.Count	Count: Integer;	read/write		The number of trigger conditions within the trigger condition list.
	TriggerCondList.Item[]	Item[Index: Integer]: ITriggerCondition;	read/write		An array of trigger conditions of the type ITriggerCondition. The index can be within the range of 0...Count-1.
	TriggerCondList.Remove	procedure Remove (Ind: Integer);			Removes the trigger condition specified by the index Ind. Ind has to be within the range 0...Count-1.
IVideoLoadEngine					
	VideoLoadEngine.GetFramesInfo	procedure GetFramesInfo (out Frames: OleVariant);			Gives information about the timestamps of the video-frames of one video file.
IVideoLoadEngines					
	VideoLoadEngines.Count	Count: Integer	read-only		The number of VideoLoadEngines.
	VideoLoadEngines.Item	Item [Index: Integer]: IVideoLoadEngine	read-only		One of the VideoLoadEngines which is of the type IVideoLoadEngine.
AOperationMode 					
	AOperationMode.aomFixed	aomFixed = 0			
	AOperationMode.aomSweep	aomSweep = 1			
	AOperationMode.aomStepSweep	aomStepSweep = 2			
	AOperationMode.aomBurst	aomBurst = 3			
	AOperationMode.aomChirp	aomChirp = 4			
AOSweepMode 					
	AOSweepMode.aosSingle	aosSingle = 0			
	AOSweepMode.aosLoop	aosLoop = 1			
AOWaveForm 					
	AOWaveForm.aowSine	aowSine = 0			
	AOWaveForm.aowTrian	aowTrian = 1			
	AOWaveForm.aowRect	aowRect = 2			

The DCOM Interface of DEWESoft 6.4 – DEWESoft DCOM Interface – Properties and Methods

	AOWaveForm.aowSaw	aowSaw = 3			
	AOWaveForm.aowWhiteNoise	aowWhiteNoise = 4			
	AOWaveForm.aowArbitrary	aowArbitrary = 5			
MenuItems 					
	MenuItems.ItemLoadSetup	ItemLoadSetup = 2			
	MenuItems.ItemSaveSetup	ItemSaveSetup = 0			
	MenuItems.ItemSaveSetupAs	ItemSaveSetupAs = 1			
EventReason 					
	EventReason.erGetData	erGetData = 0			
	EventReason.erStartStoring	erStartStoring = 1			
	EventReason.erStopStoring	erStopStoring = 2			
	EventReason.erTrigger	erTrigger = 3			
	EventReason.erException	erException = 4			
	EventReason.erTriggerStop	erTriggerStop = 5			
	EventReason.erAlarm	erAlarm = 6			
	EventReason.erExit	erExit = 7			
	EventReason.erDataLost	erDataLost = 8			
EventType 					
	EventType.etStart	etStart = 1			
	EventType.etStop	etStop = 2			
	EventType.etTrigger	etTrigger = 3			
	EventType.etKeyboard	etKeyboard = 20			
	EventType.etText	etText = 21			
	EventType.etVoice	etVoice = 22			
	EventType.etPicture	etPicture = 23			
	EventType.etModule	etModule = 24			
	EventType.etVStart	etVStart = 11			
	EventType.etVStop	etVStop = 12			
ExportTypes 					
	ExportTypes.etValueBased	etValueBased = 0			
	ExportTypes.etChannelBased	etChannelBased = 1			
T_CANFrame 					
	T_CANFrame.Byte0	Byte0: Byte			
	T_CANFrame.Byte1	Byte1: Byte			
	T_CANFrame.Byte2	Byte2: Byte			
	T_CANFrame.Byte3	Byte3: Byte			
	T_CANFrame.Byte4	Byte4: Byte			

The DCOM Interface of DEWESoft 6.4 – DEWESoft DCOM Interface – Properties and Methods

	T_CANFrame.Byte5	Byte5: Byte			
	T_CANFrame.Byte6	Byte6: Byte			
	T_CANFrame.Byte7	Byte7: Byte			
T_ChIndex 					
	T_ChIndex.Index1	Index1: Integer			Group
	T_ChIndex.Index2	Index2: Integer			Group dependant value.
	T_ChIndex.Index3	Index3: Integer			Group dependant value.
	T_ChIndex.Index4	Index4: Integer			Group dependant value.
	T_ChIndex.Index5	Index5: Integer			Group dependant value.
	T_ChIndex.IndexLevel	IndexLevel: Smallint			Number of used indexes.
T_RecordPosition 					
	T_RecordPosition.Mid	Mid: Integer			
	T_RecordPosition.Dir	Dir: Integer			
T_ReducedRec 					
	T_ReducedRec.Ave	Ave: Single	-		Average value in the reduced buffer.
	T_ReducedRec.Max	Max: Single	-		Maximum value in the reduced buffer.
	T_ReducedRec.Min	Min: Single	-		Minimum value in the reduced buffer.
	T_ReducedRec.Rms	Rms: Single	-		RMS value in the reduced buffer.
TSRDivType 					
	TSRDivType.sdSkip	sdSkip = 0			
	TSRDivType.sdAverage	sdAverage = 1			
	TSRDivType.sdFilter4th	sdFilter4th = 2			
	TSRDivType.sdFilter6th	sdFilter6th = 3			
	TSRDivType.sdFilter8th	sdFilter8th = 4			

Index

A

AbsoluteTime 40
Acquiring 65
ActiveChannels 93
ActiveCount 48
ActiveItem 48
ActiveScreen 64
ActualRunMode 65
Add 111
AddAsyncByteSample 75
AddAsyncDoubleSample 75
AddAsyncSingleSample 75
AddNewEvent 109
Address 90, 102
AddSingleSample 75
AddSingleSamples 75
AISetupScreen 65
Alarms 65
AllChannels 12, 93
AlwaysEnableTrigger 65
Ampl 50
AmplChangeFactor 52
AOChannels 52
AOGetManualAvail 54
AOGroup 65
AOSetManual 54
Apply 43
ApplyChannels 92
Async 78
AType 86
AutoCreate 97
AutoFlipAbsTime 97
AutoFlipFile 97
AutoFlipSize 97
AutoFlipUnit 97
AutoZero 88
AveCount 71
AveragedCPB 65
AverageType 72

B

BaseFileName 98
BlockSize 87
Borland Delphi 7 18
Buffer Structure 12
BuildChannelList 92
Bytes 79

C

CalculateFromPos 70
CAN 65
CardBitResolution 89
CardGain 89
CardOffset 89
ChangeComPort 55
ChangeDaqType 54
Channel 87
Channel Structur 12
ChannelGroup 12
ChannelGroups 12
ClearAllChannels 107

ClearChannelsInstance 103
ClearModule 100
CloseFile 99
ConfigCode 102
Configure 103
ConnTypes 87
ControlsClock 52
CopyToString 89, 102
CopyUnitToString 89, 102
Count 48, 73, 87, 88, 96, 102, 108, 111
CreateConnection 75
ctLast 86, 87
ctNew 86, 87
ctOverlap 86, 87
ctTrigger 86, 87
CurrentPos 94
CurrentSource 90
CustomExport 32

D

DaqData 101
DaqGroup 65
DaqNNames 90
DaqNNamesCount 90
Data 65, 96, 102
DataCount 40
DataLost 65
DataSections 100
DataType 79
DBBufSize 79
DBDataSize 79
DBPos 79
DBTimeStamp 79
DBValues 79
DCChangeFactor 52
DeltaFreq 52
Description 79
DetectModule 101
DEWESoft library 19
DEWESoft Library 13
direct buffer 12
Direction 110
DisableStoring 65

E

Enabled 65
EnableOutput 74
EndAlarm 49
EndChannel 37
EndDataFolder 37
EndDataSync 92
EndExport 38
EndHeader 38
EndInfo 38
EndRead 74
EndStamp 94
EndValue 38
EventList 66
ExportData 55
ExportOrder 80
ExportRate 87, 108
ExportType 40, 55
Extension 40

ExternalClock 94

F

FileName 41
FileNameSettings 66
FileOpened 100
FileSize 109
FillModule 101
FilterCode 90
FilterFreq1 50
FilterFreq2 50
FilterOrder 50
FilterProtoType 51
FiltersCount 90
FilterType 50
FindChannel 92
FindChannelByIndex 92
FindChannelByIndex1 92
frames 18
Freq 53
FREQAFindTriggerLevel 101
FREQAInputCoupling 90
FREQAOutputFilter 90
FREQATriggerLevel 90
FreqChangeFactor 53

G

Get_SupportsDouble 42
GetBaudRate 74
GetBaudRateList 74
GetChannels 71
GetCurrentTime 100
GetData 71
GetDataBlocks 84
GetDataBlocks1 84
GetDataValues 84
GetDataValues1 84
GetDBAddress 76
GetDWTypeLibVersion 41, 105
GetFramesInfo 112
GetIBValues 76
GetIndex1 76
GetIndexName 87, 92, 107
GetIndexName1 93
GetIndexNameShort 88, 93
GetIndexNameShort1 93
GetInterfaceVersion 56
GetPadData 101
GetRBValues 76
GetSamplesAcquired 93
GetScaledData 76
GetScaledDataEx 77
GetScaledDataEx1 77
GetSerialNumber 101
GetTSBlocks 85
GetTSBlocks1 85
GetTSDData 77
GetTSDDataEx 77
GetTSDDataEx1 77
GetTSValues 85
GetTSValues1 85
GetUnscaledData 77
GetUnscaledDataEx 78
GetUnscaledDataEx1 78
Globally Unique Identifier 13
Group 80

Groups 94
GUID 13

H

HardwareSetup 56
Height 66
HideFrame 43, 104
HighpassType 90
HoldoffTime 110
HoldoffTimeUsed 110

I

IAISetupScreen 48
IAAlarmCond 48
IAAlarms 48
IAOChannel 49
IAOGroup 52
IApp 54
IBBufSize 80
IBDataSize 80
IBPos 80
IBValues 80
ICAN 73
ICANPort 74
IChannel 75
IChannelConnection 84
IChannelGroup 87
IChannelGroup2 88
IChannelGroups 88
IChannelList 88
ICPInput 90
ICustomExport 36
ICustomExport2 36, 41
Id 108
IDaqChannel 88
IDaqData 89
IDaqGroup 91
IData 92
IDataSection 95
IDataSections 96
IEvent 96
IEventList 96
IExportFrame 36
ILoadEngine 97, 99
IMasterClock 100
IModule 100
IModules 102
IncDBSamples 78
Index 48, 80, 101
Index1 82
Index2 82
Index3 82
Index4 83
Index5 83
IndexLevel 82
IniFileDir 66
Init 56
Initiate 104
intermediate buffer 12
IPadData 102
IPlugin2 103
IPlugin3 105
IPluginGroup 107
IScreen 108
IScreens 108
IsCurrent 108

IsSetupMode 66
IStoreEngine 109
IsTriggering 109
Item 48, 73, 87, 88, 96, 102, 108, 111
ItemLoadSetup 70
ItemSaveSetup 70
ItemSaveSetupAs 70
ITrig 109
ITrigger 110
ITriggerCondition 110
ITriggerCondList 111
IVideoLoadEngine 112
IVideoLoadEngines 112

L

Left 66
Level1 111
Level2 111
Lines 72
LoadDBC 57
LoadDisplaySetup 57
LoadEngine 66
LoadFile 57
LoadModuleSetup 57
LoadSetup 57, 104
LogSweep 53

M

MainDataDir 66
MainDisplayColor 81
MainWndMessage 58
ManualStart 58
ManualStop 58
MasterClock 66
Measure 59
Measurement 81
MeasureSampleRate 66
MenuClick 59
MenuItems 70
MessageCount 75
Methods 48
Mode 111
ModuleAmpl 89, 102
ModuleError 91
ModuleGain 89
ModuleOffset 89, 90, 102
Modules 66
ModuleType 89, 91, 102
MountChannel 107
MultiFileStartIndex 98

N

Name 49, 81, 87, 91, 103, 108
NewSetup 59, 104
NextDBLoad 99
NotOrList 109
NumBlocks 87, 100
NumValues 87

O

Offset 51, 81
OnAfterCalcMath 105
OnAfterStartAcq 106
OnAfterStopAcq 106

OnAlarm 69, 106
OnBeforeStartAcq 106
OnBeforeStopAcq 106
OnBigListLoad 106
OnDataLost 69
OnEvent 69
OnException 69
OnExit 69, 106
OnGetClock 106
OnGetData 70, 104
OnGetSetupData 106
OnGetTime 70
OnOleMsg 104
OnRepaintFrame 106
OnResizeFrame 106
OnStartAcq 104
OnStartSetup 107
OnStartStoring 70, 104
OnStopAcq 104
OnStopSetup 107
OnStopStoring 70, 105
OnTrigger 70, 105
OnTriggerStop 70, 107
OperationMode 53
OrList 109
Overflow 91
Overlap 73, 87

P

PadData 102
Parent 66
PauseStoring 59
Phase 51
PhaseChangeFactor 53
PosDir 96
PosMid 96
PostTime 110
PostTimeExtensionUsed 110
PostTimeUsed 110
PreTime 110
PreTimeUsed 110
PrintScreen 60
Properties 48
ProvidesClock 107

R

Range 51
RangeCode 91, 103
RangeIndex 103
Ranges 91, 103
RangesCount 91, 103
RBBufSize 81
RBDataSize 81
RBPos 81
RBValues 81
ReadData 95
ReadData1 95
ReadMessage 74
reduced buffer 12
ReducedOnly 100
registry 13
regsvr32.exe 13
Reload 99
ReloadBlock 99
Remote 91
Remove 112

Reset 85
ResumeStoring 60

S

SampleRate 53, 94
Samples 94
SaveSetup 60, 105
Scale 81
ScaleValue 78
Screens 67
SendCommand 60
SendFrame 74
SetAbsMax 41
SetAbsMin 41
SetApp 41
SetBaudRate 74
SetCANPort 107
SetCardGain 88
SetChannel 41
SetChannelColor 42
SetColumnVisible 48
SetDaq 101
SetDaqAddress 101
SetDoubleFloat 42
SetFullScreen 60
SetHeaderData 60
SetInstrument 61
SetMainDataDir 62
SetModule 101
SetPad 101
SetRangeMax 42
SetRangeMin 42
SetScopeParams 62
SetScopeUsed 62
SetScreenIndex 62
SetSRDiv 78
SetSRDivType 78
SetStoreMode 63
SetTrigOffset 42
SetupScreen 63
ShortCopyToString 90, 102
Show 108
ShowChannelSetup 48
ShowFrame 43, 105
ShowInfoChannels 53
Shown 81
ShownChannels 94
ShowPropertyFrame 67
ShowSensorEditor 64
ShowSROptions 67
ShowStoreOptions 67
ShowStyle 68
ShrinkFile 100
SpeedCode 103
SRDiv 81
Start 85
StartAbsValue 38
StartChannel 38
StartDataField 38
StartDataFolder 38
StartDataSync 93
StartDBLoad 100
StartEvents 42
StartExport 39
StartFreq 53
StartInfo 39
StartModuleScan 64

StartRead 75
StartStamp 94
StartStoreTime 94
StartStoreTimeUTC 94
StartStoring 64
StartTime 54
StartTimeField 39
StartTrig 110
StartValue 39
Status 49
StayOnTop 68
Stop 64
StopEvents 42
StopFreq 54
StopModuleScan 64
StopOption 49
StopTime 49, 54
StopTrig 110
StopTrigger 49
StoreEngine 68
StoreMode 109
Storing 109
SupportsAsync 41
SupportsDouble 41
SupportsOutput 73
SupportsSRDiv 41
SweepMode 54

T

T_ChIndex 82
T_ReducedRec 84
Time 95
TimeIncrease 41
TimerInterval 68
TimeStamp 96
Top 68
Trigger 49, 68
TrigIndex 110
TrigPos 95
TrigType 111
TrigValue 111
Type_ 96
TypicalMaxValue 82
TypicalMinValue 82

U

Unit_ 82
UnmountChannel 108
UpdateFrame 105
UpdateHardwareSetup 64
Used 82, 105
UseDate 98
UsedChannels 12, 95
UsedDatafile 69
UsedSetupfile 69
UseMultiFile 98
UserScaleMax 82
UserScaleMin 82
UseTime 99

V

Version 69
VideoLoadEngines 100
Visible 69
Visual Basic 13

VRange 91

W

WaveForm 51

WideString 105

Width 69

Window 73

WriteAsyncDoubleValue 42

WriteAsyncValue 39

WriteDoubleValue 42

WriteErrorMessage 64

WriteEvent 43

WriteInfoDate 39

WriteInfoInteger 39

WriteInfoSingle 39

WriteInfoString 40

WriteValue 40

Z

ZeroAllAutoChannels 64