

SOFTWARE USER MANUAL

Brake Test V21-1



1. Table of contents

1. Table of contents	2
2. About this document	3
Legend	3
3. Software installation	3
4. Software configuration	4
5. Brake test plugin	5
5.1. Input channels	5
5.2. Start and stop conditions	6
5.3. Measurement results	7
6. Warranty information	9
6.1. Calibration	9
6.2. Support	9
6.3. Service/repair	9
6.4. Restricted Rights	9
6.5. Printing History	10
6.6. Copyright	10
6.7. Trademarks	10
7. Safety instructions	10
7.1. Safety symbols in the manual	10
7.2. General Safety Instructions	10
7.2.1. Environmental Considerations	11
7.2.2. Product End-of-Life Handling	11
7.2.3. System and Components Recycling	11
7.2.4. General safety and hazard warnings for all Dewesoft systems	11
8. Documentation version history	13

2. About this document

This is the users manual for the Brake test module.

Legend

The following symbols and formats will be used throughout the document.



Important

It gives you important information about the subject.
Please read carefully!



Hint

It gives you a hint or provides additional information about a subject.



Example

Gives you an example of a specific subject.

3. Software installation

After installing DewesoftX software package, download additional Brake test math.

Brake test: <https://download.dewesoft.com/list/plugins/brake-test>

Unzip the file and copy the content into DewesoftX(install folder)/Bin/Addons.

On the end run DewesoftX.exe as Admin to register the plugin.




Figure 1 - Run as Admin

4. Software configuration

After opening the software and configuration of input channels (Analog/digital inputs, CAN, GPS,...), go to Ch. Setup, click on button More and add Brake test mathematics module.




Figure 2 - Brake test software configuration

5. Brake test plugin

Here you can see the Brake test plugin setup form. All parameters for Brake test can be set here (Input channels, start and stop conditions, outputs,...).

Input

Velocity
Velocity

Distance
DistanceX

Acceleration
Acceleration

Output

TimeRef/Distance

Name: TimeRef/Distance

Description: -

Units: m

Color: [Yellow]

Preview Values

Max value: 5 m

Max Average Min: 0 m

Min value: -5 m

Brake Test Settings

Calculation type: Brake test

Start condition: Speed

Start value: 80

Stop condition: Speed

Stop value: 50

Output Tables

☒ Time reference
dt: 1

☒ Distance reference
ds: 1

☒ Velocity reference
dv: 10

☒ Distance
☒ Velocity
☒ Acceleration

☒ Distance
☒ Time
☒ Acceleration

☒ Distance
☒ Time
☒ Acceleration

Output Values

Index	Channel type	Properties
0	Start speed	
1	Stopping time	
2	Corrected brake distance	Start speed: 100
3	MFDD	Start speed: 80 km/h Stop speed: 10 km/h
4	Brake deceleration	
5	Custom	Type: Distance Value: 0 Output: Distance

Figure 3 - Brake test plugin overview

5.1. Input channels

Brake test plugin needs input data. Channels with input data are shown in the upper left part of the setup form. Just search for appropriate channels in dropdown list and select it:

- Velocity (km/h),
- Distance (m),
- Acceleration (m/s²)




Figure 4 - Input channels



Note: Correct units are very important inside the Brake test plugin!

5.2. Start and stop conditions


Start and stop conditions will define points where the test is started and where it ends. But first the type of test (Brake or Acceleration) has to be selected.

Options for **start conditions** are:

- **Speed** – Start at selected speed
- **Trigger** – Start on trigger defined by channel and value
- **Start of movement** – Just for acceleration test, where additional threshold has to be defined
- **Speed from channel** – Start when speed passes the value from certain single value channel (used to change speed limit with header/sequencer)

Options for **stop conditions** are:

- **Speed** – Stop at selected speed
- **Trigger** – Stop on trigger defined by channel and value
- **Distance** – Stop at certain distance
- **Time** – Stop after some time
- **Stop of movement** – Stop when vehicle stops. Additional threshold parameter has to be defined to interpolate the data
- **Speed from channel** - Start when speed passes the value from certain single value channel (used to change speed limit with header/sequencer)



The 'Brake Test Settings' dialog box contains the following fields:

- Calculation type:** Brake test (dropdown)
- Start condition:** Trigger (dropdown)
- Stop condition:** Stop of movement (dropdown)
- Trigger channel:** BrakePedal (dropdown)
- Trigger level:** 5 (text input)
- Threshold:** 1 (text input)


Figure 5 - Selecting Start/Stop condition

5.3. Measurement results

Next thing are the outputs. We have to define what we want to have as a result of the measurement. First there are tables which give more detailed information about the test. They are called reference tables and they can give values of Velocity, Distance, Acceleration and/or Time at certain measure points, which are defined with Velocity, Distance or Time intervals.

For example:

- a) Time and distance on every 10km/h speed change (1 on image below),
- b) Speed for every 1 m travel (2),...



The 'Output Tables' dialog box shows three reference tables with checkboxes for data to be recorded:

- Time reference:** dt 1. Includes checkboxes for Distance, Velocity, and Acceleration.
- Distance reference:** ds 1. Includes checkboxes for Velocity, Time, and Acceleration. This section is highlighted with a red box and a large red number '2'.
- Velocity reference:** dv 10. Includes checkboxes for Distance, Time, and Acceleration. This section is highlighted with a red box and a large red number '1'.

Figure 6 - Output tables

In total there are 9 options and just check the ones you need.



Important note: Value has to be bigger than 0!

Then there are single values which are calculated from test data. Those are:

- **Start speed** – Speed at start of the test
- **Stopping time** – Total stopping time
- **Corrected brake distance** – Calculated brake distance corrected for distance start speed. It is calculated from actual brake distance multiplied by the ratio of the square of the actual start speed to the nominated correct distance start speed.

$$CBD = \frac{(s_e - s_b) * v_{CBD}^2}{v_b^2}$$

s_e and s_b are distance at start and at the end. v_{CBD} is corrected start speed, v_b is start speed

- **MFDD** (Mean Fully Developed Deceleration) – is usually taken as average deceleration between 80 % and 10 % of the test start speed.
- **Brake deceleration** – This is average brake deceleration, calculated from start speed, stop speed and time
- **Custom** – Will give exact value of Distance, Speed or Time at certain point of test. For example when speed is 20 km/h or Time is 2s,... (Note: Only one additional Custom channel is allowed)
- **Max. deceleration** – Maximum deceleration during test, excluding last 0.5 sec.

Output Values		
<div> <div>+</div> <div>-</div> </div>		
Index	Channel type	Properties
0	Start speed	
1	Stopping time	
2	Corrected brake distance	Start speed <input type="text" value="100"/>
3	MFDD	Start speed <input type="text" value="80"/> km/h Stop speed <input type="text" value="10"/> km/h
4	Brake deceleration	
5	Custom	Type <input type="text" value="Distance"/> Value <input type="text" value="0"/> Output <input type="text" value="Distance"/>
6	Max. deceleration	

Figure 7 - Output values

6. Warranty information

Notice

The information contained in this document is subject to change without notice.

Note:

Dewesoft d.o.o. shall not be liable for any errors contained in this document. Dewesoft MAKES NO WARRANTIES OF ANY KIND WITH REGARD TO THIS DOCUMENT, WHETHER EXPRESS OR IMPLIED. DEWESOFT SPECIFICALLY DISCLAIMS THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. Dewesoft shall not be liable for any direct, indirect, special, incidental, or consequential damages, whether based on contract, tort, or any other legal theory, in connection with the furnishing of this document or the use of the information in this document.

The copy of the specific warranty terms applicable to your Dewesoft product and replacement parts can be obtained from your local sales and service office. To find a local dealer for your country, please visit <https://dewesoft.com/support/distributors>.

6.1. Calibration

Every instrument needs to be calibrated at regular intervals. The standard norm across nearly every industry is annual calibration. Before your Dewesoft data acquisition system is delivered, it is calibrated. Detailed calibration reports for your Dewesoft system can be requested. We retain them for at least one year, after system delivery.

6.2. Support

Dewesoft has a team of people ready to assist you if you have any questions or any technical difficulties regarding the system. For any support please contact your local distributor first or Dewesoft directly.

Dewesoft d.o.o.
Gabrsko 11a
1420 Trbovlje Slovenia

Europe Tel.: +386 356 25 300
Web: <http://www.dewesoft.com>
Email: Support@dewesoft.com
The telephone hotline is available Monday to Friday from 07:00 to 16:00 CET (GMT +1:00)

6.3. Service/repair

The team of Dewesoft also performs any kinds of repairs to your system to assure a safe and proper operation in the future. For information regarding service and repairs please contact your local distributor first or Dewesoft directly on <https://dewesoft.com/support/rma-service>.

6.4. Restricted Rights

Use Slovenian law for duplication or disclosure. Dewesoft d.o.o. Gabrsko 11a, 1420 Trbovlje, Slovenia / Europe.

6.5. Printing History

Version 2.0.0, Revision 217 Released 2015 Last changed: 23. July 2018 at 16:54.

6.6. Copyright

Copyright © 2015-2019 Dewesoft d.o.o. This document contains information which is protected by copyright. All rights are reserved. Reproduction, adaptation, or translation without prior written permission is prohibited, except as allowed under the copyright laws. All trademarks and registered trademarks are acknowledged to be the property of their owners.

6.7. Trademarks

We take pride in our products and we take care that all key products and technologies are registered as trademarks all over the world. The Dewesoft name is a registered trademark. Product families (KRYPTON, SIRIUS, DSI, DS-NET) and technologies (DualCoreADC, SuperCounter, GrandView) are registered trademarks as well. When used as the logo or as part of any graphic material, the registered trademark sign is used as a part of the logo. When used in text representing the company, product or technology name, the ® sign is not used. The Dewesoft triangle logo is a registered trademark but the ® sign is not used in the visual representation of the triangle logo.

7. Safety instructions

Your safety is our primary concern! Please be safe!

7.1. Safety symbols in the manual



Warning

Calls attention to a procedure, practice, or condition that could cause the body injury or death



Caution

Calls attention to a procedure, practice, or condition that could possibly cause damage to equipment or permanent loss of data.

7.2. General Safety Instructions



Warning

The following general safety precautions must be observed during all phases of operation, service, and repair of this product. Failure to comply with these precautions or with specific warnings elsewhere in this manual violates safety standards of design, manufacture, and intended use of the product. Dewesoft d.o.o. assumes no liability for the customer's failure to comply with these requirements.

All accessories shown in this document are available as an option and will not be shipped as standard parts.

7.2.1. Environmental Considerations

Information about the environmental impact of the product.

7.2.2. Product End-of-Life Handling

Observe the following guidelines when recycling a Dewesoft system:

7.2.3. System and Components Recycling

Production of these components required the extraction and use of natural resources. The substances contained in the system could be harmful to your health and to the environment if the system is improperly handled at its end of life! Please recycle this product in an appropriate way to avoid unnecessary pollution of the environment and to keep natural resources.



This symbol indicates that this system complies with the European Union's requirements according to Directive 2002/96/EC on waste electrical and electronic equipment (WEEE). Please find further information about recycling on the Dewesoft web site www.dewesoft.com

 Restriction of Hazardous Substances

This product has been classified as Monitoring and Control equipment and is outside the scope of the 2002/95/EC RoHS Directive. However, we take care of our environment and the product is lead-free.

7.2.4. General safety and hazard warnings for all Dewesoft systems

Safety of the operator and the unit depend on following these rules.

- Use this system under the terms of the specifications only to avoid any possible danger.
- Read your manual before operating the system.
- Observe local laws when using the instrument.
- DO NOT touch internal wiring!
- DO NOT use higher supply voltage than specified!
- Use only original plugs and cables for harnessing.
- You may not connect higher voltages than rated to any connectors.
- The power cable and connector serve as Power-Breaker. The cable must not exceed 3 meters, the disconnect function must be possible without tools.
- Maintenance must be executed by qualified staff only.
- During the use of the system, it might be possible to access other parts of a more comprehensive system. Please read and follow the safety instructions provided in the manuals of all other components regarding warning and security advice for using the system.
- With this product, only use the power cable delivered or defined for the host country.
- DO NOT connect or disconnect sensors, probes or test leads, as these parts are connected to a voltage supply unit.
- Ground the equipment: For Safety Class 1 equipment (equipment having a protective earth terminal), a non-interruptible safety earth ground must be provided from the mains power source to the product input wiring terminals.
- Please note the characteristics and indicators on the system to avoid fire or electric shocks. Before connecting the system, please read the corresponding specifications in the product manual carefully.

- The inputs must not, unless otherwise noted (CATx identification), be connected to the main circuit of category II, III and IV.
- The power cord separates the system from the power supply. Do not block the power cord, since it has to be accessible for the users.
- DO NOT use the system if equipment covers or shields are removed.
- If you assume the system is damaged, get it examined by authorized personnel only.
- Adverse environmental conditions are Moisture or high humidity Dust, flammable gases, fumes or dissolver Thunderstorm or thunderstorm conditions (except assembly PNA) Electrostatic fields, etc.
- The measurement category can be adjusted depending on module configuration.
- Any other use than described above may damage your system and is attended with dangers like short-circuiting, fire or electric shocks.
- The whole system must not be changed, rebuilt or opened.
- DO NOT operate damaged equipment: Whenever it is possible that the safety protection features built into this product have been impaired, either through physical damage, excessive moisture, or any other reason, REMOVE POWER and do not use the product until the safe operation can be verified by service-trained personnel. If necessary, return the product to Dewesoft sales and service office for service and repair to ensure that safety features are maintained.
- If you assume a more riskless use is not provided anymore, the system has to be rendered inoperative and should be protected against inadvertent operation. It is assumed that a more riskless operation is not possible anymore if the system is damaged obviously or causes strange noises. The system does not work anymore. The system has been exposed to long storage in adverse environments. The system has been exposed to heavy shipment strain.
- Warranty void if damages caused by disregarding this manual. For consequential damages, NO liability will be assumed!
- Warranty void if damage to property or persons caused by improper use or disregarding the safety instructions.
- Unauthorized changing or rebuilding the system is prohibited due to safety and permission reasons (CE).
- Be careful with voltages >25 VAC or >35 VDC! These voltages are already high enough in order to get a perilous electric shock by touching the wiring.
- The product heats during operation. Make sure there is adequate ventilation. Ventilation slots must not be covered!
- Only fuses of the specified type and nominal current may be used. The use of patched fuses is prohibited.
- Prevent using metal bare wires! Risk of short circuit and fire hazard!
- DO NOT use the system before, during or shortly after a thunderstorm (risk of lightning and high energy over-voltage). An advanced range of application under certain conditions is allowed with therefore designed products only. For details please refer to the specifications.
- Make sure that your hands, shoes, clothes, the floor, the system or measuring leads, integrated circuits and so on, are dry.
- DO NOT use the system in rooms with flammable gases, fumes or dust or in adverse environmental conditions.
- Avoid operation in the immediate vicinity of high magnetic or electromagnetic fields, transmitting antennas or high-frequency generators, for exact values please refer to enclosed specifications.
- Use measurement leads or measurement accessories aligned with the specification of the system only. Fire hazard in case of overload!

- Lithium ion batteries are classified as not hazardous when used according to the recommendations of the manufacturer described in Battery Safety Data Sheet, which is available for download from [this link](#).
- Do not switch on the system after transporting it from a cold into a warm room and vice versa. The thereby created condensation may damage your system. Acclimatise the system unpowered to room temperature.
- Do not disassemble the system! There is a high risk of getting a perilous electric shock. Capacitors still might be charged, even if the system has been removed from the power supply.
- The electrical installations and equipment in industrial facilities must be observed by the security regulations and insurance institutions.
- The use of the measuring system in schools and other training facilities must be observed by skilled personnel.
- The measuring systems are not designed for use in humans and animals.
- Please contact a professional if you have doubts about the method of operation, safety or the connection of the system.
- Please be careful with the product. Shocks, hits and dropping it from already- lower level may damage your system.
- Please also consider the detailed technical reference manual as well as the security advice of the connected systems.
- This product has left the factory in safety-related flawlessness and in proper condition. In order to maintain this condition and guarantee safety use, the user has to consider the security advice and warnings in this manual.

EN 61326-3-1:2008

IEC 61326-1 applies to this part of IEC 61326 but is limited to systems and equipment for industrial applications intended to perform safety functions as defined in IEC 61508 with SIL 1-3.

The electromagnetic environments encompassed by this product family standard are industrial, both indoor and outdoor, as described for industrial locations in IEC 61000-6-2 or defined in 3.7 of IEC 61326-1.

Equipment and systems intended for use in other electromagnetic environments, for example, in the process industry or in environments with potentially explosive atmospheres, are excluded from the scope of this product family standard, IEC 61326-3-1.

Devices and systems according to IEC 61508 or IEC 61511 which are considered as “operationally well-tried”, are excluded from the scope of IEC 61326-3-1.

Fire-alarm and safety-alarm systems, intended for the protection of buildings, are excluded from the scope of IEC 61326-3-1.

8. Documentation version history

Version	Date	Notes
V21-1	29.10.2021	New template, updated screenshots.