

## Firmware Upgrade in DEWESoft® X3

How-to, Version: 1.1, Date: 18.5.2018

DEWESoft d.o.o.
Gabrsko 11a, 1420 Trbovlje, Slovenia
www.dewesoft.com

support@dewesoft.com




## Required equipment

- DEWESoft® instrument
- DEWESoft® version X3 or above
- DEWESoft® firmware upgrade package (.dxu file)


## Upgrade process

- 1. Download the DEWESoft® upgrade package (.dxu file) from the DEWESoft® downloads page under the section Drivers.
- 2. Copy the file into the Firmwares folder of your DEWESoft® installation (e.g. D:\DEWESoftX\System\X3\Firmwares).
- 3. Connect the DEWESoft® instrument to the PC and run DEWESoft® X3.
- 4. Go to settings:






5. In settings go to the Update menu:



- 6. If the firmware package isn't selected, select it by pressing the  $\Theta$  button and find the folder with the firmware file in it.
- 7. Select the device you want to upgrade and start the firmware upgrade by pressing the "Upgrade" button.
- 8. The following window should appear indicating that the upgrade has begun:





9. Wait until the software finishes the upgrade and then press close:



10. After the upgrade the device status should turn green and state "Up to date".

Warning: Do not disconnect the device during the firmware upgrade!